

目盛り付き 保温保冷 蓋付きマグカップ

中国製

本体: ステンレス鋼

蓋: 飽和ポリエステル樹脂

スライド蓋、パッキン: シリコンゴム

[250 mL]

実容量: カップのみ 354 mL、蓋使用時 285 mL

保温効力: 61 °C以上(1時間)、38 °C以上(3時間)

保冷効力: 8 °C以下(1時間)、12 °C以下(3時間)

[400 mL]

実容量: カップのみ 508 mL、蓋使用時 435 mL

保温効力: 75 °C以上(1時間)、55 °C以上(3時間)

保冷効力: 7 °C以下(1時間)、10 °C以下(3時間)

- 保温効力とは、室温20 °C±2 °Cにおいて製品に沸騰水を飲み口下端まで満たし、縦置きにした状態で水温が95 °C±1 °Cの時から1時間・3時間放置した場合におけるその水の温度です。
- 保冷効力とは、室温20 °C±2 °Cにおいて製品に冷水を飲み口下端まで満たし、縦置きにした状態で水温が4 °C±1 °Cの時から1時間・3時間放置した場合におけるその水の温度です。

【蓋からのスライド蓋の外し方】

蓋の裏側からスライド蓋の突起を指で押し上げ取り外してください。

【蓋のスライド蓋の取り付け方】

蓋のスリットにスライド蓋の突起を押し込んでください。その際、蓋の突起とスライド蓋の溝を合わせるようにしてください。

※スライド蓋はシリコンゴム製なので取り付け取り外しの際、力をいれて行っても壊れることはありません。

△取扱上の注意

- 初めてご使用する際は、食器用中性洗剤で洗浄してからご使用ください。●乳幼児の手の届かないところに保管してください。また、お子様のいたずらには十分ご注意ください。ヤケドをするおそれがあります。●蓋・スライド蓋を開けたまま放置しないでください。本体が転倒して飲み物がこぼれ、ヤケドや物を汚す原因となります。●電子レンジ、食器洗い乾燥機は使用できません。●発酵・腐敗しやすいものは入れないでください。●落下や転倒等の強い衝撃や、無理な力は加えないでください。変形、破損の原因となります。●本体は煮沸しないでください。変形、破損の原因となります。●浸け置き洗いはしないでください。サビ発生の原因となります。●ご使用後は、すぐに洗浄し、乾燥させてください。●洗浄の際、研磨剤入りのスポンジ、金属たわし、クレンザー等は使用しないでください。表面をキズつけ、本品が破損するおそれがあります。●本体内側の変色は、サビの付着が原因と考えられ、水に含まれる鉄分などが付着したものです。食酢を10%程度入れたぬるま湯を本体に入れ、約30分後によく洗浄してください。

With scale Mug with lid

MADE IN CHINA

BODY: STAINLESS STEEL

LID: SATURATED POLYESTER RESIN

SLIDE LID, RUBBER SEAL: SILICONE RUBBER

[250 mL]

Actual Capacity: Cup only 354 mL, with lid 285 mL

Heat retention efficacy: 61 °C or higher (1 hour), 38 °C or higher (3 hours)

Cold retention efficacy: 8 °C or lower (1 hour), 12 °C or lower (3 hours)

[400 mL]

Actual Capacity: Cup only 508 mL, with lid 435 mL

Heat retention efficacy: 75 °C or higher (1 hour), 55 °C or higher (3 hours)

Cold retention efficacy: 7 °C or lower (1 hour), 10 °C or lower (3 hours)

- Heat retention efficacy is verified based on the water temperature measured after the product is filled with boiling water up to below the opening in a room temperature (20 °C±2 °C) environment and left upright for 1 to 3 hours from the time when the water temperature becomes 95 °C±1.
- Cold retention efficacy is verified based on the water temperature measured after the product is filled with cold water up to below the opening in a room temperature (20 °C±2 °C) environment and left upright for 1 to 3 hours from the time when the water temperature becomes 4 °C±1.

【How to remove the slide part of the lid】

Remove it by pressing the protrusion on the reverse side of the lid.

【How to install the slide part of the lid】

Push the protrusion of the slide part into the slit on the lid.

*Make sure to align the protrusions on the lid with the grooves on the slide part.

△CAUTION

- Wash with neutral dish detergent before first use.
- Do not keep within the reach of small children, and be careful not to allow them to play with the product. Otherwise this may cause burns.
- Do not leave the product with lid / slide lid open. If the product falls over, drinks may spill, causing burns and stains to surrounding area.
- Do not use in a microwave or dishwasher.
- Do not put in items that are prone to fermentation or spoilage.
- Do not subject to impact such as drops and falls, and do not apply excessive force. Otherwise this may cause deformation or damage.
- Do not sterilise by boiling. Otherwise this may cause deformation or damage.
- Do not soak. Otherwise rust may occur.
- Thoroughly wash and dry after use.
- Do not use an abrasive scouring pad, wire wool or cleanser to wash. This may scratch the surface and damage the product.
- There are rusty red dots. Fill the product with about 10% vinegar and 90% lukewarm water solution, and leave it for about 30 minutes. Finally, rinse well to completely remove the vinegar.