


- Thank you for purchasing the Floor Chair.
- Please read this instruction manual before attempting to assemble or use this product.
- After you have assembled this product, please store this manual somewhere safe for future reference.

Retain for future reference


Directions

- The floor chair features six reclining angles. Select recline angle 1 2 3 4 5 6 for use.
- Recline the Floor Chair until you hear a solid click. The chair will remain at that angle.
- To return to the original/flat angle:
Move the chair back rest forward past 90 degrees to release the lock mechanism.
- The chair seat surface is the side with the fastener on the bottom.



⚠ Please use this product with the specially designed Floor Chair cover (sold separately).

Fastener
(Bottom Side)



⚠ Do not remove the inner cover

Notes about the Floor Chair

- This product may show some urethane discoloration that has occurred during the manufacturing process. Such discoloration has no effect on the function of this product.
- This product has been molded from tiny urethane foam chips. You may notice some tiny urethane chips attached to the surface of this product, etc. during use.
- The base color of the urethane foam chips is blue. However, the urethane foam may also contain white or yellow chips.
- Due to its nature, urethane foam will yellow over time if left standing for long periods. This discoloration has no effect on the function of this product.
- This product may present a distinct urethane odor upon unpacking. This odor will dissipate over time as the product is used.
- Should this odor be bothersome in the meantime, place the Floor Chair in a well-ventilated area out of direct sunlight to air out.
- A fastener is affixed to the inner cover of this product. Please do not open this fastener. It was used to insert the internal components of this product.
- The inner cover is not removable.
- The inner cover is not washable.

⚠ Warning

- Do not sit down on this chair with extreme force.
- Placing an extreme force or load on the back rest of the Floor Chair may damage the gear mechanism. Please exercise caution.
- Place a rug or carpet underneath the Floor Chair when using on a tatami mat or wooden flooring, etc. The Floor Chair may damage such surfaces if used directly on them.
- Do not sit on the top of the back rest. Doing so may cause the Floor Chair to flip over, damaging the chair or causing injury.
- Do not drag the Floor Chair across floors, as doing so may damage your floor's surface.
- Avoid placing the Floor Chair in direct sunlight or close to open flames. Doing so may cause the chair to warp, discolor, or catch fire.
- A gear mechanism is located between the Floor Chair back and seat sections. When the chair is in a full flat position, standing or stepping on the gear mechanism may cause an injury. Please supervise children when they use this product.

Quality Labeling for Chairs

Measurements:

Large: Width 570mm Depth 1,020mm Height 100mm

Small: Width 460mm Depth 860mm Height 100mm

Structural Components: Metal (steel)

Cover: 100% Polyester

Cushion: Urethane Foam

Warning

- Avoid exposing product to direct sunlight or heat.
- The cover is not removable.
- The cover is not washable.