


ALUMINUM ROUND FOUNTAIN PEN

How to use:

Remove cap and twist bottom of pen shaft counterclockwise to separate.
Remove the ink cartridge inside.

With pointed end of the ink cartridge facing up, push top of pen shaft down onto cartridge.



- Precautions:
Pen tip will dry out if pen is left with cap off. Close cap securely after use.
Avoid keeping the pen with tip facing downward.
When the pen is not used for long periods, be sure to remove ink and wash pen nib with lukewarm or just water before keeping it.
- Replacing Cartridge:
Use ink cartridge from Aluminum Round Fountain Pen (sold separately).