

オーク材アームチェア・丸脚

OAK / ROUND LEG ARM CHAIR

白橡木扶手椅/圆脚

取扱説明書

User Guide

使用说明书

日本語

この度は本製品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 7.

中文

本次承蒙惠购本产品，在此深表感谢。
请从第十三页开始阅读。

オーク材アームチェア・丸脚

取扱説明書

この度は本商品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2～3
パーツリスト	4
各部の名称	4
ご使用方法	4
お手入れ方法	5
ご使用に際して	5
製品仕様	6
お問い合わせ先	6

重要なお知らせ（安全上のご注意）

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び治療に入院、長期の通院を要するものをさします。

※2 傷害とは、治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。




警告





禁止

- 乳幼児を寝かさないでください。床への落下や窒息など思わぬケガをするおそれがあります。
- 保護者の目の届かないところで、お子さまだけでは使用させないでください。
- 座面の上に立ったり、飛びはねたり、踏み台代わりに使用しないでください。バランスを崩し転倒したり、商品の破損によりケガをする原因となります。
- 座った状態でチェアを傾けるなど不安定な状態では使用しないでください。転倒や商品の破損によりケガをしたり、床をキズつける原因となります。
- 座面に浅く腰掛けしないでください。転倒や商品の破損により思わぬケガをする原因となります。
- 座面以外に座らないでください。ケガの原因になることがあります。
- 2人以上では使用しないでください。転倒や破損によりケガをするおそれがあります。
- 不安定な状態や場所で使用しないでください。転倒によりケガをする原因になることがあります。
- ストーブなど引火するおそれのあるものを近くに置かないでください。火災の原因になります。
- タバコの火などを商品に落とさないでください。火災の原因になります。
- 製品の脚で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因になることがあります。
- 不要になった包装材料のプラスチック製の袋は乳幼児の手の届くところに置かないでください。頭からかぶるなどしたときに口や鼻をふさぎ窒息するおそれがあります。
- 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。


⚠ 注意	
 禁止	●移動する際は、引きずったり落としたりしないでください。商品の破損、床面へのキズの原因となります。  ●本来の用途以外では使用しないでください。思わぬ事故やケガの原因となります。 ●フェルトを貼った状態では凹凸や継ぎ目などの段差のある床面では使用しないでください。フェルトがはがれて、床面を汚したり、キズつけたりする原因となります。 ●破損や変形、木部の欠けなど生じた状態では使用しないでください。思わぬケガをするおそれがあります。 ●修理及び改造はしないでください。製品の強度が弱くなりケガをするおそれがあります。
	 行う ●使い始めるときは、室内の換気を十分にしてください。ホルムアルデヒド放散量の少ない木材を使用しておりますが、ホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。 ●使用時は脚の裏にフェルトなどの保護材を貼るか、敷物を敷くなどしてご使用ください。そのまま使用すると、床面をキズつける原因となります。また、クッションフロアなどの場合は木部の塗料とクッションフロアの反応により変色する可能性があります。 ●各部にゆみやぐらつきがないか定期的に点検し、異常が見られたら使用を中止してください。商品の破損、ケガの原因となります。

お願い (その他 注意)	
	●平らで安定した場所に設置してください。不安定な場所での使用は、製品がゆがんだり、破損の原因になることがあります。 ●直射日光や照明、ストーブやエアコンなどの熱や温風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になります。 ●直接日光のあたる部屋へ設置する場合はカーテンなどを利用し、直接日光があたらないようにしてください。反りやゆがみ、割れ、変色などの原因になります。 ●暖房器具を使用する場合は室内温度は適正に保つようにしてください。冬場など暖房器具による室内の極端な乾燥は天然木材の割れや反りの原因になります。 ●チェアに直接熱いものや濡れたものを置いたり、ビニール等長時間おおって使用しないでください。反ったり、変色したりする原因となります。 ●シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。変色や変形の原因となります。 ●化学雑巾を長時間接触させたままにしないでください。変色したり、表面がはがれたりすることがあります。 ●廃棄の際は、居住地域自治体のルールに従い、処分してください。

パーツリスト

①本体× 1 	フィッティングパーツ ②フェルト× 4 
---	---

各部の名称




ご使用方法

必要に応じて、床面の保護の為に付属③フェルトを脚の底に貼ってください。

お願い
(その他
注意)

貼られる際は、貼る面のほこりなどの付着物を拭き取ってください。付着物があると粘着力が低下します。貼った後は全体をしっかりと押さえて、ムラなく接着してください。



お手入れ方法

保守点検

- 金具類はゆるみやグラつきがないか定期的に点検し、ゆるみははじめたら、しっかり締め直してください。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

木部のお手入れ

- 塗装面のほこりはやわらかい布または、はたきで軽く払ってください。硬い布でほこりのあるままでこすると細かいキズがついてかえって逆効果です。通常、やわらかい布での乾拭きで十分です。
- 汚れのひどい時は、薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよく拭き取ってください。次に乾いたやわらかい布で軽く拭いた後、自然乾燥させてください。
- 化学雑巾を長時間、接触させておくと変色したり表面がはげたりすることがありますのでご注意ください。

ご使用に際して

天然木について

- 本商品は天然木を使用しているため、木目や色合い等、天然木材特有の個体差があります。そのため、商品として木目や色調に差がありますが、あらかじめご了承ください。
- 天然木は下記条件により割れや反りなどが発生することがありますのでご注意ください。
 - ①直射日光のあたる場所でのご使用はできる限りお避けください。どうしても直射日光が当たる場所は、カーテンなどでできる限りお避けください。
 - ②冷暖房器具の近くでのご使用はできる限りお避けください。必ず冷暖房の風が直接当たらないようにしてください。
 - ③特に冬の暖房による室内の極端な乾燥は、天然木の割れや反りを発生させる原因になります。

ホルムアルデヒドの対策について

- ホルムアルデヒドとは
ホルムアルデヒドは、シックハウス症候群の原因物質の一つといわれています。常温で気化する無色で刺激臭のある化学物質で、家具はもとより建築資材、壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。
- お部屋の換気をしてください。



家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。複数の家具を同時に設置した場合は特に窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は特に換気をするようご注意ください。換気効率を上げるため、複数の窓を開けたり、換気扇、扇風機、サーキュレーターなどの利用をおすすめします。

- 化学物質に敏感な体質のお客様へ
ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質は許容量に個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましてもホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。アレルギー症状が起きた際は、医師にご相談される事をおすすめします。

- 無印良品の家具は梱包内にホルムアルデヒド吸着・分解シート（※）を入れて出荷しています。

（※ホルムアルデヒド吸着・分解シート：アイシン精機(株)との共同開発）

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、少しでもお客様のお手元に届くまでにホルムアルデヒド濃度を低下させるためにホルムアルデヒド吸着・分解シートを入れてあります。※同梱の「ホルムアルデヒド吸着・分解シート」は、効力が落ちておりますので、燃えるゴミとして処分してください。

製品仕様

品 名	オーク材アームチェア・丸脚
製 品 寸 法	幅 555 × 奥行 505 × 高さ 730 mm（座面の高さ：445 mm）
製 品 質 量	約 5.6 kg
用 途	チェア（1人用）
材 質	構造部材：天然木（オーク材） 表面加工：ウレタン樹脂塗装
原 産 国	日本

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様室までご連絡ください。

株式会社 良品計画

〒170-8424

東京都豊島区東池袋 4-26-3

お客様室でんわ



0120-14-6404

受付時間 ■平日 10:00 ～ 21:00
■土・日・祝 10:00 ～ 18:00

OAK / ROUND LEG ARM CHAIR

User Guide

Thank you for your purchase.

Read the User Guide before use to ensure correct use of this product.

Please store this User Guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	8 - 9
Parts	10
Part Names	10
Directions for Use	10
Care Instructions	11
Usage	11
Specifications	12
Contact Information	12

Important Information (Safety Advice)

These instructions
must be followed.

This User Guide contains important information for the safe use of this product in order to prevent harm to the user and others or damage to the property.

Please note the following contents (indications and graphic symbols) before reading the main contents of this User Guide, and follow the instructions given.

- Explanations of Indications

If the product is used incorrectly, the degree of injury or damage that may arise is classified and explained with the following symbols.

 Warning	Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury* ¹ to the user.	 Caution	Indicates a hazard with a level of risk which, if not avoided, could result in injury* ² to the user or property damage* ³ .
--	---	--	--

- Explanations of Graphic Symbols

Instructions are given in the form of the following graphic symbols. (Examples of graphic symbols are as follows.)

 DON'Ts: Actions that are prohibited.	 DOs: Actions that must be taken.
---	---

*1 "Serious injury" indicates blindness, injuries, burns, bone fractures, poisoning, or electric shocks which have long term effects and require hospitalisation and / or long-term hospital visits for treatment.


*2 "Injury" indicates injuries or burns which do not require hospitalisation or long-term hospital visits for treatment.

*3 "Property damage" indicates an extended damage that involves the house or household property.

 Warning	
 DON'Ts	• Do not lay an infant on the product. Doing so may result in unexpected accident, such as the infant falling to the floor or suffocating. • Do not let children use the product without adult supervision. • Do not stand or jump on the seat of this product or use it as a stepladder. Doing so may result in injury from losing balance and falling, or damage to the product. • Do not use in an unstable condition, such as tilting the chair while sitting on it. Doing so may result in injury due to falling or damage to the product, or damage to the floor. • Do not sit on the front edge of the seat. Doing so may result in unexpected injury from falling or damage to the product. • Do not sit on any part other than the seat. Doing so may cause injury. • Do not allow more than two people to use the product at the same time. Doing so may result in injury due to falling or damage to the product. • Do not use in an unstable state or location. Doing so may result in injury due to falling. • Do not place the product near an object that may catch fire such as a room heater. Doing so may cause a fire. • Do not drop hot items such as a lit cigarette onto the product. Doing so may cause fire. • Do not place a leg of the product on the power cord of an electrical appliance. Doing so may damage the cord, resulting in electric shock or a fire. • Do not keep unwanted packaging materials within reach of small children. Small children may accidentally pull them over the mouth or nose, causing suffocation. • Do not use outdoors. Doing so may cause deformation or severe degradation of the product, resulting in injury.



Important Information (Safety Advice)

These instructions must be followed. (Cont'd)


 Caution	
 DON'Ts	- Do not drag or drop the product when moving it. Doing so may cause damage to the product or scratches to the floor.  - Do not use for other than its intended purpose. Failure to do so may result in an unexpected accident or injury. - Do not use on an uneven or jointed floor when the felt is attached to the product. Doing so may cause the felt to be removed, resulting in dirt or scratches on the floor surface. - Do not use if there is any damage, deformation, or chips in the wooden sections. Doing so may cause unexpected injury. - Do not attempt to repair or modify. Doing so may weaken the product, resulting in injury.
 DOs	- Ventilate the room well at the early stage of product use. Wooden materials that emit as little formaldehyde as possible are used. However, formaldehyde may still remain, and those with chemical sensitivity or small children may experience allergic reactions. - Be sure to attach protective material such as felt to the underside of legs, or use on top of a rug or something similar. Using without either may cause scratches on the floor, etc. Additionally, using on a cushioned floor may cause discolouration of the cushioned floor due to a reaction between the coating materials of wooden parts and the cushioned floor. - Periodically check for any looseness or wobbling in all of the parts, and stop use immediately if any abnormalities are found. Failure to do so may cause damage to the product or injury.

Note (Other Cautions)	
	- Install in a level and stable place. Using the product in an unstable place may distort or damage the product. - Do not expose to direct sunlight, lighting or heat and air from appliances such as a heater or air conditioner. Doing so may cause warping, cracks or discolouration. - When installing the product in a room that is subject to direct sunlight, use a curtain, etc., to protect the product from direct sunlight. Failure to do so may cause warping, cracks or discolouration. - When using a heating appliance, be sure to keep the room at an appropriate temperature. Using heating appliances during the winter season may cause the room to become particularly dry, resulting in cracking or warping of natural wood. - Do not place hot or wet items directly on the chair, or cover the product in plastic, etc. for use for a long period of time. Doing so may result in warping or discolouration. - Do not use an organic solvent such as thinner or bleach to clean the product. Doing so may cause deformation or discolouration. - Do not leave a chemical wipe on the product for a long time. Doing so may cause discolouration or peeling of the surface material. - To dispose of this product, follow the rules implemented by your local government.

Parts

Ⓐ Body × 1 	Parts Ⓐ Felt × 4 
---	---

Part Names




Directions for Use

If necessary, attach the provided Ⓐ felt to the underside of legs in order to protect the floor.

Note
(Other
Cautions)

Remove any debris such as dust from the surface before attaching the felt. Debris reduces the adhesive of the felt. Press the whole felt hard to ensure even adhesion.



Care Instructions

Maintenance and inspection

- Periodically check for any looseness in fittings, and re-tighten them if any looseness is found.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, insect damage may worsen.

Maintenance for wooden sections

- Gently wipe off dust from coated surfaces using a soft cloth or duster. Rubbing dusty surfaces with a hard cloth is counter-productive as it may cause small scratches. Normally, wiping off with a soft, dry cloth is sufficient for cleaning.
- If the product is particularly dirty, clean it using a cloth soaked in a neutral detergent solution, and then wipe off any detergent residue with a damp cloth. Next, gently wipe with a soft, dry cloth and let the product dry naturally.
- Do not leave a chemical duster in contact with the product for a long time, as doing so may cause discolouration or peeling of the surface coating.

Usage

Natural wood

- This product is manufactured using natural wood. There are differences in the grain and colouring as a result of these natural materials.
Please note that the wooden grains and colours of the all products are not the same.
- Please note that cracks and warping may occur in natural wood in the following conditions.
 - ① Avoid use in a place that is subject to direct sunlight. If use in direct sunlight is unavoidable, reduce the amount of sunlight using curtains, etc.
 - ② Avoid use near heaters or air conditioners. Be sure that the air from heaters or air conditioners does not come into direct contact with the product.
 - ③ In particular, air from heaters in the winter season is very dry and can easily cause cracks and warping in natural wood.

Formaldehyde countermeasures

- What is Formaldehyde?
Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent smelling compound that vaporizes at room temperature, and is found in such items as furniture, building materials and wallpaper adhesives. It is released gradually, and people in a room where formaldehyde has accumulated for a long time may experience symptoms such as itchy eyes or a sore throat. A high concentration of formaldehyde may cause breathing difficulties.
- Ventilate the room.



Ventilate the room well when installing the furniture.
Small children and those who are sensitive to chemicals may have allergic reactions.

Formaldehyde is easily dispersed in the air. Therefore, be sure to ventilate the room regularly. When several pieces of furniture are installed at the same time, open the windows widely for sufficient ventilation. More formaldehyde is released when the room temperature increases. Therefore, be careful if the room is closed for a long time during the summer, and ventilate the room thoroughly. In order to increase ventilation efficiency, it is recommended that you open multiple windows, or use a ventilation fan or air circulator.

- For persons who have high sensitivity to chemicals
There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even when the actual formaldehyde value in the room is lower than the indoor concentration guideline value (indoor concentration of formaldehyde that is tolerable for health), some people react to formaldehyde. At present, MUJI furniture products are made with materials that emit as little formaldehyde as possible, but this does not guarantee that no formaldehyde is emitted at all.
We recommend consulting a physician if you experience any allergic symptoms.
- MUJI furniture products contain formaldehyde absorption / decomposition sheets(*) as part of the packing materials.

(* Formaldehyde absorption / decomposition sheet: Jointly developed with Aisin Seiki Co., Ltd.)

If the product is used in a restricted space, formaldehyde may be re-absorbed by the material if there is nowhere for it to dissipate. Formaldehyde absorption / decomposition sheets are used to reduce the concentration of formaldehyde as much as possible before the product reaches the customer.

* Effectiveness of the "formaldehyde absorption / decomposition sheet" in the packaging has been expended by the time the package reaches the customer, and it can be disposed of as burnable rubbish.

Specifications

Product Name	OAK / ROUND LEG ARM CHAIR
Product Dimensions	W555 × D505 × H730mm (seat height 445mm)
Product Weight	Approx. 5.6kg
Usage	Chair (for 1 person)
Materials	Structural Materials: Natural Wood (Oak) Surface Treatment: Urethane Resin Coating
Country of Origin	Japan

Contact Information

For your inquiry about the product, please contact the store where you bought it.

白橡木扶手椅/圆脚

使用说明书

本次承蒙惠购本商品，在此深表感谢。
使用前请务必仔细阅读本文，并在充分理解的基础上再进行使用。
此外，请务必妥善保管本文，以备随时进行确认。

目录	页
重要通知 (安全注意事项)	14 ~ 15
配件清单	16
各部位名称	16
使用方法	16
保养方法	17
使用注意事项	17
产品规格	18
联系方式	18

重要通知(安全注意事项)

请务必遵守。

为了防止使用者或他人遭受危害和经济损失，本文中记述了确保安全且正确使用的重要内容。
请在充分理解下述内容(标示/图形符号)的基础上仔细阅读本文，并严格遵守所述事项。

●标示说明
按错误使用所造成的危害或损失程度进行分类说明。

 警告 可能会导致使用者死亡或重伤(※1)的内容。	 注意 可能会导致使用者遭受伤害(※2)或物质损失(※3)的内容。
---	---

●图形符号说明
通过以下图形符号对应严守的内容进行说明。(以下为图形符号范例。)


 不得执行的“禁止”内容。	 必须执行的“强制”内容。
--	--

※1 所谓重伤，是指因失明或受伤、烫烧伤、骨折、中毒、触电等原因而留下后遗症以及需住院治疗、长期就医的伤势。
※2 所谓伤害，是指无需治疗或住院、长期就医的受伤、烫烧伤。
※3 所谓物质损失，是指住房、家庭财产相关的连带损失。


禁止



 **警告**

- 请勿让婴幼儿睡在本产品上。否则可能导致摔落地面或窒息等意外受伤。
- 请勿让儿童在无家长监督的环境下单独使用。
- 请勿在座面上站立、跳跃或将其作为脚踏使用。否则可能因失衡翻倒、商品损坏而导致受伤。
- 坐着时使商品倾斜等不稳定的状态下请勿使用。否则可能因翻倒或商品损坏而导致受伤或损伤地面。
- 请勿坐于座面边缘。否则可能因翻倒或商品损坏而导致意外受伤。
- 请勿坐在座面以外的地方。否则可能导致受伤。
- 请勿2人以上同时使用。否则可能因翻倒或商品损坏而导致受伤。
- 请勿在不稳定的状态或场所使用。否则可能导致翻倒而受伤。
- 请勿设置于火炉等火源附近。否则可能引起火灾。
- 请勿让烟灰等掉落于商品上。否则可能引起火灾。
- 请注意不要使产品脚部压住家电产品的电源线。否则可能会因电源线裂损而导致触电、火灾。
- 请将不要的塑料袋包装材料放置于婴幼儿无法触及的场所。否则可能有因包装材料套住头部等阻碍嘴或鼻的呼吸而导致窒息的危险。
- 请勿在室外使用。否则可能发生变形或严重劣化而导致受伤。


! 注意	
 禁止	● 移动时请勿在地面上拖动或使其掉落。否则可能导致商品损坏、地面损伤。  ● 请勿用于原本用途以外的其他用途。可能会导致意外事故以及受伤。 ● 请勿在粘贴毛毡的状态下设置于有凹凸或接缝等高低不平的地面上使用。否则可能导致毛毡剥落、污损或损伤地面。 ● 请勿在商品损坏、变形或木材残缺等状态下使用。否则可能会导致意外受伤。 ● 请勿擅自修理或改造。否则可能导致产品强度下降而受伤。
 严守	● 刚开始使用时，请务必对室内进行充分换气。虽然已使用甲醛扩散量较少的木材,但是仍可能含有甲醛残留物，可能导致化学物质过敏体质者及婴幼儿等出现过敏症状。 ● 使用时请在椅脚的底面贴上毛毡等保护材料，或铺设铺垫物等再使用。如果直接使用可能会损伤地面。此外，用于软木地板等时，可能会由于木材的涂料与软木地板发生反应而导致变色。 ● 请定期检查各部分是否没有松动或摇晃，发现异常时请立即停止使用。否则可能导致商品损坏、受伤。

请求(其他 注意事项)	
	● 请设置于平坦、稳定的场所。如果在不平稳的场所使用，则可能导致产品变形、损坏。 ● 请勿使商品受到阳光直射以及直接接触照明、火炉和空调等热源及冷暖风直吹。否则可能导致弯曲或歪斜、开裂、变色等。 ● 设置在阳光直射的房间时，请使用窗帘等遮挡，避免阳光直射。否则可能导致弯曲或歪斜、开裂、变色等。 ● 使用暖气设备时,请保持适当的室内温度。冬季等使用暖气设备使室内极度干燥时，可能导致天然木材发生开裂、弯曲。 ● 请勿在椅子上直接放置过热或濡湿的物品，也请勿用塑料布等长时间覆盖。否则可能导致弯曲、变色。 ● 清洁时，请勿使用天那水等有机溶剂或漂白剂等药剂。否则可能导致变色或变形。 ● 请勿使产品长时间接触化学抹布。否则可能导致变色或表面剥落。 ● 报废时，请按各地区规定的方式进行废弃处理。

配件清单

① 主体 × 1 	组装零件 ② 毛毡 × 4 
---	---

各部位名称




使用方法

必要时，请在产品脚底粘贴保护地面用的附属配件②毛毡。

请求
(其他
注意事项)

粘贴时，请先将椅脚粘贴面上的灰尘等附着物擦拭干净。带有附着物将会导致粘着力下降。
粘贴后，请对粘贴面整体进行按压，确保粘合均衡。



保养方法

保养 / 检查

- 请定期检查金属部件类有无松动或摇晃，一旦发现松动，请立即重新紧固。
- 发现害虫时，请立即进行杀虫及防虫处理。若置之不理则可能导致虫害范围扩大。

木质部分的保养方法

- 涂装面的灰尘请用软布或掸子轻轻除去。若用硬布直接擦拭灰尘，则会造成留下细小伤痕的不良效果。一般使用软布干擦即可。
- 污垢严重时，请用浸透中性洗涤剂稀释液的布擦除污垢，再用清水浸湿的布将洗涤剂擦拭干净。然后用柔软的干布擦拭后使其自然风干。
- 请注意，长时间接触化学抹布可能会导致变色、表面剥落等现象。

使用注意事项

关于天然木材

- 本商品采用天然木材制作，木纹及色调等均具有天然木材特有的个体差异。因此，商品会在木纹及色调上存在差异，敬请谅解。
- 天然木材由于以下条件，可能会出现开裂或弯曲等，敬请注意。
 - ① 请尽量避免在阳光直射的场所使用。难以避开阳光直射时，请尽量使用窗帘等遮挡。
 - ② 请尽量避免在暖气设备附近使用。请务必不要在暖气设备风口处使用。
 - ③ 尤其是冬季的暖气会使室内极度干燥，因而可能导致天然木材发生开裂、弯曲。

关于甲醛对策

- 何谓甲醛
据说甲醛是导致病态建筑综合症的物质之一。是一种在常温下会气化的无色且具有刺激性气味的化学物质，除了家具以外，建筑材料、粘贴墙纸使用的粘合剂等中均含有这种物质。由于会逐渐扩散，所以如果长时间滞留于被甲醛污染的室内环境，将会刺激眼睛、导致咽喉产生不适的刺激感。如果浓度过高，还可能导致呼吸困难。
- 请对房间进行换气。



注意

设置家具后，请务必对室内进行充分换气。
否则可能导致化学物质过敏体质者及婴幼儿等出现过敏症状。

- 甲醛易在空气中扩散，故请在日常随时对室内进行充分换气。同时设置多款家具时，请尽量开大窗户，对室内进行充分换气。室内温度一旦升高，甲醛可能出现加速扩散的倾向，所以在夏季长时间门窗紧闭时，请务必确保充分换气。为了提高换气效率，建议同时打开多扇窗户，开启换气扇、电风扇、空气循环风扇等。
- 致化学物质过敏体质的用户
除甲醛以外，其他导致病态建筑综合症的化学物质在容许量上也均因人而异。因此，即使浓度在室内浓度标准值(不会影响健康的甲醛室内浓度值)以下，也会存在过敏反应体质的用户。我们在目前的无印良品家具上已尽力使用甲醛释放量较少的材料，但依然无法完全阻止扩散，故请多加注意。
一旦出现过敏症状，建议立即向医生咨询。
 - 无印良品的家具在封装出厂时均已放入甲醛吸附/分解纸(※)。
(※ 甲醛吸附/分解纸：与爱信精机株式会社共同开发)
甲醛在狭窄的空间内无处可逃，可能再次被材料吸附。因此，为了尽量降低送达顾客手中的商品所附甲醛浓度，我们在封包中放入了甲醛吸附/分解纸。
※ 封包中的“甲醛吸附/分解纸”在运输等过程中性能已下降，故请作为可燃垃圾处理。

产品规格

产品名称	白橡木扶手椅/圆脚
产品尺寸	长555×宽505×高730mm(座面高445mm)
产品重量	约5.6kg
用 途	椅子(1人用)
材 质	结构材料：天然木材(橡木) 表面加工：聚氨酯树脂涂装
执行标准	GB/T 3325-2008
原 产 国	日本

联系方式

有关商品的咨询，请联系购买的代理商。

无印良品(上海)商业有限公司
注册地址：上海市静安区南京西路1601号35楼
电话：021-6375-6677
www.muji.com.cn