

**ステンレスユニットシェルフ用  
高さ調整金具 (4個セット)**

**スチールユニットシェルフ用  
高さ調整金具・グレー (4個セット)**

**スチールユニットシェルフ用  
高さ調整金具・ライトグレー  
(4個セット)**

**組立・取扱説明書**

この度は本商品をお買い上げいただき、誠にありがとうございます。ご使用前に本書をよくお読みいただき、内容を理解した上で正しく組み立て、正しくお使いください。また、本書はいつでも確認できるように大切に保管してください。

2020年6月18日

**製品仕様**

品名	ステンレスユニットシェルフ用 高さ調整金具	
J A N	4548076580850	
製品寸法	幅 410×奥行 11×高さ 115 (mm)	
製品重量	約 0.4kg	
用途	ステンレスユニットシェルフ用追加パーツ	
材質	本体：金属（鋼） / ニッケルメッキ エポキシ樹脂粉末塗装	

Made in Taiwan

品名	スチールユニット シェルフ用高さ調整 金具・グレー	スチールユニット シェルフ用高さ調整 金具・ライトグレー
J A N	4548076580867	4550002998851
製品寸法	幅 410×奥行 11×高さ 115 (mm)	
製品重量	約 0.4kg	
用途	スチールユニットシェルフ用追加パーツ	
材質	本体：金属（鋼） / エポキシ樹脂粉末塗装	

Made in Taiwan

**ご使用方法**

**移動について**

●引越しなどで移動させる際などは、本体からはずしてから行ってください。

**廃棄について**

●廃棄の際は、居住地域自治体のルールに従い、処分してください。

**お手入れ方法**

**保守・点検**

●破損、変形した状態では使用しないでください。  
●ネジ、金具類は、ゆるみやグラツキがないか定期的に点検し、ゆるみははじめたら、しっかり締め直してください。ゆるんだままだと、ケガや本体の破損、床面のキズの原因となります。

**金属部のお手入れ**

●通常のお手入れはやわらかい布で乾き拭いてください。

**お手入れ方法 (つづき)**

●汚れがひどい時は、3~5%程度に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤をよくふき取ってください。次に乾いたやわらかい布で軽くふいた後で自然乾燥してください。

**お問い合わせ先**

商品のお問い合わせは、お買い上げの販売店、もしくは下記お客様室までご連絡ください。

**株式会社 良品計画**

〒170-8424  
東京都豊島区東池袋 4-26-3

お客様室でんわ  
**0120-14-6404**

**重要なお知らせ (安全上のご注意)**

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。



してはいけない「禁止」の内容です。



実行しなければならない内容です。

**警告 死亡や重傷などに結びつくおそれがあるもの**

●不要になった梱包材は、乳幼児の手の届くところに置かないでください。口や鼻をふさぐなどしたときに窒息するおそれがあります。  
●フィッティングパーツは小さな部品です。乳幼児の手の届くところに置かないでください。また、紛失しないでください。誤飲した場合、窒息などのおそれがあります。

●棚セット (※) もしくは追加用帆立 (単品) に付属の組立・取扱説明書をよく読み、正しくお使いください。組み立てた商品に対し、お使いになる上での注意が記載されており、ケガを防ぎ、安全にお使いいただく為に重要です。

※ステンレスユニットシェルフシリーズ、スチールユニットシェルフシリーズの帆立、棚板、クロスバーがセットになった商品。

**注意 傷害を負う可能性や物的損害が生じるおそれがあるもの**

●組み立てが不完全なまま使用しないでください。ケガの原因となるおそれがあります。  
●本来の用途以外では使用しないでください。思わぬ事故やケガの原因となります。  
●修理および改造はしないでください。製品の強度が弱くなりケガをするおそれがあります。

●引っ越しなどで部屋や階をまたぐような移動をする際は、組み立て前の状態に戻してから運んでください。パーツがはずれて、ケガや商品が破損する原因となります。

**お願い (その他 注意)**

●「追加棚・ステンレスワイヤー」・「追加棚・コーナータイプ」・「追加小棚・奥行12cm」には取り付けてできません。  
●1列に3セットまで高さ調整金具をご使用いただけます。(4セット以上は使用しないでください)  
●高さ調整金具を使用しない棚板も合わせてご使用ください。

**パーツリスト**

① 高さ調整金具・左 × 2	② 高さ調整金具・右 × 2	フィッティングパーツ
		③ 六角レンチ × 1 (M4用)
※左前と右後に使用します	※右前と左後に使用します	

**組立方法**

※この組立・取扱説明書は共通です。

※ユニットシェルフ全体の組み立て手順については、棚セットもしくは追加用帆立 (単品) に付属の組立・取扱説明書をよく読み正しく組み立ててください。


**1** 棚板の四隅に固定されているボルト、フックをそれぞれ②六角レンチで取りはずし、片側にだけ (背面側) ①と②の高さ調整金具を取り付けます。

**2** 背面の①②高さ調整金具・左/右のフックを、帆立の帆立柱に引っ掛け (ポイント①)、帆立柱の横桎まで落とし、しっかりと引っ掛けます。(ポイント②)

**4** ゆるめに取り付けていたすべてのボルトを、②六角レンチでしっかり締め付け、固定します。




**お願い (その他 注意)**

- 高さ調整金具は左右があります。
- ゆるめに取り付けておいてください。
- 取りはずしたフックは、無くさないよう大切に保管してください。



**お願い (その他 注意)**

- 一箇所をきつく絞めてしまうと、棚がゆがんで装着され、最後のフックが締めにくくなりますので、全体を調整しながら締めてください。
- 必要に応じたクロスバーをご使用ください。





**ポイント①** 引っ掛ける

**ポイント②** 横桎まで落とし引っ掛ける

**お願い (その他 注意)**

指をはさまないようにご注意ください。

**3** 棚板が外れないよう前側を支えます。前面に①②高さ調整金具・左/右フックを帆立柱と棚の間のすき間から入れて取り付けながら、フック部を先に帆立柱に引っ掛けてからボルトで固定します。(ポイント③) 手順**1**と同様に②六角レンチでボルトをゆるめに締めおきます。※木製棚の場合は、メネジを使用し、手順**1**同様に行います。



Retain for future reference

## STAINLESS UNIT SHELF / HEIGHT ADJUSTABLE BRACKET (SET OF 4)

## STEEL UNIT SHELF / HEIGHT ADJUSTABLE BRACKET / GREY (SET OF 4)

## STEEL UNIT SHELF / HEIGHT ADJUSTABLE BRACKET / LIGHT GREY (SET OF 4)

### User Guide

Thank you for your purchase. Read the User Guide before use to ensure correct use and assembly of this product. Please store this User Guide in an easily accessible place for future reference.

18 June 2020

## Specifications

Product Name	STAINLESS UNIT SHELF / HEIGHT ADJUSTABLE BRACKET
JAN	4548076580850
Product Dimensions	W410 × D11 × H115 (mm)
Product Weight	Approx. 0.4 kg
Usage	Optional parts for Stainless Unit Shelf
Material	Metal (Steel) / Nickel plating / Epoxy Resin Powder Coating

Made in Taiwan

Product Name	STEEL UNIT SHELF / HEIGHT ADJUSTABLE BRACKET / GREY	STEEL UNIT SHELF / HEIGHT ADJUSTABLE BRACKET / LIGHT GREY
JAN	4548076580867	4550002998851
Product Dimensions	W410 × D11 × H115 (mm)	
Product Weight	Approx. 0.4 kg	
Usage	Optional parts for Steel Unit Shelf	
Material	Metal (Steel) / Epoxy Resin Powder Coating	

Made in Taiwan

## Directions for Use

### Relocating the product

- Be sure to detach the product from the shelf before relocating it in situations such as moving house.

### Disposal

- To dispose of this product, follow the rules implemented by your local government.

## Care Instructions

### Maintenance and Inspection

- Do not use this product if it is damaged or deformed.
- Periodically check for any looseness in screws and metal parts, and re-tighten them if any looseness is found. Using the product with loose parts may result in injury, damage to the product or scratches to the floor.

### Maintenance for Metal Sections

- For usual care, wipe with a soft, dry cloth.

- If the product is particularly dirty, wipe clean with a cloth dampened with a 3% to 5% neutral detergent solution. Then wipe off any detergent residue with a damp cloth. Next, gently wipe with a soft, dry cloth and let the product dry naturally.

## Contact Information

For your inquiry about the product, please contact the store where you bought it.

## Important Information (Safety Advice)

The warnings and cautions indicated here are intended to prevent injury to the user or other people, or damage to their property. These instructions must be followed.

⊘ DON'Ts: Actions that are prohibited.

ⓘ DOs: Actions that must be taken.

### Warning Hazards that may lead to death or serious injury

- Do not keep unwanted packaging materials within reach of small children. It may cause suffocation if the mouth and nose are covered.
- Do not keep the small parts within reach of small children. And do not lose any of them. These parts are all small and they may cause suffocation if swallowed accidentally.
- Carefully read the User Guide provided with Shelf Set(\*) or Additional Frame (sold separately) to ensure correct use. It contains precautions for using the product, which are to prevent injury and to ensure your safety.

\* A set containing the frame, shelf boards and cross bars for the Stainless Unit Shelf series or Steel Unit Shelf series.




### Caution Hazards that may result in injury or damage to property

- Do not use unless fully assembled. Doing so may cause injury.
- Do not use for other than its intended purposes. Doing so may result in an unexpected accident or injury.
- Do not attempt to repair or modify. Doing so may reduce the strength of the product, resulting in injury.
- When relocating the shelf to a different room or floor for moving house, etc., disassemble the shelf before relocating it. Not doing so may result in parts detaching from the product, causing injury or damage to the product.

### Note (Other Cautions)

- The product cannot be used for Additional Stainless Wire Shelf, Additional Shelf / Corner Type and Additional Shelf / Narrow Type (D 12cm).
- Up to 3 sets of the height adjustment parts can be used per shelf. (Do not use more than 4 sets)
- There must be some shelf board(s) without any Height Adjustable Bracket on the same shelf, resulting in injury.

## Parts

<p>Ⓐ Height Adjustable Bracket / Left x2</p>  <p>* Use for front-left and back-right</p>	<p>Ⓑ Height Adjustable Bracket / Right x2</p>  <p>* Use for front-right and back-left</p>	<h3>Fitting Parts</h3> <p>Ⓐ Hexagonal Wrench x1 (For M4)</p> 
---	--	--

## Assembly Instructions

\* This User Guide is for both stainless / steel type.

\* For details on how to assemble the Unit Shelf, read the User Guide provided with Shelf Set or Additional Frame (sold separately).

**1** Take off all the bolts and hooks attached to the shelf board with ① hexagonal wrench. Then attach ② and ③ height adjustable brackets only on one side (back side).

- Note (Other Cautions)**
- Height adjustable brackets for left and right are different.
  - Attach the brackets loosely.
  - Store the hooks that have been taken off.

### Steel / Stainless shelf


**Point**

Tighten the bolts loosely

\*Use the bolts that are attached to the shelf board.

Only the height adjustable brackets for the back side have been attached.

Do not attach the ones for the front side yet.



### Wooden shelf

**Point**

Tighten the bolts loosely


\*Use the bolts and barrel nuts that are attached to the shelf board.

\*The side with barrel nuts is the bottom side.

Adjust the direction of the barrel nut.

Do not attach the ones for the front side yet.

Bottom side




### Make sure that the hooks are securely attached to the frame poles.

**Caution**

Not attached to the poles

Attached to the poles



**2** Attach the hooks of ④ height adjustable brackets left/right to the pole of the frame (Point ①), then drop the hooks so they sit on the rungs. (Point ②)


**Point ①** Hook

Be careful not to get your fingers caught.

Frame Pole

Hook

**Point ②** Drop the hooks so they sit on the rung



**4** Fully tighten all the bolts that have been loosely tightened to fix using ① hexagonal wrench.

- Note (Other Cautions)**
- If only one bolt is tightened all the way, it will be difficult to tighten the last hook as the shelf board is attached not straight. Tighten all the bolts at the same time while adjusting them.
  - Use Cross Bars if necessary.

**3** Hold the front side to prevent the shelf board from falling. Insert ④ height adjustable brackets / left/right, between the frame pole and the shelf board, on the front side. Attach the hooks to the poles, then fix them with the bolts. (Point ③) Loosely tighten the bolts with ① hexagonal wrench as same as the step 1.

\*For wooden shelf, follow the step 1 using barrel nuts.

**Point ③** Insert in between the pole and the shelf board first.

Hook Frame Pole

Hold with hand


Bolt

Steel / Stainless Steel Shelf Board

Wooden Shelf

Height Adjustable Bracket / left

Barrel Nut



## Attachment Precautions


### Location of Back Panel / Cross Bars

The bolts for back panel and cross bars cannot be attached to where there are height adjustable brackets.

\*Because the parts of the height adjustable bracket interfere with the attachment of bolts. Change the position of the back panel / cross bars.

<Example>

The bolts cannot be attached because they are interfering with the height adjustable brackets.




### Precaution for attaching Height Adjustable Bracket

Height adjustable bracket cannot be attached next to Unit Shelf Box, at the same height.

### Unit Shelf Box

Cannot be attached

Can be attached



\* The image is for illustration purposes.