

ソファベンチ・本体 SOFA BENCH

組立・取扱説明書 User Guide

日本語

この度は本製品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 11.

4550002850708 SOFA BENCH

ソファベンチ・本体

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で正しく組み立て、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2 ～ 3
パーツリスト	4
各部の名称	4
組立方法	5 ～ 7
ご使用方法	8
お手入れ方法	8
ご使用に際して	9
製品仕様	10
お問い合わせ先	10

重要なお知らせ（安全上のご注意）

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び、治療に入院、長期の通院を要するものをさします。

※2 傷害とは、治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。



警告



禁止

- 乳幼児を寝かさなideてください。床へ落下したり、窒息の原因となることがあります。
- 保護者の目の届かない場所で、お子さまだけで使用させないでください。思わぬケガの原因となります。
- 製品の上にのらないでください。バランスをくずして転倒したり、製品の破損によりケガをするおそれがあります。
- 座りながら製品を傾けたり、不安定な体勢で使用しないでください。転倒や破損、ケガをするおそれや、床をキズつける原因となります。
- 座面に浅く腰掛けしないでください。転倒や破損、ケガをするおそれがあります。
- 座面以外に座らないでください。思わぬケガの原因となります。
- 規定を超える人数では使用しないでください。破損してケガをするおそれがあります。（詳しくは製品仕様をご確認ください。）
- 製品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因となります。
- 不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。
- 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。
- フィッティングパーツは幼児の手の届くところには置かないでください。また、なくさないでください。これらは小さく、誤飲してしまうと窒息などのおそれがあります。





注意










禁止

- 高温多湿な場所に長期間設置しないでください。カビやダニなどが発生し、健康を害することがあります。



⚠ 注意	
 禁止	<ul style="list-style-type: none"> ●移動させる際は、製品を引きずらないでください。製品破損や床面へのキズ、ケガしたりするおそれがあります。 ●指定の用途以外で使用しないでください。破損してケガをするおそれがあります。 ●破損や変形した状態では使用しないでください。製品の強度が弱くなりケガをするおそれがあります。 ●修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。 ●フェルトを貼った後、凹凸や継ぎ目などの段差のある床面では使用しないでください。フェルトがはがれると、床面を汚したり、キズつけたりする原因となります。 ●12cmを超える長さの脚、また無印良品の木製脚／スチール脚（別売り）以外は取り付けしないでください。転倒や破損、ケガをするおそれがあります。
 行う	<ul style="list-style-type: none"> ●無印良品の木製脚／スチール脚（別売り）を取り付けてご使用ください。 ●平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になることがあります。 ●使い始める時は、室内の換気を十分にしてください。接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状をおこすおそれがあります。 ●使用時は、脚底面にフェルトなどの保護材を貼ったり、敷物を敷いたりしてご使用ください。床へのキズ防止、また、クッションフロアなどの場合は木部の塗料とクッションフロアの反応による変色を防いでくれます。 ●ボルトや脚（別売り）にゆるみやグラつきがないか定期的に点検し、ゆるんでいたらしっかり締め直してください。ケガや製品の破損、床面へのキズ防止になります。

お願い (その他 注意)	
	<ul style="list-style-type: none"> ●開封後の梱包材は、居住地域の自治体のルールに従い、処分してください。

パーツリスト

<p>①本体 × 1</p> 	<p>②背クッション × 1</p> 
<p>フィッティングパーツ</p>	
<p>③蝶ネジ × 5</p>  <p>※②に取り付けてあります。取りはずして使用します。</p>	<p>④ハンガーボルト × 5</p>  <p>※②に取り付けてあります。取りはずして使用します。 ※設置時はボルト保護用キャップをはずしてください。</p>
<p>⑤スプリングワッシャー × 5</p>  <p>※②に取り付けてあります。取りはずして使用します。</p>	<p>⑥ワッシャー × 5</p>  <p>※②に取り付けてあります。取りはずして使用します。</p> <p>⑦六角レンチ × 1</p>  <p>※メンテナンス用</p>

各部の名称

<p>例：カバー（別売り）装着時</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>(完成図)</p> </div> <div style="text-align: center;">  <p>※カバーと脚は別売りです。 それぞれ専用のものをご使用ください。</p> </div> </div>	
--	--

組立方法




注意

- ❶ 組み立ては、大人2人以上で行ってください。1人で作業すると、転倒や破損、ケガをしたり、床をキズつける原因となります。
- ❷ 組み立て時は、組み立てに必要なスペースを十分に確保し、敷物を敷いてください。床や既存の家具のキズ防止になります。


1

❷ 背クッションの❷に付いているボルト保護用キャップ、❶、❸、❹を取りはずします。



❶ ボルト保護用キャップをはずす。



❷ ❶、❸、❹を取りはずす。



❸ ❷ハンガーボルトは5cm外部に残るよう長さ調整してください。



注意

- ❶ ❷ハンガーボルトを手締めする際は、手袋などで手を保護してください。
- ❷ ❷ハンガーボルトは5 cm外部に残るように締めてください。5 cm以下だと❸で本体に取り付けられない場合があります。


取りはずしたパーツは手順❸で使用します。

2

❶ 本体の底面を上にして置き、木製脚／スチール脚（別売り）を取り付けます。
※イラストには「木製脚・12cm/ナチュラル(M8)」(別売り)を使用しています。

注意

- ❶ 12 cmを超える長さの脚、また、無印良品の脚（別売り）以外は取り付けないでください。転倒や破損、ケガをするおそれがあります。
- ❷ 取り付ける脚は、商品名に（M8）と記載されているものをご使用ください。2018年8月以前に販売されていた脚は、本製品に対応していませんのでご注意ください。




組立方法（つづき）

※カバー取り付け方法は、カバー（別売り）の取扱説明書をご参照ください。

③背クッションはカバー（別売り）を装着後、①本体に取り付けてください。
③取り付け後にカバー（別売り）は装着できません。


④ 本体に、⑤ 背クッションを、まず軽く取り付けます。

- ① ①本体を起こし、
- ② ②背クッションの②を本体のパイプ穴に差し込み、
- ③ ③1で取りはずしたa、c、dを使い、①本体に軽く取り付けます。



④本体に、⑤背クッションをしっかりと取り付けます。

- ① ⑧背クッションの底面が見えるよう、**4**を横向きに倒し、
- ② ②aをしっかりと締め付けてください（5ヶ所）。
- ③ ③A本体のボルト（10ヶ所）を確認し、ゆるんでいたら②eで締め付けてください。



❗ ④蝶ネジにゆるみがないか定期的に点検し、ゆるんでいたらしっかり締め直してください。


組立方法（つづき）

6

5 を起こして、完成です。

ご使用前に必ず取り付け部分にグラつきがないことを確認してください。

グラつきがある場合は、手順 4 まで戻り、取り付け部分を確認、締め直してください。



完成



注意

本体の起こし方（組み立て時）

⊘ 片方の脚に片寄る過度な荷重は加えないでください。部材の破損の原因となり、ケガをするおそれがあります。

下図のように、二人以上で床からやや持ち上げて起こしてください。



❗ 組み立て後、1 週間程度経過したら、蝶ネジを締め直してください。使い始めはゆるみやすく、ゆるんだまま使用すると本体破損により、ケガの原因となります。

ご使用方法

移動について

- 移動させる際は、大人2人以上で、必ず製品の下に両手を掛け、床面を引きずらないように持ち上げて運んでください。床や既存の家具のキズ防止になります。

廃棄について

- 廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お手入れ方法

保守・点検

- 破損や変形した状態では使用しないでください。
- 取り付け部分にゆるみやグラつきがないか定期的に点検し、ゆるんでいたらしっかり締め直してください。ケガや製品の破損、床面へのキズ防止になります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

金属部のお手入れ

- 通常のお手入れはやわらかい布で乾拭きしてください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。

生地のお手入れ

- 通常のお手入れは、やわらかい布で乾ぶきしてください。ほこりなどはブラシや掃除機（弱設定）などで取り除いてください。
- コーヒーなどひどい汚れの時は、ぬるま湯に3～5%に薄めた中性洗剤を入れた中にやわらかい布を浸し、よく絞って表面を叩くようにふき取ってください。その後、水に浸した布で洗剤をよくふき取り、自然乾燥してください。
- カバー（別売り）の洗濯方法については、カバーの品質表示ラベルに従い、正しくお取り扱いください。（インナーカバーは取りはずして洗濯することはできません。）

ご使用に際して

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

シックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

●お部屋の換気について



❗ 家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をするようにご注意ください。換気効率をあげるため複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

●化学物質に敏感な体質のお客様へ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましても、ホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。
アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

●ホルムアルデヒド吸着・分解シートについて

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、無印良品の家具には、ホルムアルデヒド吸着・分解シートを同梱しています。

※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

製品仕様

品 名	ソファベンチ・本体
J A N	4550002850708
製 品 寸 法	幅1800×奥行900×高さ485 mm 座面の高さ285 mm (脚を除く) ・脚 (別売り) を取り付けた時の高さ 「5 cmの脚」をつけた場合 高さ535 mm 座面の高さ335 mm 「10 cmの脚」をつけた場合 高さ585 mm 座面の高さ385 mm 「12 cmの脚」をつけた場合 高さ605 mm 座面の高さ405 mm
製 品 質 量	約 47 kg
用 途	ソファ (2～3人用)
材 質	構造部材 フレーム: 金属 (鋼)、合板 張り材: ポリエステル100% クッション材: ウレタンフォーム、鋼製ばね (コイルスプリング)、パームパッド
原 産 国	マレーシア

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

〒170-8424

東京都豊島区東池袋 4-26-3

お客様相談室でんわ



0120-14-6404

S1Y180608

SOFA BENCH

User Guide

Thank you for your purchase.
Read this User Guide before use to ensure correct assembly and use of the product.
Store this guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	12~13
Parts	14
Part Names	14
Assembly Instructions	15~17
Directions for Use	18
Care Instructions	18
General Notes	19
Specifications	20
Contact Information	20

Important Information (Safety Advice)



The instructions
must be followed.

This User Guide contains important information for safe use of the product in order to prevent harm to users and other individuals as well as damage to property.

Please note the following contents (indications and graphic symbols) before reading the main contents of this guide and follow the given instructions.

- Explanations of Indications

The extent of injury and damage that may arise when the product is used incorrectly is classified and explained with the following symbols.

 WARNING	Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury ^{*1} to the user.	 CAUTION	Indicates a hazard with a level of risk which, if not avoided, could result in injury ^{*2} to the user or property damage ^{*3} .
--	---	--	--

- Explanations of Graphic Symbols



Instructions are given in the form of the following graphic symbols. (Examples of graphic symbols are as follows.)




 Actions that are prohibited.	 Actions that must be taken.
--	---

*1 "Serious injury" indicates injuries, such as blindness, traumas, burns, bone fractures, poisoning, or electric shocks, that have long-term effects and require hospitalisation and/or long-term hospital visits for treatment.

*2 "Injury" indicates traumas or burns that do not require hospitalisation or long-term hospital visits for treatment.








*3 "Property damage" indicates extended damage that involves the house or household property.

 WARNING	
 DON'Ts	<ul style="list-style-type: none">• Do not lay small children on the product. Doing so may cause them to suffocate or fall on the floor.• Do not let children use without supervision. Doing so may result in unexpected injury.• Do not climb on the product. Doing so may cause tip-over from loss of balance or product damage and may lead to injury.• Do not use in an unstable position, such as tilting while sitting on the product. Otherwise this may cause tip-over, damage, injury and/or floor scratches.• Do not sit near the edge of the seat. Doing so may cause tip-over, damage and/or injury.• Do not sit on any part other than the seat. Doing so may result in unexpected injury.• Do not allow more than the specified number of people to use at the same time. Doing so may cause product damage and lead to injury. (See the Specifications for details.)• Do not place on the power cord of an electrical appliance. Doing so may damage the cord, leading to electric shock or a fire.• Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate.• Do not use outdoors. Doing so may cause deformation or severe degradation, leading to injury.• Do not keep the fitting parts within reach of small children and be careful not to lose them. Children may accidentally swallow small parts and choke.



 CAUTION	
 DON'Ts	<ul style="list-style-type: none"> • Do not install in locations with high temperatures and humidity for a long time. Doing so may cause mould and mites to grow, leading to health hazards. • Do not drag when moving the product. Doing so may cause product damage, floor scratches and/or injury. • Do not use for other than its intended purpose. Doing so may cause product damage and lead to injury. • Do not use if damaged or deformed. Doing so reduces the strength of the product and may lead to injury. • Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury. • Do not use the product on an uneven floor when felt pads are applied to it. Doing so may cause them to come off, leading to dirt or scratches on the floor surface. • Do not attach legs longer than 12 cm or anything other than MUJI's wooden/steel legs (sold separately). Otherwise this may cause tip-over, damage and/or injury.
 DOs	<ul style="list-style-type: none"> • Use the product with MUJI's wooden/steel legs (sold separately) attached. • Install on a flat and stable surface. Using on an unstable surface may cause product distortion or damage. • Ventilate the room well at the early stage of use. Formaldehyde contained in adhesive may still remain, and those with chemical sensitivity and small children may experience allergic reactions. • Apply felt pads or any protective materials to the bottom of the legs, or use an underlay. This is to protect the floor from scratches and discolouration due to reaction between the coating on the wooden parts and the floor when the product is installed on a cushioned vinyl flooring. • Regularly check for any looseness or wobbling in the bolts and legs (sold separately), and retighten them if any looseness is found. This is to prevent injury, product damage and floor scratches.

Note (Other Caution)	
	<ul style="list-style-type: none"> • To dispose of the packaging materials, follow the rules implemented by your local government.

Parts

<p>Ⓐ Main Unit × 1</p> 	<p>Ⓑ Back Cushion × 1</p> 	
<p>Fitting Parts</p>		
<p>Ⓐ Wingnut × 5</p>  <p>* Already attached to Ⓑ. Remove them before use.</p>	<p>Ⓑ Hanger Bolt × 5</p>  <p>* Already attached to Ⓑ. Remove them before use. * Remove the bolt protective caps before installing.</p>	
<p>Ⓒ Spring Washer × 5</p>  <p>* Already attached to Ⓑ. Remove them before use.</p>	<p>Ⓓ Washer × 5</p>  <p>* Already attached to Ⓑ. Remove them before use.</p>	<p>Ⓔ Hexagonal Wrench × 1</p>  <p>* For maintenance.</p>

Part Names

 <p>Seat</p> <p>Back Cushion</p> <p>Main Unit</p> <p>Legs (sold separately)</p>	<p>Example: When covers (sold separately) are attached</p>  <p>Covers (sold separately)</p> <p>* Covers and legs are sold separately. Use exclusive covers and legs.</p>
<p>(Completion Image)</p>	

Assembly Instructions




- ❗ The product must be assembled by at least two adults. Assembling alone may cause injury, tip-over, damage and/or floor scratches.
- ❗ Secure enough space and place an underlay when assembling the product. This prevents the floor and other furniture from scratches.


1

Remove the bolt protective caps which are attached to (b) of (B) back cushion and (a), (c) and (d).



① Remove the bolt protective caps.



② Remove (a), (c) and (d).



③ Tighten (b) hanger bolts so that they remain 5 cm outside.



Removed parts will be used in Step 4.

CAUTION


- ❗ Wear gloves when tightening (b) hanger bolts to protect your hands.
- ❗ Tighten (b) hanger bolts so that they remain 5 cm outside. If it is less than 5 cm, it may not be possible to attach to the main unit in 4.

2

Place (A) main unit with the reverse side facing up and attach wooden/steel legs (sold separately).
* Wooden leg / 12 cm / Natural (M8) (sold separately) is used in the illustration.

CAUTION


- ⊘ Do not attach legs longer than 12 cm or anything other than MUJI's legs (sold separately). Doing so may cause tip-over, damage and/or injury.
- ❗ Use legs with (M8) included in the product name. Note that legs sold prior to August 2018 are not compatible with this product.




* Refer to the User Guide provided with the cover (sold separately) to attach.

Attach the cover (sold separately) to ❷ back cushion first, then attach it to ❶ main unit.
Be aware that the cover (sold separately) can not be attached after attaching ❷ to the main unit.

- ① Raise ① main unit.
- ② Insert ② of ② back cushion into the holes of main unit.
- ③ Use ③, ④, and ⑤ that were removed in **1** and lightly attach back cushion to ① main unit.



- ① Turn **4** over sideways so that the bottom surface of **Ⓑ** back cushion can be seen.
- ② Tighten **Ⓐ** (× 5) firmly.
- ③ Check the bolts (× 10) on **Ⓐ** main unit and tighten them with **Ⓔ** if they are loose.



❗ Regularly check for any looseness in (a) wingnut and retighten them if looseness is found.


Assembly Instructions (Continued)

6

Stand **5** upright to complete.

Make sure to check for any wobbling at the attached part before use.

If any wobbling is found, go back to Step **4** and check the attached part, retighten the fitting parts.



Completed





CAUTION

How to Stand the Main Unit Upright (During Assembly)

⊘ Do not put excessive load only on one side of the leg. Doing so may damage the parts and lead to injury.

When standing the main unit upright, lift by two or more people as shown in the illustrations below.



⚠ Retighten the wingnut after about one week of assembly. It may become loose at the beginning of use, and continued use with this state may cause damage to the product, resulting in injury.

Directions for Use

Relocating the Product

- When moving the assembled product, do not drag it on the floor. It must be lifted and carried by at least two adults holding the underneath of the product with both hands. This prevents the floor and other furniture from scratches.

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Care Instructions

Maintenance and Inspection

- Do not use if damaged or deformed.
- Regularly check for any looseness or wobbling in the attached part and retighten them if any looseness is found. This is to prevent injury, product damage and floor scratches.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Maintenance for Metal Parts

- For regular maintenance, wipe with a soft, dry cloth.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.

Maintenance for Fabric Parts

- For regular cleaning, wipe with a soft, dry cloth. Remove dust with a brush or a vacuum cleaner (at low setting).
- If the product is heavily soiled (with coffee stains, etc.), soak a soft cloth in warm 3–5% neutral detergent solution, wring it out thoroughly and pat the stained surface with the cloth to remove the stains. Then, wipe off any detergent residue with a damp cloth and let the product dry naturally.
- When washing the cover (sold separately), follow the care label on the cover and handle it properly.
(The inner cover cannot be taken off for washing.)


General Notes

Formaldehyde Countermeasures

- What is Formaldehyde?

Formaldehyde is said to be a cause of sick house syndrome. It is a colourless, pungent-smelling chemical that vaporises at room temperature, often found in furniture, building materials, wallpaper adhesives, etc. As it is gradually released into the air, spending a long time in a room contaminated with formaldehyde can result in eye/throat irritation. Also, exposure to a high concentration of formaldehyde may cause breathing difficulties.

- Room Ventilation

 CAUTION	! Ventilate the room well when installing the furniture. Some individuals sensitive to chemicals and small children may experience allergic symptoms.
---	--

Be sure to frequently ventilate the room on a regular basis as formaldehyde is released into the air. Especially when installing multiple pieces of furniture at the same time, open the windows wide enough to allow adequate ventilation. Formaldehyde release tends to increase with temperature rise of the room. Therefore, be sure to ventilate well after the room has been closed up for a long time during summer. It is recommended that you open multiple windows and use a ventilation fan or an air circulator to increase ventilation efficiency.

- For Individuals Sensitive to Chemicals

There are individual differences in resistance to chemicals that are related to sick house syndrome other than formaldehyde. Therefore, even if the actual concentration in the room is lower than the indoor concentration guideline value (acceptable safe level of formaldehyde indoors), some people may react to formaldehyde. MUJI furniture are made with materials that contain as little formaldehyde as possible, but note this does not guarantee that they are completely formaldehyde-free. It is recommended that you seek medical attention if you experience any allergic symptoms.

- Formaldehyde Adsorption/Decomposition Sheet

Formaldehyde is readsorbed onto materials when there is nowhere for it to dissipate in a confined space. Therefore, a formaldehyde adsorption/decomposition sheet is included in the packaging to reduce formaldehyde concentration as much as possible before the product reaches the customer.

* The effect of the sheet will be diminished by the time the product reaches the customer. Dispose of the sheet as burnable waste after unpackaging.

Specifications

Product Name	SOFA BENCH
JAN	4550002850708
Product Dimension	W1800 × D900 × H485 mm Seat Height: 285 mm (excluding legs) * Height when legs (sold separately) are attached When "5 cm legs" are attached: Height: 535 mm Seat Height: 335 mm When "10 cm legs" are attached: Height: 585 mm Seat Height: 385 mm When "12 cm legs" are attached: Height: 605 mm Seat Height: 405 mm
Product Weight	Approx. 47 kg
Usage	Sofa (for 2 or 3 people)
Material	Structural Element Frame : Metal (Steel) / Plywood Upholstery Material : 100% Polyester Cushion : Urethane Foam, Steel Spring (coil spring), Coco Fibre
Place of Origin	MALAYSIA

Contact Information

For enquiries regarding the product, please contact the store of purchase.