

ソファ本体・2.5シーター・フェザー・ポケットコイル・ハイバックタイプ
SOFA / HIGH BACK TYPE / FEATHER / POCKET COIL / 2.5S
沙发主体/2.5人座/羽毛/独立式樽型弹簧/高靠背型

組立・取扱説明書

User Guide

组装 / 使用说明书

日本語

この度は本商品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 9.

中文

本次承蒙惠购本产品，在此深表感谢。
请从第十七页开始阅读。

ソファ本体・2.5シーター・フェザー・ポケットコイル・ハイバックタイプ

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2～3
パーツリスト	4
各部の名称	4
組立方法	5
お手入れ方法	6
ご使用に際して	7
製品仕様	8
お問い合わせ先	8

重要なお知らせ（安全上のご注意）

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び治療に入院、長期の通院を要するものをさします。

※2 傷害とは治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。

⚠ 組み立ての際のご注意

⚠ 警告



禁止

- 不要になった包装資材はすぐに処分するなど、お子さまの手の届く所に置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。

⚠ 注意



行う

- 重量がありますので、組み立ては必ず2人以上で行ってください。重いものや長いものなど無理やり持ち上げたり、無理な態勢で取り付けると商品破損やケガの原因となります。
- 組み立て中にパーツなどの不足、不備があった場合は、組み立てを中止してください。固定部分がはずれて、ケガの原因になります。

お願い（その他 注意）

- 組み立てに十分な場所を確保し、敷物などを敷いて床や既存の家具にキズがつかないように、注意して行ってください。

⚠ 設置環境についてのご注意

⚠ 警告



禁止

- ストーブなど引火するおそれのあるものを近くに置かないでください。火災の原因となります。
- 商品の脚などで電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因になることがあります。

⚠ 注意



禁止

- 多湿な場所（目安：湿度70%以上でかつ室温20℃以上）で長期間設置はしないでください。カビやダニなどが発生し、健康を害することがあります。
- 壁から少し離して設置してください。（目安：10cm程度）。風通しが悪くて空気が滞留したり、壁側の結露や外気の影響でカビが発生しやすくなり、健康を害することがあります。また、壁に直接触れていると、壁紙が変色するおそれがあります。

重要なお知らせ (安全上のご注意)

必ずお守りください。(つづき)

⚠ 設置環境についてのご注意 (つづき)

お願い (その他 注意)

- 直射日光や照明、ストーブやエアコンなどの熱や風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になります。
- 商品を長時間同じ場所に設置し使用されますと床と、脚の設置面が凹んだりして床をいためる場合があります。必ずカーペットなど敷物の上にソファを設置するか、ソファの脚にフェルトなどを貼って使用してください。木部の塗料と床面との化学反応による汚れ防止になります。
- 平らで安定した場所に設置してください。不安定な場所での使用は、製品がゆがんだり、破損の原因になることがあります。

⚠ 使用上のご注意

⚠ 警告



禁止

- 乳幼児を寝かさないでください。床への落下や窒息の原因になることがあります。
- 保護者の目の届かないところで、お子さまだけでは使用させないでください。
- クッションを強くたたいたり、折り曲げたりしないでください。羽毛や側生地をいためて、羽毛の飛び出しの原因となり、ケガをするおそれがあります。
- タバコの火などを商品に落とさないでください。火事の原因となります。
- 座る以外には使わないでください。思わぬケガの原因になることがあります。
- 座った状態でソファを傾けるなど、不安定な状態では使用しないでください。転倒や商品の破損により、思わぬケガをする原因となります。
- 商品の上に立ったり、飛びはねたり、踏み台代わりに使用したりしないでください。バランスを崩し転倒したり、商品の破損によりケガの原因になることがあります。
- 破損・変形したソファは使用しないでください。思わぬケガをするおそれがあります。
- 修理や改造はしないでください。製品の強度が弱くなり、ケガをする原因となります。
- 座面に浅く腰掛けしないでください。転倒してケガをする原因となります。
- アームや背もたれには座らないでください。思わぬケガの原因となります。

⚠ 注意



禁止

- 製品の周辺、または上部に物を置かないでください。落下しケガの原因になることがあります。
- 移動する際は、大人2人以上で移動させてください。
1人で無理に移動させるとケガや商品の破損、また床をキズつける原因となります。
- 12cmを超える長さの脚、また、無印良品の木製脚/スチール脚 (別売り) 以外は取り付けしないでください。転倒や破損、ケガをするおそれがあります。



行う

- 万が一、羽毛の硬い部分が飛び出している場合は、羽毛を取り除いてください。そのまま使用すると、飛び出した羽毛でケガをすることがあります。
- 使い始めるときは、室内の換気を十分にしてください。
木材の接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。
- 木製脚/スチール脚 (別売り) を取り付けでご使用ください。


お願い (その他 注意)

- シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。変色や変形の原因となります。
- 化学雑巾を長時間接触させたままにしないでください。
変色したり、表面がはがれたりすることがあります。
- フェルトを貼った状態では凹凸や継ぎ目などの段差のある床面では使用しないでください。
フェルトがはがれて、床面を汚したり、キズつけたりする原因となります。

パーツリスト

(A) 本体×1	(B) ヘッドサポート×2	(C) 背クッション×2	(D) 座クッション×2
背もたれ		タグ	タグ
		タグ表示	タグ表示
		GB3R/GB3L/YB2.5	YZ2.5

各部の名称



※別売りのカバーを必ず装着してご使用ください。

※カバー装着方法は、別売りのカバー付属の説明書をご確認ください。

※脚は別売りです。無印良品の木製脚/スチール脚をご使用ください。

組立方法


お願い
(その他 注意)

組み立ての前に必ずお読みください。

- 組み立てに十分な場所を確保し、敷物などを敷いて床や既存の家具にキズが付かないように、注意してください。
- 組み立ては必ず2人以上で行ってください。

1

- ① (A) 本体を下図のように立ててください。
- ② (A) 本体側の脚取り付け穴に脚 (別売り) のボルトを入れ、矢印方向に回し、最後までしっかり締めつけてください。
- ③ (A) 本体を起こしてください。




2



カバー (別売り) を付属の取扱説明書に従って、装着してください。

3

- ① (D) 座クッションを下図のように、側生地ファスナーが付いている方を下面、タグが付いている方を後ろ上面にし、設置してください。
- ② (C) 背クッションと (B) ヘッドサポートは、下図のようにフレームを (D) 座クッションの後ろに差し込むように設置してください。



- ③ 背クッションはファスナータグが付いている方向を下面にしカバーを装着してください。



注意

- 起こす際に脚の片側に過度の荷重がかからないようにご注意ください。破損、床のキズなどの原因になります。移動するときは2人以上で持ち上げて移動してください。
- 各パーツがしっかり固定されているか必ず確認してください。
- ご使用後、一週間程経過しましたら脚の取り付けボルトをしっかり締め直してください。ゆるんだまま使用すると、ソファが破損し、ケガをするおそれがあります。



お手入れ方法

汚れについて

【本体の側生地のお手入れ】

- 通常のお手入れはやわらかい布で乾ぶきしてください。ほこりなどはブラシや掃除機（弱設定）などを使って取り除いてください。
- コーヒーなどの汚れがひどいときは、ぬるま湯を使って3～5%程度に薄めた中性洗剤にやわらかい布を浸し、よく絞って表面をたたくようにふき取ってください。その後、水を浸した布で洗剤をよくふき取り、自然乾燥してください。

【クッションの側生地のお手入れ】

- 部分的に側生地が汚れた場合は、中性洗剤でつまみ洗いをしてください。その後は、風通しの良い場所で陰干しし、中の羽毛をほぐしてください。湿気が残っている場合には、臭いの原因になりますので充分乾燥させてください。

【カバーのお手入れ】

- カバー（別売り）の洗濯方法については、カバーの品質表示ラベルに従い、正しくお取り扱いください。

クッションについて

【クッションのお手入れ】

- クッションの中身は、隅に片寄る性質があります。型崩れ防止のためにも、定期的にクッションをもみほぐし、中に空気を入れて形を整えるようにしてください。
- お使いいただくうちにクッション材が動いて移動して形状が型くずれします。クッションをかるく横からたたいたり、揉みほぐすなどして形を整えてください。クッションの中に十分な空気はいるようにすると、よりきれいに仕上がります。



クッションは強くたたいたり、無理に折り曲げたりしないでください。
羽毛や側生地をいため、羽毛の飛び出しの原因となり、ケガをするおそれがあります。

- 側生地の縫い目が一部ほつれたり、小さな穴が開いた場合には、裏側に接着剤の付いた市販の補修布をご使用ください。
- 陰干しなどした後は、表面を軽く手で払いホコリを取り除くようにしてください。強く“たたく”行為は、羽毛や側生地をいため、羽毛飛び出しの原因になるおそれがありますので、軽くたたくようにしてください。

【羽毛の飛び出しについて】

クッションには詰め物の羽毛が外に出てこないように高密度に織られた側生地を使用し、ダウンプルーフ加工を施していますが、縫い目などからまれに羽軸の硬い部分が生地からでてくる事があります。羽軸の硬い部分が飛び出している場合は、飛び出した羽毛を取り除いてご使用ください。

【羽毛の臭いについて】

ご購入直後や湿気の多い梅雨時には、羽毛の臭いがすることがあります。臭いが気になる場合は、クッションの中の臭気（空気）を押し出し、新しい空気と入換えて、3～4時間、風通しの良いところに干してください。

ご使用に際して

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

ホルムアルデヒドは、シックハウス症候群の原因物質の一つといわれています。常温で気化する無色で刺激臭のある化学物質で、家具はもとより建築資材、壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

●お部屋の換気をしてください。



家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。複数の家具を同時に設置した場合は特に窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は特に換気をするようご注意ください。換気効率を上げるため、複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

●化学物質に敏感な体質のお客様へ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質は許容量に個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましてもホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。アレルギー症状が起きた際は、医師にご相談される事をおすすめします。

●無印良品の家具は梱包内にホルムアルデヒド吸着・分解シートを入れて出荷しています。

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お客様のお手元に届くまでに少しでもホルムアルデヒド濃度を低下させるために、ホルムアルデヒド吸着・分解シートを入れてあります。

同梱の「ホルムアルデヒド吸着・分解シート」は、効力が落ちておりますので、燃えるゴミとして処分してください。

保守点検

●脚にゆるみやグラつきがないか定期的に点検し、ゆるみはじめたらしっかり締めなおしてください。

ケガや破損、床面へのキズの防止となります。

●クッションの縫い目などから羽毛の羽軸が飛び出している場合は、取り除いてご使用ください。

●害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

移動について



1人では移動を行わないでください。ケガや破損、床面へのキズの原因になります。

●移動させる際は、クッションなど取りはずしできるものははずして運んでください。

必ず座部の下に両手をかけて、大人2人以上で、床面をひきずらないように持ち上げて運んでください。

廃棄について

●廃棄の際は、居住地域の自治体のルールに従い、処分してください。

製品仕様

品 名	ソファ本体・2.5シーター・フェザー・ポケットコイル・ハイバックタイプ		
製品寸法	幅	1930mm	
	奥行	905mm	
	高さ	835mm（脚を除く）※	
	座面の高さ	330mm（脚を除く）※	
	※木製脚/スチール脚（別売り）を取り付けたときの高さ 「5cmの脚」をつけた場合 高さ885mm 座面の高さ380mm 「10cmの脚」をつけた場合 高さ935mm 座面の高さ430mm 「12cmの脚」をつけた場合 高さ955mm 座面の高さ450mm		
製品重量	約59Kg		
用 途	ソファ・2人用		
材 質	構造部材	本 体	金属（鋼）、合板 プラスチックボード（ポリプロピレン）
		ヘッドサポート	金属（鋼）
	表面加工	ヘッドサポート	エポキシポリエステル樹脂粉体塗装
	張り材	本 体	ポリエステル
		クッション	ポリエステル、綿
		ヘッドサポート	ポリエステル、綿
	クッション材	本 体	ウレタンフォーム 鋼製ばね（Sばね） スチールワイヤー
		背クッション	フェザー ウレタンフォーム
		座クッション	フェザー ウレタンフォーム 鋼製ばね（コイルスプリング）
		ヘッドサポート	フェザー ウレタンフォーム
原 産 国	中国		

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様室までご連絡ください。

株式会社 良品計画

〒170-8424

東京都豊島区東池袋 4-26-3

お客様室でんわ



0120-14-6404

SOFA / HIGH BACK TYPE / FEATHER / POCKET COIL / 2.5S

User Guide

Thank you for your purchase.

Please read this User Guide before use to ensure correct use and assembly of the product.

Please store this guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	10 - 11
Parts	12
Part Names	12
Assembly Instructions	13
Care Instructions	14
Usage	15
Specifications	16
Contact Information	16

Important Information (Safety Advice)

These instructions must be followed.

This User Guide contains important information for safe use in order to prevent harm to the user and others as well as damage to property.

Please note the following contents (indications and graphic symbols) before reading the main contents of User Guide, and follow the instructions given.

- **Explanations on Indications**

The degrees of injury and damage that may arise when the product is used incorrectly are classified and explained with the following symbols.



Warning

Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury*¹ to the user.



Caution

Indicates a hazard with a level of risk which, if not avoided, could result in injury*² to the user or property damage*³.

- **Explanations on Graphic Symbols**

Instructions are given in the forms of the following graphic symbols. (Examples of graphic symbols are as follows.)



DON'Ts: Actions that are prohibited.



DOs: Actions that must be taken.

*1 "Serious injury" indicates blindness, injuries, burns, bone fractures, poisoning, or electric shocks which have long term effects and require hospitalisation and/or long-term hospital visits for treatment.

*2 "Injury" indicates injuries or burns which do not require hospitalisation or long-term hospital visits for treatment.

*3 "Property damage" indicates expanded damage involving house and household property.

Assembly Precautions

Warning



DON'Ts

- Do not leave unnecessary packing materials within reach of small children and discard them as soon as possible. Small children may accidentally pull them over the head and cover the mouth or nose, causing suffocation.

Caution



DOs

- Assemble the product with two or more people since the product is heavy. Forcibly lifting a heavy object or a long object or installing such objects in an inappropriate posture may cause product damage and/or injury.
- In case any parts are missing or broken while in assembly, stop the assembly process. Fixed parts may become detached, resulting injury.

Note (Other Cautions)

- Secure enough space for assembling and use a protective underlay to prevent scratches on the floor and other furniture when assembling and installing the product.

Installation Environment Precautions

Warning



DON'Ts

- Do not place the product near any inflammable objects, such as a heater. Doing so may cause fire.
- Do not place a leg of the product on the power cord of an electrical appliance. Doing so may damage the cord, resulting in electric shock or fire.

Caution



DON'Ts

- Do not install the product in a room with high humidity (approx. humidity of 70% or higher and room temperature of 20°C or higher) for a long time. Doing so may cause infestation of mould and mites, causing health hazards.
- Do not install too close to the wall (leave a space of about 10 cm). Doing so may cause mould growth due to air stagnation from poor ventilation or condensation on the wall and outdoor influences, resulting in health hazards. Placing the product directly in contact with the wall may cause discolouration of the wall paper.

Important Information (Safety Advice)

These instructions must be followed. (Continued)

Installation Environment Precautions (Continued)

Note (Other Cautions)

- Do not expose the product to direct sunlight, lighting, or heated air from appliances such as a heater or air conditioner. Doing so may cause warping, deformation, cracks, or discolouration.
- Do not use the product at a same location for a long time. Doing so may damage the floor, as the floor gets dented by the sofa legs. Be sure to place a carpet or rug under the sofa or attach the felt pads at the bottom of the sofa legs. It prevents stains from reactions between coating on the wooden parts and floor surface.
- Use in a flat and stable place. Using the sofa on an unstable floor may cause deformation or breakage of the product.

Usage Precautions

Warning


DON'Ts

- Do not lay small children on the product. Doing so may cause the child to fall to the floor or suffocate.
- Do not let children use the product alone without supervision of a parent or other adult.
- Do not beat or bend the feather cushion. Doing so may damage the feathers or the outer shell, and cause the feathers to protrude, resulting in injury.
- Do not drop lit cigarettes, etc. onto the product. Doing so may cause fire.
- Do not use the product other than for its intended use. Doing so may cause unexpected injury.
- Do not use the sofa in unstable conditions such as inclining the sofa while sitting on it. Doing so may cause the product to fall over or get damaged, resulting in unexpected injury.
- Do not stand or jump on the sofa or use it as a stepladder. Doing so may cause the user to lose balance and fall, or the product to get damaged resulting in injury.
- Do not use a damaged or deformed sofa. Doing so may cause unexpected injury.
- Do not repair or modify the sofa. Doing so may weaken the product, resulting in injury.
- Do not sit on the front edge of the product. Doing so may cause the product to tip over, resulting in an injury.
- Do not sit on the arm or the backrest. Doing so may cause unexpected injury.

Caution


DON'Ts

- Do not place an object around or on the sofa. Doing so may cause the object to fall, resulting in injury.
- Do not move the product with less than two people.
Moving the sofa by only one person may cause injury, product damage, or scratches on the floor.
- Do not attach legs longer than 12 cm or those manufactured by other retailers. Doing so may result in injury due to falling or damage to the product.






DOs

- In case the feather quills are protruding from the sofa, remove them. Not doing so may cause injury.
- Ventilate the room well at the early stage of product use.
Formaldehyde contained in the adhesive for wooden parts may still remain, and persons who have high sensitivity to chemicals and small children may experience allergy reaction.
- Make sure to attach legs (sold separately) when using this product.


Note (Other Cautions)

- Do not use organic solvent such as thinner or bleach for maintenance.
Doing so may cause discolouration or deformation.
- Do not leave chemical wipe in contact for a long time.
Doing so may cause discolouration and/or peeling of the surface.
- Do not use the product on an uneven floor with the felt pads attached to the product.
Doing so may cause the felt pads to come off, resulting in stains or scratches on the floor.

Parts

Ⓐ Main Unit × 1	Ⓑ Head Support × 2	Ⓒ Back Cushion × 2	Ⓓ Seat Cushion × 2
			
		Code on Tag GB3R/GB3L/YB2.5	Code on Tag YZ2.5

Part Names



- * Be sure to use with the cover sold separately.
- * For instructions on how to attach the cover, refer to the user guide enclosed with the cover sold separately.
- * Legs are sold separately. Use dedicated ones.

Assembly Instructions


Note (Other Cautions)

Read these instructions carefully before assembling the product.

- Secure enough space and use a protective underlay to prevent scratches on the floor and other furniture when assembling and installing the product.
- Be sure to assemble the product with two or more people.

1

- ① Place (A) main unit as shown in the illustration below.
- ② Screw the bolt for legs (sold separately) into the leg attachment holes on (A) main unit.
Turn the legs in the arrow direction. Fully tighten the legs.
- ③ Bring (A) main unit to the normal position.




2



- Put the cover (sold separately) by referring to the supplied user guide.

3

- ① Place (D) seat cushions so that their fastener sides are facing down and the sides with a tag are facing up and back as shown in the illustration below.
- ② Place (C) back cushions and (B) head supports by inserting the frame behind the back of (D) seat cushions.



Put the covers on (C) back cushions so that their fastener sides with a tag are facing down.



* The frame of (B) head support is designed not to reach the bottom of (A) main unit.

Caution

- When raising the sofa, be sure not to apply too much load on one side of the legs. Otherwise, sofa may get damaged or the floor may get scratched. When moving the sofa, lift it with two or more people.
- Make sure all parts are firmly fixed.
- Retighten the leg attachment bolts approximately one week after start of use. Continued use with loose bolts may cause damage to the sofa, resulting in injury.



Care Instructions

Dirt and Stain

[Care instructions for the outer shell of the main unit]

- For daily care, wipe them with a soft and dry cloth. Remove the dust using a brush or a vacuum cleaner (low setting).
- When the sofa is heavily stained by coffee or other substances, remove the stain with a soft cloth soaked in the warm and diluted 3% to 5% neutral detergent. Soak and squeeze the cloth tightly, and wipe the surface by tapping. Then, wipe off the residual detergent with a cloth soaked into water and dry naturally.

[Care instructions for the outer shell of cushion]

- If the outer shell is partially stained, spot-treat the stain with neutral detergent. Then, hang it out in a well-ventilated shade to spread out the feathers. Be sure to fully dry the product, as moisture may cause odour.


[Care instructions for the cover]

- When washing the cover (sold separately), follow the quality label on the cover and handle properly.

Cushion

[Care instructions for the cushion]

- The stuffing inside the cushion tends to move to corners. In order to prevent the cushion from losing its shape, periodically knead the cushion, and let air in to fix up the shape.
- The stuffing inside will move and the cushion shape will deform gradually with continued use. Lightly tap the cushion from the side and/or knead it to fix up the shape. The shape can be finished better by letting enough air inside the cushion.



Warning

Do not beat or bend the feather cushion. Doing so may damage the feathers or the outer shell, and cause the feathers to protrude, resulting in injury.

- When stitching is partially frayed or a hole is opening on the outer shell, use a commercially available mending patch with adhesive applied on the rear side.
- After drying the cushion in the shade, lightly tap its surface to remove the dust. Be sure to tap lightly. Pounding the cushion strongly may cause damage on the feather or the outer shell and protrusion of the feather quill.

[Protrusion of the feather quill]

In order to prevent the feather stuffed inside from coming out, densely woven outer shell is used and treated with the down-proof process. However, hard part of feather quills sometimes protrudes from the fabric seams. In such case, remove the feather.

[Odour of feather]

The feather may have a specific odour immediately after purchase and during wet season with high humidity. If this bothers you, press out the air from the cushion, allow to fill with new air, and hang in a well-ventilated place for 3 to 4 hours.

Usage

Formaldehyde Countermeasures

- What is formaldehyde?

Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent-smelling compound that vaporizes at room temperature, and is found in items such as furniture, building materials, and wallpaper adhesives. It is released gradually, and people in a room where formaldehyde has accumulated for a long time may experience symptoms such as eye irritations or a sore throat. A high concentration of formaldehyde may cause breathing difficulties.

- Ventilate the room.

**Caution**

Ventilate the room well when installing the furniture.

Those who are sensitive to chemicals and small children may experience allergic reactions.

Since formaldehyde is easily dispersed in the air, periodically ventilate the room.

When several pieces of furniture are installed at the same time, open the windows widely for sufficient ventilation. More formaldehyde is released when the room temperature increases. Therefore, be careful if the room is closed for a long time during the summer, and ventilate the room thoroughly. In order to increase ventilation efficiency, opening multiple windows, or using a ventilation fan or air circulator is recommended.

- For Persons Who Have High Sensitivity to Chemicals

There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even though the actual value in the room is lower than the indoor concentration guideline value (indoor concentration of formaldehyde that is tolerable for health), some people react to formaldehyde. At present, MUJI furniture products are made with materials that emit as little formaldehyde as possible, but this does not guarantee that no formaldehyde is emitted at all. We recommend consulting a physician if you experience any allergic symptoms.

- MUJI furniture products contain formaldehyde absorption/decomposition sheets as part of the packing materials.

When used in confined spaces, formaldehyde may be reabsorbed by the material if there is nowhere for it to dissipate. Formaldehyde absorption/decomposition sheets are used to reduce the concentration of formaldehyde as much as possible before the product reaches the customer.

Effectiveness of the "formaldehyde absorption/decomposition sheet" in the packaging has been expended by the time the package reaches the customer. Dispose of the sheet as burnable waste after unpacking.

Maintenance and Inspection

- Periodically check the legs for loosening or wobbling and securely retighten them if any looseness is found. This procedure can prevent injury, damage, or scratch on the floor.
- If a feather quill is protruding from the seam of the cushion, remove it.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Moving the product

**Caution**

Do not attempt to move the product alone. Doing so may cause injury, damage to the product, or scratches to the floor.

- When moving the sofa, remove all removable items such as cushions before start moving.

Lift up and move with two or more adults by holding underneath the main unit with both hands without dragging on the floor surface.

Disposal

To dispose of this product, follow the rules implemented by your local government.

Specifications

Product Name	SOFA / HIGH BACK TYPE / FEATHER / POCKET COIL / 2.5S		
Product Dimensions	Width	:	1930 mm
	Depth	:	905 mm
	Height	:	835 mm (excluding legs)*
	Seat Height	:	330 mm (excluding legs)*
	* Height when legs (sold separately) are attached When "5 cm legs" are attached: Height 885 mm Seat Height 380 mm When "10 cm legs" are attached: Height 935 mm Seat Height 430 mm When "12 cm legs" are attached: Height 955 mm Seat Height 450 mm		
Product Weight	Approx. 59 kg		
Usage	Sofa for 2 persons		
Materials	Structural Materials	Main Unit	: Metal (Steel) / Plywood Plastic Board (Polypropylene)
		Head Support	: Metal (Steel)
	Surface Finish	Head Support	: Epoxy Polyester Resin Powder Coating
	Covering Materials	Main Unit	: Polyester
		Cushion	: Polyester / Cotton
		Head Support	: Polyester / Cotton
	Cushioning Materials	Main Unit	: Urethane Foam Steel Springs (S-shaped Springs) Steel Wire
		Back Cushion	: Feather Urethane Foam
		Seat Cushion	: Feather Urethane Foam Steel Springs (Coil Springs)
		Head Support	: Feather Urethane Foam
Country of origin	China		

Contact Information

For your inquiry about the product, please contact the store where you purchased it.

沙发主体/2.5人座/羽毛/独立式樽型弹簧/高靠背型

组装/使用说明书

本次承蒙惠购本产品，在此深表感谢。

使用前请务必仔细阅读本文，并在对内容充分理解的基础上再正确组装和使用。

此外，请务必妥善保管本文，以备随时进行确认。

目录	页
重要通知(安全注意事项)	18 ~ 19
配件清单	20
各部位名称	20
组装步骤、使用方法	21 ~ 22
保养方法、产品故障分析和排除	22 ~ 23
使用注意事项、有害物质限量的控制指标	23 ~ 24
产品规格	25
联系方式	25

重要通知(安全注意事项)

请务必遵守。

为了防止使用者或他人遭受危害和经济损失，本文中记述了确保安全且正确使用的重要内容。
请在充分理解下述内容(标示/图形符号)的基础上仔细阅读本文，并严格遵守所述事项。

●标示说明

按错误使用所造成的危害或损失程度进行分类说明。

 警告 可能会导致使用者死亡或重伤(※1)的内容。	 注意 可能会导致使用者遭受伤害(※2)或物质损失(※3)的内容。
---	---

●图形符号说明

通过以下图形符号对应严守的内容进行说明。(以下为图形符号范例。)

 不得执行的“禁止”内容。	 必须执行的“强制”内容。
--	--

※1 所谓重伤，是指因失明或受伤、烫烧伤、骨折、中毒、触电等原因而留下后遗症以及需住院治疗、长期就医的伤势。
※2 所谓伤害，是指无需治疗或住院、长期就医的受伤、烫烧伤。
※3 所谓物质损失，是指住房、家庭财产相关的连带损失。

⚠ 组装注意事项

⚠ 警告	
 禁止	● 对于多余的包装材料应立即进行清理等，请勿放置于幼儿可以触及的场所。否则可能因包装材料套住头部等阻碍嘴或鼻的呼吸而导致窒息的危险。
⚠ 注意	
 严守	● 本产品分量较重，组装时请务必确保两人以上共同作业。强行抬起重物或长物等、以非自然姿势执行安装均可能导致商品损坏或人体受伤。 ● 组装中若发现零部件等的缺损，请立即停止组装并联系客服中心。否则可能因固定部位脱落而导致人体受伤。
请求(其他注意事项)	
	● 请确保宽敞的组装空间，并在地板上铺上铺垫物等以防损伤地板或周围的家具。

⚠ 设置环境注意事项

⚠ 警告	
 禁止	● 请勿设置于火炉等火源附近。否则可能引起火灾。 ● 请注意产品脚部等不要压住家电产品的电源线。否则可能会因电源线断裂而导致触电、火灾。
⚠ 注意	
 禁止	● 请勿长期设置于潮湿场所(参考：湿度在70%以上且室温在20℃以上)。否则可能导致发霉或螨虫等繁殖而危害健康。 ● 设置时，请勿贴着墙壁。(参考：10cm左右)。否则可能因通风不畅、空气滞留而导致墙壁结露或受外部空气影响导致发霉而危害健康。此外，如果直接接触墙壁，还可能导致墙纸变色。

⚠ 设置环境注意事项(续)

请求(其他注意事项)	
	● 请勿使商品直接受到阳光和照明直射、以及火炉和空调等热源及风直吹。否则可能导致弯曲或变形、开裂、变色等。 ● 如果将沙发长期设置于同一场所使用，则可能导致地面及沙发脚接触面产生凹陷而损伤地面。请务必在沙发下铺垫地毯等铺垫物、或在沙发脚上粘贴毡垫等后再使用。由此可防止因木质部位涂漆与地板之间的化学反应而产生污渍。 ● 请设置于平坦、稳定的场所。如果在不稳定场所使用，则可能导致产品变形、损坏。

⚠ 使用注意事项

⚠ 警告

 禁止	● 请勿让婴幼儿睡在本产品上。否则可能会摔落地面或导致窒息。 ● 请勿让孩子在无家长监督的环境下单独使用。 ● 请勿用力拍打、折弯羽毛坐垫。否则可能损伤羽毛或表面面料、导致羽毛外露、人体受伤。 ● 请勿使香烟烟灰等掉落于沙发座面等。否则可能引起火灾。 ● 请勿用于坐以外的其他用途。否则可能导致人体意外受伤。 ● 请勿在坐于沙发上时使沙发倾斜等不稳定状态下使用。否则可能因摔倒或商品损坏而导致人体意外受伤。 ● 请勿在商品上站立、跳跃、将其作为脚踏使用。否则可能因失衡摔倒、商品损坏而导致人体意外受伤。 ● 请勿使用损坏、变形的沙发。可能会造成意外受伤。 ● 请勿擅自维修或改造。否则可能导致产品强度下降、人体受伤。 ● 请勿坐于沙发边缘。否则可能导致摔倒而受伤。 ● 请勿坐在扶手或靠背上。否则可能会造成意外受伤。
---	--





⚠ 注意

 禁止	● 请勿在产品周围、或上部放置物品。否则可能因物品掉落而导致人体受伤。 ● 移动时，请务必确保2人以上共同作业。如果单人强行搬动，则可能导致人体受伤或商品损坏、划伤地板。 ● 请勿安装高度超过12cm的脚及无印良品以外的脚(另售)。否则可能会因翻倒或产品损坏而导致受伤。
 严守	● 万一羽毛较硬部位外露，则请取出羽毛。继续使用则可能因外露的羽毛而导致人体受伤。 ● 刚开始使用时，请务必对室内进行充分换气。木材接合剂等中可能含有甲醛残留物，易导致化学物质过敏体质者及婴幼儿等出现过敏症状。 ● 请安装脚(另售)后再使用。


请求(其他注意事项)

	● 清洁时，请勿使用稀释剂等有机溶剂或漂白剂药剂。否则可能导致变色或变形。 ● 请勿使产品长直接触化学抹布。否则可能导致变色、表面剥落等现象。 ● 请勿在粘贴毡垫的状态下设置于凹凸不平或接缝等具有高低差的地面上使用。否则可能因毡垫剥落而导致污渍或损伤地面。
--	--

配件清单

① 主体×1	② 靠头垫×2	③ 靠垫×2	④ 座垫×2
			
		标签标示 GB3R/GB3L/YB2.5	标签标示 YZ2.5

各部位名称



※使用时请务必安装另售的沙发套。
※沙发套的安装方法请参阅另售沙发套附带的说明书。
※脚为另售。请使用专用脚。

组装步骤


请求
(其他
注意事项)

组装前请务必仔细阅读。

- 请注意确保宽敞的组装空间，并在地板上铺上铺垫物等以防损伤地板或周围的家具。
- 组装时，请务必确保两人以上共同作业。

- 1

 - ① 请按下图所示将 ①A 主体放倒。
 - ② 请将脚(另售)螺栓插入 ①A 主体侧的脚安装孔，然后向箭头方向旋转，最后将其牢牢紧固。
 - ③ 请扶起 ①A 主体。




- 2

请按附带的使用说明书所述安装沙发套(另售)。

- 3

 - ① 请如下图所示，设置 ①D 座垫时将表面面料上带有拉链的一面作为底面，使带有标签的一侧朝向后上方。
 - ② 请按下图所示，设置 ①C 靠垫和 ①B 靠头垫时将框架插入 ①D 座垫的后侧。



请将 ①C 靠垫上带有拉链的一侧朝向下方安装靠垫套。

请按下图所示，设置 ①B 靠头垫时将框架插入 ①D 座垫的后侧。

※ ①B 靠头垫的框架采用不接触 ①A 主体底面的规格。

!
 注意

- 扶起主体时，请注意勿对单侧沙发脚施加过度负荷。否则可能导致产品损坏、地板受损等。移动时，请务必确保2人以上同时抬起后再移动。
- 请务必确认各零件是否已牢固紧固。
- 请在使用一周后重新紧固沙发脚的安装螺栓。如果在松动状态下继续使用，则可能导致沙发损坏而造成受伤的危险。

使用方法

请设置于平坦、稳定的场所。使用时请务必安装另售的沙发套。

保养方法

关于污垢

【主体的表面面料的保养方法】

- 平常保养时，请使用柔软的干布轻轻擦拭。对于灰尘等，请使用毛刷或吸尘器(弱风)等进行清除。
- 如果咖啡等污渍严重时，请用温水将中性洗涤剂进行3~5%左右的稀释后，再将软布浸湿、拧干，轻敲式地擦拭表面。然后，用清水浸润的湿布将洗涤剂擦拭干净，使其自然风干。

【垫部分的表面面料保养方法】

- 局部表面面料沾上污渍时，请使用中性洗涤剂进行手工搓洗。然后将其悬挂于通风良好的场所晾干，并将其中的羽毛揉开。请注意充分晾干，一旦带有湿气则可能产生异味。

【沙发套保养方法】

- 沙发套(另售)的洗涤方法请按其附带的品质标志标签正确进行洗涤。

关于垫部分

【垫部分的保养方法】

- 垫部分的填充物容易偏向一侧。为了防止垫部分走形，请定期揉搓垫部分，使空气充盈其中，保持良好的形状。
- 缓冲材料在使用过程中会逐渐移动而导致变形。请通过从侧面轻轻拍打、揉搓等方式使其保持良好形状。并将垫中充满空气后即可使形状更加完美。



警告

请勿用力拍打、强行折弯垫部分。
否则可能损伤羽毛或表面面料、导致羽毛外露而造成受伤。

- 如果表面面料的接缝处部分绽线、出现小孔，请使用在背面带胶的市售补丁进行修补。
- 阴干等后，请用手轻拍表面清除灰尘。
用力“拍打”可能损伤羽毛或表面面料而导致羽毛外露，故请轻轻拍打。

【关于羽毛外露】

垫部分为了防止充填物的羽毛外露，采用了高密度编织的表面面料，并进行了防绒加工，但羽轴较硬的部位有时可能会从面料的接缝处等钻出。
如果羽轴较硬的部位外露，则请清除外露的羽毛。

【关于羽毛的气味】

刚购买时或在湿度较高的梅雨季节，可能会有羽毛的气味。
如果介意其气味，则请将垫中的气味(空气)压出，换为新鲜空气后放置于通风良好的场所晾晒3至4小时。

产品故障分析和排除

- 使用初期觉得有气味的話
由于是直接工厂放入箱子里，从箱子里拿出来后一段时间会有气味。如果在意的話，可以将其在无阳光直射无雨的地方放置一段时间。慢慢的气味会变淡。
- 家具不稳定的情况下
请确认家具和地面的接触面是否有夹杂物品。如有障碍物，可以将其移走将家具放在平坦的地面。带有调节器的家具，可以进行调整保证其不会前后左右晃动。
- 感觉有摇晃的话
点检各部件的螺丝钉或螺栓是否有松动的情况。如有松动的话请重新安置。部分零件如有裂痕或破损的话请停止使用。
- 其它
上述内容解决不了的问题或存在不清楚的地方请联络所购的店铺。

使用注意事项

关于甲醛对策

- 何谓甲醛
据说，甲醛是导致病态建筑综合症的物质之一。是一种在常温下会气化的无色且具有刺激性气味的化学物质，除了家具以外，建筑材料、黏贴墙纸使用的粘合剂等中均含有这种物质。由于会逐渐扩散，所以如果长时间滞留于被甲醛污染的室内环境，将会刺激眼睛、导致咽喉产生不适的刺激感。如果浓度过高，还可能导致呼吸困难。
- 请对房间进行换气。



注意

设置家具后，请务必对室内进行充分换气。
否则可能导致化学物质敏感体质者及婴幼儿等出现过敏症状。

甲醛易在空气中扩散，故请在日常随时对室内进行充分换气。
同时设置多款家具时，请尽量开大窗户，对室内进行充分换气。室内温度一旦升高，甲醛可能出现加速扩散的倾向，所以在夏季长时间门窗紧闭时，请务必确保充分换气。为了提高换气效率，建议同时打开多扇窗户、开启换气扇、电风扇、空气循环风扇。

- 致化学物质敏感体质的用户
除甲醛以外，其他导致病态建筑综合症的化学物质在容许量上也均因人而异。因此，即使浓度在室内浓度标准值(不会影响健康的甲醛室内浓度值)以下，也会存在过敏反应体质的用户。我们在目前的无印良品家具上已尽力使用甲醛释放量较少的材料，但依然无法完全阻止扩散，故请多加注意。
一旦出现过敏症状，建议立即向医生咨询。
- 无印良品的家具在封装出厂时均已放入甲醛吸附/分解纸。
甲醛在狭窄的空间内无处可逃，可能再次被材料吸附。因此，为了尽量降低送达顾客手中的商品所附甲醛浓度，我们在封包中放入了甲醛吸附/分解纸。
封包中的“甲醛吸附/分解纸”性能已下降，故请作为可燃垃圾处理。

保养检查

- 请定期检查沙发脚有无松动或摇动，一旦发现松动，请立即将其紧固。
以防止受伤或产品损坏、地面损伤。
- 如果羽毛的羽轴从垫部分的接缝等处露出，则请清除后再使用。
- 发现害虫时，请立即进行杀虫或防虫处理。若置之不理则可能导致虫害范围扩大。

关于移动



注意

请勿单人移动产品。否则可能导致受伤或产品损坏、划伤地面。

使用注意事项(续)

- 移动时，请拆除垫部分等可拆除的配件后再进行移动。
请务必双手扶住座部底部，并由两位以上成人抬起后搬运，不得在地面上拖动。

关于报废

报废时，请按各地官方规定的方式进行报废处理。

木家具中有害物质限量 符合GB 18584
甲醛释放量:≤1.5 mg/L
木家具中重金属限量
可溶性铅:≤90mg/kg
可溶性镉:≤75mg/kg
可溶性铬:≤60mg/kg
可溶性汞:≤60mg/kg
纺织面料甲醛含量 符合GB 18401 C类
甲醛含量:≤300 mg/kg

产品规格

产品名称	沙发主体/2.5人座/羽毛/独立式樽型弹簧/高靠背型		
产品尺寸	长	1930mm	
	宽	905mm	
	高	835mm(脚除外)※	
	座面高	330mm(脚除外)※	
	※安装脚(另售)后的高度 安装“5 cm脚”时 高885mm 座面高380mm 安装“10cm脚”时 高935mm 座面高430mm 安装“12cm脚”时 高955mm 座面高450mm 该商品是根据与制造厂商的商定来决定上述商品的尺寸大小。		
产品重量	约59kg		
用 途	沙发/2人用		
材 质	结构材料	主体	: 金属(钢)/胶合板 塑料板(聚丙烯树脂)
		靠头垫	: 金属(钢)
	表面加工	靠头垫	: 环氧聚酯树脂粉体涂装
	蒙面材料	主体	: 聚酯纤维
		垫	: 聚酯纤维/棉
		靠头垫	: 聚酯纤维/棉
	缓冲材料	主体	: 聚氨酯泡沫 钢制弹簧(S型弹簧)
			钢丝
		靠垫	: 羽毛 聚氨酯泡沫
		座垫	: 羽毛 聚氨酯泡沫
			钢制弹簧(樽型弹簧)
		靠头垫	: 羽毛 聚氨酯泡沫
使用场所	室内		
执行标准	QB/T 1952.1-2012 等级 合格品		
安全类别	GB18401-2010 C类		
原 产 国	中国		

联系方式

商品相关咨询，请联系购买商品的销售店。

销售商: **无印良品(上海)商业有限公司**
地 址: 上海市静安区南京西路1601号35楼
3501-3508室 (邮编200040)
电 话: 021-63756677
www.muji.com