

ソファ本体・3シーター・ウレタン・ポケットコイル SOFA / URETHANE / POCKET COIL / 3S 沙发主体/3人座/聚氨酯/独立式樽型弹簧

組立・取扱説明書

User Guide

组装/使用说明书

日本語

この度は本商品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 10.

中文

本次承蒙惠购本产品，在此深表感谢。
请从第十九页开始阅读。

ソファ本体・3シーター・ウレタン・ポケットコイル

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2～4
パーツリスト	5
各部の名称	5
組立方法	6～7
お手入れ方法・ご使用に際して	8～9
製品仕様	8
お問い合わせ先	8

重要なお知らせ (安全上のご注意)

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び治療に入院、長期の通院を要するものをさします。

※2 傷害とは治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。



組み立て・分解の際のご注意



警告



禁止

●不要になった包装資材はすぐに処分するなど、お子さまの手の届く所に置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。



注意



行う

- 重量がありますので、作業は必ず2人以上で行ってください。重いものや長いものなど無理やり持ち上げたり、無理な態勢で取り付けると商品破損やケガの原因となります。
- 組み立て中にパーツなどの不足、不備があった場合は、組み立てを中止してください。固定部分がはずれて、ケガの原因になります。
- 手で④ハンガーボルトを締める際は、手袋や当て布をしてください。④ハンガーボルトで指などケガをするおそれがあります。
- ご使用後一週間ほど経過しましたら、④蝶ネジにゆるみがないか確認し、ゆるみが生じている場合は、締め直してください。ゆるんだまま使用すると商品が破損したり、ケガをするおそれがあります。
- 引越しなどで移動する際は、組み立て前の状態に戻してから運んでください。④蝶ネジにゆるみが生じ商品が破損しケガをするおそれがあります。

お願い (その他 注意)

- 組み立てに十分な場所を確保し、敷物などを敷いて床や既存の家具にキズがつかないように、注意して行ってください。



設置環境についてのご注意



警告



禁止

- ストーブなど引火するおそれのあるものを近くに置かないでください。火災の原因となります。
- 商品の脚などで電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因になることがあります。

重要なお知らせ (安全上のご注意)

必ずお守りください。(つづき)

⚠ 設置環境についてのご注意 (つづき)

⚠ 注意	
禁止	●多湿な場所（目安：湿度70%以上でかつ室温20℃以上）で長期間設置はしないでください。カビやダニなどが発生し、健康を害することがあります。 ●壁から少し離して設置してください。（目安：10cm程度）風通しが悪くて空気が滞留したり、壁側の結露や外気の影響でカビが発生しやすくなり、健康を害することがあります。また、壁に直接触れていると、壁紙が変色するおそれがあります。

お願い (その他 注意)

	●直射日光や照明、ストーブやエアコンなどの熱や風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になります。 ●必ずカーペットなど敷物の上にソファを設置するか、ソファの脚にフェルトなどを貼って使用してください。商品を長時間同じ場所に設置し使用されますと床と、脚の設置面が凹んだりして床をいためる場合があります。木部の塗料と床面との化学反応による汚れ防止になります。 ●平らで安定した場所に設置してください。不安定な場所での使用は、製品がゆがんだり、破損の原因になることがあります。
--	---

⚠ 使用上のご注意

⚠ 警告	
禁止	●乳幼児を寝かさないでください。床への落下や窒息の原因になることがあります。 ●保護者の目の届かないところで、お子さまだけでは使用させないでください。 ●タバコの火などを商品に落とさないでください。火事の原因となります。 ●座る以外には使わないでください。思わぬケガの原因になることがあります。 ●座った状態でソファを傾けるなど、不安定な状態では使用しないでください。転倒や商品の破損により、思わぬケガをする原因となります。 ●商品の上に立ったり、飛びはねたり、踏み台代わりに使用したりしないでください。バランスを崩し転倒したり、商品の破損によりケガの原因になることがあります。 ●破損・変形したソファは使用しないでください。思わぬケガをするおそれがあります。 ●修理や改造はしないでください。製品の強度が弱くなり、ケガをする原因となります。 ●座面に浅く腰掛けないでください。転倒してケガをする原因となります。 ●アームや背もたれには座らないでください。思わぬケガの原因となります。

⚠ 注意

禁止	●製品の周辺、または上部に物を置かないでください。落下しケガの原因になることがあります。 ●12cmを超える長さの脚、また、無印良品の木製脚/スチール脚（別売り）以外は取り付けしないでください。転倒や破損、ケガをするおそれがあります。
行う	●移動する際は、大人2人以上で移動させてください。1人で無理に移動させるとケガや商品の破損、また床をキズつける原因となります。 ●使い始めるときは、室内の換気を十分にしてください。 木材の接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。 ●木製脚/スチール脚（別売り）を取り付けてご使用ください。

重要なお知らせ（安全上のご注意）









必ずお守りください。（つづき）

使用上のご注意（つづき）


お願い（その他 注意）

- シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。
変色や変形の原因となります。
- 化学雑巾を長時間接触させたままにしないでください。
変色したり、表面がはがれたりすることがあります。
- フェルトを貼った状態では凹凸や継ぎ目などの段差のある床面では使用しないでください。
フェルトがはがれて、床面を汚したり、キズつけたりする原因となります。

パーツリスト

①ベース×1 	②背もたれ×1 	③アーム(右)×1 
④アーム(左)×1 	⑤背クッション×2  タグ表示：HB3	⑥座クッション×2  タグ表示：HZ3
フィッティングパーツ		
⑦ハンガーボルト×6 (M8×70mm) 	⑧ワッシャー×6 (外径18mm) 	⑨スプリングワッシャー×6 (外径15mm) 
⑩蝶ネジ×6 (M8) 		

各部の名称



※別売りのカバーを必ず装着してご使用ください。
 ※カバー装着方法は、別売りのカバー付属の説明書をご確認ください。
 ※脚は別売りです。無印良品の木製脚/スチール脚をご使用ください。

組立方法


お願い
(その他 注意)

組み立ての前に必ずお読みください。


- 組み立てに十分な場所を確保し、敷物などを敷いて床や既存の家具にキズがつかないように注意してください。
- 組み立ては必ず2人以上で行ってください。

1

- ③背もたれをタグが後ろ側になるように置いてください。
③背もたれの連結金具に④アーム(右)、⑤アーム(左)の連結金具を下図のように上から引っかけます。




③背もたれには前・後があります。
タグが後ろ側にくるように置いてください。



2


- ③背もたれ、④アーム(右)、⑤アーム(左)に①ハンガーボルトを取り付けます。



手で①ハンガーボルトを
締める際は、手袋や当て
布をしてください。
①ハンガーボルトで指
などケガをするおそれ
があります。

3

- ①(A)ベースのファスナーを開けます。
- ②①ハンガーボルトを(A)ベースの穴から通し、②ワッシャー、③スプリングワッシャー、④蝶ネジを使い固定します。
※①ハンガーボルトがベースの穴に入りにくい場合は、無理に押し込まず、全体の位置を調整しながら差し込んでください。
- ③(A)ベースのファスナーを閉じ、ファスナーのスライダーをポケットに入れます。




ご使用後一週間ほど経過しましたら、
④蝶ネジにゆるみがないか確認し、ゆるみ
が生じている場合は、締め直してください。
ゆるんだまま使用すると商品が破損したり、
ケガをするおそれがあります。

組立方法（つづき）


4

④ ベースの脚取り付け穴に木製脚/スチール脚（別売り）のボルトを入れ、しっかり締めてから本体を起こしてください。



注意

- 起こす際に脚の片側に過度の荷重がかからないようにご注意ください。
破損、床のキズなどの原因になります。
移動するときは2人以上で持ち上げて移動してください。
- 各パーツがしっかり固定されているか必ず確認してください。
- ご使用後、一週間程経過しましたら脚をしっかり締め直してください。
ゆるんだまま使用すると、商品が破損し、ケガをするおそれがあります。





5

カバー（別売り）を付属の取扱説明書に従って装着してください。

6

- ① ⑤座クッションを下図のように、側生地のファスナーが付いている方を下面、タグが付いている方を後ろ上面にし、設置してください。
- ② ⑥背クッションを下図のように、側生地のファスナーが付いている方を下面にし、タグが付いている方を後ろ側にし、設置をしてください。



※分解する際は、組立方法と逆の手順で行ってください。

お手入れ方法

汚れについて

【本体の側生地のお手入れ】

- 通常のお手入れはやわらかい布で乾ぶきしてください。ほこりなどはブラシや掃除機（弱設定）などを使って取り除いてください。
- コーヒーなどの汚れがひどいときは、ぬるま湯を使って3～5%程度に薄めた中性洗剤にやわらかい布を浸し、よく絞って表面をたたくようにふき取ってください。その後、水を浸した布で洗剤をよくふき取り、自然乾燥してください。
- カバー（別売り）の洗濯方法については、カバーの品質表示ラベルに従い、正しくお取り扱いください。

ご使用に際して

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

シックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長期間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

●お部屋の換気について



注意

家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をするようにご注意ください。換気効率をあげるため複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

●化学物質に敏感な体質のお客さまへ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましても、ホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。

アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

●ホルムアルデヒド吸着・分解シートについて

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、無印良品の家具には、ホルムアルデヒド吸着・分解シートを同梱しています。

※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

保守点検

- 脚や背もたれ、アームにゆるみやグラつきがないか定期的に点検し、ゆるみはじめたらしっかり締めなおしてください。ケガや破損、床面へのキズの防止となります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

ご使用に際して（つづき）

移動について



1人では移動を行わないでください。ケガや破損、床面へのキズの原因になります。

- 移動させる際は、クッションなど取り外しできるものははずして運んでください。必ず座部の下に両手をかけて、大人2人以上で、床面をひきずらないように持ち上げて運んでください。
- 引越しなどで移動する際は、組み立て前の状態に戻してから運んでください。④蝶ネジにゆるみが生じ商品が破損しケガをするおそれがあります。

廃棄について

廃棄の際は、住居地域自治体のルールに従い、処分してください。

製品仕様

品 名	ソファ本体・3シーター・ウレタン・ポケットコイル		
製品寸法	幅	2270mm	
	奥行	905mm	
製品寸法	高さ	700mm (脚を除く) ※	
	座面の高さ	305mm (脚を除く) ※	
製品寸法	※木製脚/スチール脚 (別売り) を取り付けたときの高さ		
	「5cmの脚」をつけた場合	高さ750mm	座面の高さ355mm
	「10cmの脚」をつけた場合	高さ800mm	座面の高さ405mm
	「12cmの脚」をつけた場合	高さ820mm	座面の高さ425mm
製品重量	約59kg		
用 途	ソファ・2～3人用		
材 質	構 造 部 材	本 体	金属 (鋼)、合板 プラスチックボード (ポリプロピレン)
	側 生 地	本 体	ポリエステル
材 質	クッション	本 体	ポリエステル・綿
	クッション材	本 体	ウレタンフォーム 鋼製ばね (Sばね) スチールワイヤー 背クッション：ウレタンフォーム 座クッション：ウレタンフォーム 鋼製ばね (コイルスプリング)
原 産 国	中 国		

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様室までご連絡ください。

株式会社 良品計画

〒170-8424

東京都豊島区東池袋 4-26-3

お客様室でんわ



0120-14-6404

SOFA / URETHANE / POCKET COIL / 3S

User Guide

Thank you for your purchase.

Read this User Guide before use to ensure correct use and assembly of the product.

Please store this guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	11 - 13
Parts	14
Part Names	14
Assembly Instructions	15 - 16
Care Instructions	17
Usage	17 - 18
Specifications	18
Contact Information	18

Important Information (Safety Advice)

These instructions
must be followed.

This User Guide contains important information for safe use of this product in order to prevent harm to the user and others as well as damage to property.

Please note the following contents (indications and graphic symbols) before reading the main contents of this guide and follow the instructions given.

- **Explanations of Indications**

The extent of injury and damage that may arise when the product is used incorrectly is classified and explained with the following symbols.



Warning

Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury^{*1} to the user.



Caution

Indicates a hazard with a level of risk which, if not avoided, could result in injury^{*2} to the user or property damage^{*3}.

- **Explanations of Graphic Symbols**

Instructions are given in the form of the following graphic symbols.

(Examples of graphic symbols are as follows.)



DON'Ts: Actions that are prohibited.



DOs: Actions that must be taken.

*1 "Serious injury" indicates blindness, injuries, burns, bone fractures, poisoning, or electric shocks which have long term effects and require hospitalisation and/or long-term hospital visits for treatment.

*2 "Injury" indicates injuries or burns which do not require hospitalisation or long-term hospital visits for treatment.

*3 "Property damage" indicates extended damage that involves the house or household property.



Assembly and Disassembly Precautions



Warning



DON'Ts

- Do not keep unnecessary packing materials within reach of children. Discard them immediately after unpacking. Small children may accidentally pull them over their heads and cover their mouth and/or nose, causing suffocation.



Caution



DOs

- The product must be assembled by two or more people as it is heavy. Forcibly lifting a heavy or long object, or installing such object in an awkward position may cause product damage and/or injury.
- Stop the assembly if any part is missing or broken. Not doing so may cause parts to come off, resulting in injury.
- Wear gloves or use a piece of cloth when tightening hanger bolts to protect your fingers and hands from injury.
- Check if wing nuts are loose approximately one week after assembly and retighten them if necessary. Continued use with loose bolts may cause damage to the product, resulting in injury.
- When relocating the product for moving, etc., disassemble the product beforehand. Not doing so may cause wing nuts to become loose, leading to damage of the product, resulting in injury.

Note (Other Cautions)

- Secure enough space for assembly and place an underlay to protect the floor and other furniture from scratches.



Precautions for Installation Environment



Warning



DON'Ts

- Do not place near a heat source such as a room heater. Doing so may cause a fire.
- Do not place a leg of the product on the power cord of an electrical appliance. Doing so may damage the cord, resulting in an electric shock or a fire.

Important Information (Safety Advice)

These instructions must be followed. (Continued)

Precautions on Installation Environment (Continued)

Caution



DON'Ts

- Do not place the product in a humid place (approx. humidity of 70% or higher and room temperature of 20°C or higher) for a long time. Doing so may cause mould and mites to grow, resulting in health hazards.
- Do not install without any space between the product and the wall. (Approx. 10 cm) Doing so may cause mould growth due to air stagnation from poor ventilation or condensation on the wall owing to outdoor air conditions, resulting in health hazards. In addition, direct contact to the wall may cause discolouration of wallpaper.

Note (Other Cautions)

- Do not expose to direct sunlight and lighting, or heat or air from heating/cooling appliances such as heater and air conditioner. Doing so may cause warping, deformation, cracks, or discolouration.
- Install on top of a rug or other underlay, or attach felt pads on the bottom of the legs. It prevents chemical reactions between the coating on the legs and floor causing marks. Also using the product installed in the same location for a long period of time may result in dents or other damage of the floor surface.
- Install on a flat and stable surface. Using on an unstable surface may cause distortion of or damage to the product.

Precautions for Use

Warning



DON'Ts

- Do not lay small children on the product. Doing so may cause them to fall on the floor or to suffocate.
- Do not let children use the product without supervision.
- Do not drop lit cigarettes, etc. onto the product. Doing so may cause a fire.
- Do not use for other than its intended use of sitting. Doing so may cause unexpected injury.
- Do not use the sofa in unstable conditions such as tilting it while sitting on it. Doing so may result in unexpected injury from falling, or damage of the product.
- Do not stand or jump on the product or use it as a stepladder. Doing so may result in injury from tipping over or damage of the product.
- Do not use if the product is damaged or deformed. Doing so may cause unexpected injury.
- Do not attempt to repair or modify. Doing so may reduce the structural strength of the product, resulting in injury.
- Do not sit near the edge of the seat. Doing so may cause the product to tip over, resulting in injury.
- Do not sit on the arms or backrest. Doing so may result in unexpected injury.

Caution



DON'Ts

- Do not place an object near or on this product. It may fall, causing injury.
- Do not attach legs longer than 12 cm or any legs other than MUJI's wooden/steel legs (sold separately). Doing so may result in the product tipping over, being damaged, or injury.



DOs

- The product must be moved by two or more adults. Moving the product by only one person may cause injury, product damage, or damage to the floor.
- Ventilate the room well during the early stage of use.
Formaldehyde contained in the adhesives may still remain, and those who have high sensitivity to chemicals or small children may experience allergic reactions.
- Make sure to attach MUJI's wooden/steel legs (sold separately) when using this product.

Important Information (Safety Advice)

These instructions must
be followed. (Continued)









Precautions for Use (Continued)


Note (Other Cautions)

- Do not use organic solvents such as paint thinner or bleach for cleaning. Doing so may cause deformation or discolouration.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.
- Do not use on an uneven floor when felt pads are attached to the product. Doing so may cause the felt pads to come off, resulting in dirt or scratches on the floor surface.


Parts

Ⓐ Base × 1 	Ⓑ Backrest × 1 	Ⓒ Arm (right) × 1 
Ⓓ Arm (left) × 1 	Ⓔ Back Cushion × 2  Tag: HB3	Ⓕ Seat Cushion × 2  Tag: HZ3

Fitting Parts

Ⓐ Hanger Bolt × 6 (M8 × 70 mm) 	Ⓑ Washer × 6 (external diameter 18 mm) 	Ⓒ Spring Washer × 6 (external diameter 15 mm) 	Ⓓ Wing Nut × 6 (M8) 
---	---	---	--

Part Names



- * Always use with a cover (sold separately).
- * For instructions on how to attach the cover, refer to the User Guide enclosed with the cover (sold separately).
- * Legs are sold separately. Use MUJI's wooden/steel legs designed for the product.

Assembly Instructions

Note (Other Cautions)


Read these instructions carefully before assembling the product.

- Secure enough space for assembly and place an underlay to protect the floor and other furniture from scratches.
- The product must be assembled by two or more people.

1


Place ⑥ backrest with tag side facing back.

Hook the joints of ③ arm (right) and ④ arm (left) to the joints on ⑥ backrest from above as shown in the illustration below.




Caution

The front and back of ⑥ backrest are different. Place it with the tag side facing back.



2

Attach ① hanger bolts to ⑥ backrest, ③ arm (right), and ④ arm (left).



Caution

Wear gloves or use a piece of cloth when tightening ① hanger bolts to protect your fingers and hands from injury.


3

① Open the fasteners on ① base.

② Put ① hanger bolts into holes through the openings of ① base and fasten them with ② washers, ③ spring washers and ④ wing nuts.

* If ① hanger bolts are hard to fit into the holes, insert them not forcibly but gently while adjusting the overall positions.

③ Close the fasteners on ① base and put the sliders into the pockets.




Caution

Check if ④ wing nuts are loose approximately one week after assembly and retighten them if necessary. Continued use with loose bolts may cause damage to the product, resulting in injury.


Assembly Instructions (Continued)

- 4** Attach wooden/steel legs (sold separately) into the holes on (A) base then securely tighten them. Turn the sofa over.





Caution

- When turning the sofa over, be careful not to apply excessive load on one side of the legs. Doing so may cause damage or scratches on the floor. The product must be lifted and moved by two or more people.
- Make sure all parts are securely tightened.
- Approximately one week after the assembly, securely retighten the bolts on the legs. Continued use with loose bolts may cause damage to the product, resulting in injury.



- 5** Put the cover (sold separately) on referring to the supplied user guide.

- 6**
- ① Place (E) seat cushions with the fastener side facing down and the tag side facing upper back as shown in the illustration below.
 - ② Place (E) back cushions with the fastener side facing down and the tag side facing back as shown in the illustration below.



Completed

* To disassemble the product, follow the process in reverse order.

Care Instructions

Dirt and Stains

[Care instructions for the outer shell of the body]

- For usual care, wipe with a soft, dry cloth. Remove dust by using a brush or a vacuum cleaner (low setting).
- If the product is particularly soiled with stains such as coffee, soak a soft cloth in a warm 3 to 5% solution of a neutral detergent, wring out the cloth thoroughly and pat the cloth on the surface to remove the stain. Then, wipe off any detergent residue with a damp cloth and leave it to dry naturally.
- When washing the cover (sold separately), follow the washing instructions on the cover and handle properly.

Usage

Formaldehyde Countermeasures

- What is Formaldehyde?

Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent-smelling compound that vaporises at room temperature, and is found in items such as furniture, building materials, and wallpaper adhesives. It is released gradually, and people in a room where formaldehyde has accumulated for a long time may experience symptoms such as eye irritations or a sore throat. A high concentration of formaldehyde may cause breathing difficulties.

- Ventilate the room

 Caution	Ventilate the room well when installing the furniture. Persons who have high sensitivity to chemicals or small children may experience allergic reactions.
--	---

Formaldehyde is easily dispersed in the air. Therefore, be sure to ventilate the room regularly. When multiple pieces of furniture are installed at the same time, open the windows widely for sufficient ventilation. More formaldehyde is released when the room temperature increases. Therefore, be careful if the room is closed for a long time during summer, and ventilate the room thoroughly. In order to increase ventilation efficiency, it is recommended that you open multiple windows, or use a ventilation fan or air circulator.

- For persons who have high sensitivity to chemicals

There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even when the actual value in the room is lower than the indoor concentration guideline value (indoor concentration of formaldehyde that is tolerable for health), some people react to formaldehyde. At present, MUJI furniture products are made with materials that emit as little formaldehyde as possible, but this does not guarantee that no formaldehyde is emitted at all. If any allergy symptom appears, it is recommended that you see a physician.

- Formaldehyde absorption/decomposition sheets

When used in confined spaces, formaldehyde may be reabsorbed by the material if there is nowhere for it to dissipate. Formaldehyde absorption/decomposition sheets are used to reduce the concentration of formaldehyde as much as possible before the product reaches the customer.

* Effectiveness of the "formaldehyde absorption/decomposition sheet" in the packaging has been expended by the time the package reaches the customer. Dispose of the sheet as burnable waste after unpacking.

Maintenance and Inspection

- Periodically check for any looseness or wobbling in the legs, arms and backrest, and retighten them if any looseness is found. Doing so will prevent injury, damage or scratches to the floor.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Usage (Continued)

Moving the Product



Do not attempt to move the product alone. Doing so may cause injury, damage to the product, or scratches on the floor.

- When moving the product, remove all removable parts such as cushions beforehand and hold the underside of the seat with both hands. The product must be moved by at least two adults. Do not drag the product on the floor.
- When relocating the product for moving, etc., disassemble it beforehand. Wing nuts may become loose, causing the product to become damaged, resulting in injury.

Disposal

To dispose of the product, follow the rules implemented by your local government.

Specifications

Product Name	SOFA / URETHANE / POCKET COIL / 3S		
Product Dimensions	Width	2270 mm	
	Depth	905 mm	
	Height	700 mm (excluding legs)*	
	Seat Height	305 mm (excluding legs)*	
	*The height when wooden/steel legs (separately sold) are attached.		
	When 5-cm-long legs are attached	Height: 750 mm	Seat Height: 355 mm
	When 10-cm-long legs are attached	Height: 800 mm	Seat Height: 405 mm
	When 12-cm-long legs are attached	Height: 820 mm	Seat Height: 425 mm
Product Weight	Approx. 59 kg		
Usage	Sofa for 2 to 3 People		
Materials	Structural Elements	Body:	Metal (steel), Plywood Plastic Board (polypropylene)
	Outer Shell	Body:	Polyester
		Cushions:	Polyester / Cotton
	Filling	Body:	Urethane Foam Steel Springs (S-spring) Steel Wire
		Back Cushion:	Urethan Foam
		Seat Cushion:	Urethan Foam Steel Springs (coil spring)
Country of Origin		China	

Contact Information

For inquiries regarding the product, please contact the store of purchase.

沙发主体/3人座/聚氨酯/独立式樽型弹簧

组装/使用说明书

本次承蒙惠购本产品，在此深表感谢。
使用前请务必仔细阅读本说明书，并在充分理解的基础上再正确组装和使用。
此外，请妥善保管本说明书，以备随时进行确认。

目录	页
重要通知(安全注意事项)	20~22
配件清单	23
各部位名称	23
组装步骤	24~25
保养方法、产品故障分析和排除	26
使用注意事项	26~27
有害物质限量的控制指标	27
产品规格	27
联系方式	27

重要通知(安全注意事项)

请务必遵守。

为了防止使用者或他人遭受危害和经济损失，本说明书中记述了确保安全且正确使用的重要内容。请在充分理解下述内容(标示/图形符号)的基础上仔细阅读本说明书，并严格遵守所述事项。

- 标示说明
按错误使用所造成的危害或损失程度进行分类说明。

 警告 可能导致使用者死亡或重伤(※1)的内容。	 注意 可能导致使用者遭受伤害(※2)或物质损失(※3)的内容。
--	--

- 图形符号说明
通过以下图形符号对应严守的内容进行说明。(以下为图形符号范例。)

 不得执行的“禁止”内容。	 必须执行的“严守”内容。
--	--

- ※1 所谓重伤，是指因失明或受伤、烫烧伤、骨折、中毒、触电等原因而留下后遗症以及需住院治疗、长期就医的伤势。
- ※2 所谓伤害，是指无需治疗或住院、长期就医的受伤、烫烧伤。
- ※3 所谓物质损失，是指住房、家庭财产相关的连带损失。

组装/拆分注意事项

 警告	
 禁止	●对于多余的包装材料应立即进行清理，请勿放置于儿童可以触及的场所。否则可能有因包装材料套住头部等阻碍嘴或鼻的呼吸而导致窒息的危险。

 注意	
 严守	●本产品分量较重，组装时请务必至少由2人共同作业。强行抬起重或长的物品等，或以不合理的姿势执行安装均可能导致商品损坏或受伤。 ●组装中若发现零部件等的缺损，请立即停止组装。否则可能因固定部位脱落而导致受伤。 ●用手拧紧④吊挂螺栓时，请佩戴手套或垫上布块。④吊挂螺栓可能会导致手指等受伤。 ●请在使用一周后确认④蝶形螺钉是否没有松动，发现松动时请重新拧紧螺钉。如果在松动状态下照常使用，则可能因商品损坏而导致受伤。 ●因搬家等原因需要移动时，请将其恢复至组装前状态后再搬运。否则可能会由于④蝶形螺钉发生松动、造成商品损坏而受伤。

请求(其他 注意事项)	
	●进行组装时请注意确保宽敞的空间，并在地面上铺设铺垫物等以防损伤地面或周围家具。

设置环境注意事项

 警告	
 禁止	●请勿设置于火炉等火源附近。否则可能引起火灾。 ●请注意不要使产品脚部等压住家电产品的电源线。否则可能会因电源线断裂而导致触电、火灾。

⚠ 设置环境注意事项(续)

⚠ 注意

 禁止	● 请勿长期设置于潮湿场所(参考: 湿度在70%以上且室温在20℃以上)。否则可能导致发霉或螨虫等繁殖而危害健康。 ● 设置产品时, 请与墙壁保持一定距离。(参考: 10cm左右)。否则可能因通风不畅而导致空气滞留、墙壁结露或受外部空气影响导致发霉而危害健康。此外, 如果产品直接接触墙壁, 还可能导致墙纸变色。
---	---

请求(其他 注意事项)

	● 请避免阳光或灯光直射, 请勿使火炉、空调等冷暖设备的热气或风直吹到产品。否则可能导致弯曲或歪斜、开裂、变色等。 ● 请务必在沙发下铺垫地毯等铺垫物, 或在沙发脚底面粘贴毛毡等后再使用。如果将产品长期置于同一场所使用, 则可能造成地面与脚部接触面出现凹陷、地面损伤。由此可防止因木质部分的涂漆与地面之间的化学反应而产生污渍。 ● 请设置于平坦、稳定的场所。如果在不平稳的场所使用, 则可能导致产品变形、损坏。
--	---

⚠ 使用注意事项

⚠ 警告

 禁止	● 请勿让婴幼儿睡在本产品上。否则可能导致摔落地面或窒息。 ● 请勿让儿童在无家长监督的环境下单独使用。 ● 请勿使烟灰等掉落于商品。否则可能引起火灾。 ● 请勿用于坐以外的其他用途。否则可能导致人体意外受伤。 ● 请勿在坐于沙发上时使沙发倾斜等不稳定状态下使用。否则可能因翻倒或商品损坏而导致意外受伤。 ● 请勿在商品上站立、跳跃或将其作为脚踏使用。否则可能因失衡翻倒、商品损坏而导致意外受伤。 ● 请勿使用损坏、变形的沙发。否则可能会导致意外受伤。 ● 请勿擅自修理或改造。否则可能因产品强度下降而导致受伤。 ● 请勿坐于座面边缘。否则可能因翻倒而导致受伤。 ● 请勿坐在扶手或靠背上。否则可能导致意外受伤。
---	---







⚠ 注意

 禁止	● 请勿在产品周围或上方放置物品。否则可能因物品掉落而导致受伤。 ● 请勿安装长度超过12cm的沙发脚或者无印良品的木制脚/钢制脚(另售)以外的商品。否则可能会因翻倒或产品损坏而导致受伤。
 严守	● 移动时, 请务必确保2人以上共同作业。如果1人强行搬动, 则可能导致受伤或商品损坏、划伤地面。 ● 刚开始使用时, 请对室内进行充分换气。木材粘合剂等中可能含有甲醛残留物, 易导致化学物质过敏体质者及婴幼儿等出现过敏症状。 ● 请安装木制脚/钢制脚(另售)后使用。


 使用注意事项(续)

请求(其他 注意事项)	
	●清洁时，请勿使用稀释剂等有机溶剂或漂白剂等药剂。 否则可能导致变色或变形。 ●请勿使产品长间接触化学抹布。 否则可能导致变色或表面剥落。 ●请勿在粘贴毛毡的状态下设置于凹凸或接缝等高低不平的地面上使用。 否则可能因毛毡剥落而导致污损或损伤地面。

配件清单

①底座×1 	②靠背×1  连接用 金属零件	③扶手(右)×1  连接用 金属零件	
④扶手(左)×1 连接用 金属零件 	⑤靠垫×2  标签 标签标示：HB3	⑥座垫×2  标签 标签标示：HZ3	
组装零件			
⑦吊挂螺栓×6 (M8×70mm) 	⑧垫圈×6 (外径18mm) 	⑨弹簧垫圈×6 (外径15mm) 	⑩蝶形螺钉×6 (M8) 

各部位名称



※请务必安装另售的专用沙发套后再使用。
※沙发套的安装方法请参阅另售沙发套附带的说明书。
※沙发脚为另售。请使用无印良品木制脚/钢制脚。

######

保养方法

关于污垢

【主体的表面面料的保养方法】

- 日常保养时请使用软布干擦。对于灰尘等，请使用毛刷或吸尘器(弱档)等进行清除。
- 如果沾上咖啡等污渍严重时，请用温水将中性洗涤剂进行3-5%稀释，将软布浸湿、用力拧干后，轻敲式地擦拭表面。然后，请用湿布将洗涤剂擦拭干净后使其自然风干。
- 沙发套(另售)的洗涤方法请按洗涤标识正确进行洗涤。

产品故障分析和排除

- 使用初期觉得有气味的話
由于是直接工厂放入箱子里，从箱子里拿出来后一段时间会有气味。如果在意的話，可以将其在无阳光直射无雨的地方放置一段时间。慢慢的气味会变淡。
- 家具不稳定的情况下
请确认家具和地面的接触面是否有夹杂物品。如有障碍物，可以将其移走将家具放在平坦的地面。带有调节器的家具，可以进行调整保证其不会前后左右晃动。
- 感觉有摇晃的话
点检各部件的螺丝钉或螺栓是否有松动的情况。如有松动的话请重新安置。部分零件如有裂痕或破损的话请停止使用。
- 其它
上述内容解决不了的问题或存在不清楚的地方请联络所购的店铺。

使用注意事项

关于甲醛对策

- 何谓甲醛
据说是导致病态建筑综合症的物质之一。是一种在常温下会气化的无色且具有刺激性气味的化学物质，除了家具以外，建筑材料、粘贴墙纸使用的粘合剂等中均含有这种物质。由于会逐渐扩散，所以如果长时间滞留于被甲醛污染的室内环境，将会刺激眼睛、导致咽喉产生不适的刺激感。如果浓度过高，还可能导致呼吸困难。
- 有关室内通风



注意

设置家具后，请充分对室内进行换气。
否则可能导致对化学物质敏感体质者及婴幼儿等出现过敏症状。

- 甲醛易在空气中扩散，故请在日常充分对室内进行换气。特别在同时设置多款家具时，请尽量开大窗户，对室内进行充分换气。室内温度一旦升高，甲醛可能出现加速扩散的倾向，所以在夏季长时间门窗紧闭时，请务必确保充分换气。为了提高换气效率，建议同时打开多扇窗户，开启换气扇、电风扇、空气循环风扇等。
- 对化学物质敏感体质的顾客
除甲醛以外，其他导致病态建筑综合症的化学物质在容许量上也均因人而异。因此，即使浓度在室内浓度标准值(不会影响健康的甲醛室内浓度值)以下，也会存在过敏反应体质的用户。我们在目前的无印良品家具上已尽力使用甲醛释放量较少的材料，但依然无法完全阻止扩散，故请多加注意。一旦出现过敏症状，建议立即向医生咨询。
 - 甲醛吸附/分解纸
甲醛在狭窄的空间内无处可逃，可能再次被材料吸附。因此，为了尽量降低送达顾客手中的商品所附甲醛浓度，在无印良品的家具封包中放入了甲醛吸附/分解纸。
※封包中的“甲醛吸附/分解纸”性能已下降，故请作为可燃垃圾处理。

保养检查

- 请定期检查沙发脚和靠背是否有松动或摇晃，发现松动时请重新紧固。以避免受伤或商品损坏、划伤地面。
- 发现虫害时，请立即杀虫及进行防虫处理。若置之不理，则可能会导致扩大虫害面积。

关于移动



注意

请勿1人移动商品。否则可能会导致受伤、产品损坏或造成地面损伤。

使用注意事项（续）

- 移动时，请拆除座垫等可拆除的配件后再进行移动。请务必双手抬住座位底部，并由2名以上成人抬起搬运，注意请勿在地面上拖动。
- 因搬家等原因而需要移动时，请将其恢复至组装前状态后再搬运。否则可能会由于④蝶形螺钉发生松动、造成商品损坏而受伤。

关于报废

报废时，请按各地官方规定的方式进行处理。

有害物质限量的控制指标

木家具中有害物质限量 符合GB 18584
甲醛释放量：≤1.5 mg/L
木家具中重金属限量
可溶性铅：≤90mg/kg 可溶性镉：≤75mg/kg 可溶性铬：≤60mg/kg 可溶性汞：≤60mg/kg
纺织面料甲醛含量 符合GB 18401 C类
甲醛含量：≤300 mg/kg

产品规格

产品名称	沙发主体/3人座/聚氨酯/独立式樽型弹簧		
产品尺寸	宽	2270mm	
	深	905mm	
	高	700mm (不包括沙发脚)※	
	座面高度	305mm (不包括沙发脚)※	
	※安装木制脚/钢制脚(另售)后的高度 安装“5cm脚”时 高750mm 座面高 355mm 安装“10cm脚”时 高800mm 座面高 405mm 安装“12cm脚”时 高820mm 座面高 425mm 该商品是根据与制造厂商的商定来决定商品的尺寸大小。		
产品重量	约59kg		
用 途	沙发/2-3人用		
材 质	结构件	主体：	金属(钢)、胶合板、树脂板(聚丙烯树脂)
	表面面料	主体：	聚酯纤维
	缓冲材料	靠垫、座垫：	聚酯纤维、棉
		主体：	聚氨酯泡沫、钢制弹簧(S弹簧)、钢丝
		靠垫：	聚氨酯泡沫
	座垫：	聚氨酯泡沫、钢制弹簧(弹簧)	
使用场所	室内		
执行标准	QB/T 1952.1-2012		
安全类别	GB18401-2101 C类		
等 级	合格品		
原 产 国	中 国		

联系方式

商品相关咨询，请联系购买商品的销售店。

销售商：无印良品(上海)商业有限公司
地 址：上海市静安区南京西路1601号35楼
3501-3508室（邮编200040）
电 话：021-63756677
www.muji.com