

ブナ材アームチェア 丸脚

品名	ブナ材アームチェア 丸脚
J A N	4550512892397
製品寸法	約幅555 × 奥行505 × 高さ730 mm
座面の高さ	約425 mm
製品重量	約6 kg
用途	チェア (1人用)
材質	構造部材:天然木(ブナ材)
表面加工	ウレタン樹脂塗装
原産国	日本

取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

2024年1月30日

お手入れ方法

保守・点検

- 各部にグラつきや破損がないか定期的に点検し、異常が認められたら使用を中止してください。そのまま使用すると、ケガや破損の原因となります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

木部のお手入れ

- 塗装面のほこりはやわらかい布または、はたきで軽く払ってください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。

ご使用方法

移動について

- 移動させる際は、製品を引きずらないでください。製品破損や床面へのキズ、ケガしたりするおそれがあります。

廃棄について

- 廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ
0120-14-6404

重要なお知らせ(安全上のご注意)

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

⊘ してはいけない「禁止」の内容です。

❗ 実行しなければならない内容です。

⚠ 警告 死亡や重傷などに結びつくおそれがあるもの

- 乳幼児を寝かさないでください。床へ落下したり、窒息したりする原因となることがあります。
- 座りながら製品を傾けたり、不安定な体勢で使用したりしないでください。転倒や破損、床をキズつける、ケガの原因となります。
- 規定を超える人数では使用しないでください。破損してケガをするおそれがあります。(詳しくは製品仕様をご確認ください。)
- 製品の上に立たないでください。バランスをくずして転倒する、製品の破損によりケガをするおそれがあります。
- 保護者の目の届かない場所で、お子さまだけで使用させないでください。思わぬケガの原因となります。
- 座面以外に座らないでください。思わぬケガの原因となります。
- 座る用途以外で使用しないでください。思わぬケガの原因となります。
- 座面に浅く腰掛けないでください。転倒や破損、ケガをするおそれがあります。
- 一部(の脚)に片寄る過度な荷重は加えないでください。部材の破損の原因となり、ケガをするおそれがあります。
- 破損や変形した状態では使用しないでください。製品の強度が弱くなりケガをするおそれがあります。
- 修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。
- 製品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因となります。

- ❗ 行う ●平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になることがあります。

⚠ 注意 傷害を負う可能性や物的損害が生じるおそれがあるもの

- 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。
 - 不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。
 - シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。変色や変形の原因となります。
 - 長時間、化学雑巾を接触させたままにしないでください。変色や表面がはがれる原因となります。
- ❗ 行う ●使い始めは室内の換気を十分に行ってください。製品に微量にホルムアルデヒドが含まれることがあります。敏感な方や乳児などはアレルギー症状を起こすおそれがあります
 - 直射日光を避け、冷暖房具の熱や風に当たらないようにしてください。反り、割れ、変色の原因になります。
 - 塗装やプラスチック部にアルコールを含む消毒剤などが垂れた場合にはすぐにふき取ってください。また、過度なアルコール消毒剤でのふき掃除はお避けください。表面が変色や変質することがあります。

パーツリスト・各部の名称

① 本体×1	フィッティングパーツ
	② フェルト×4 

ご使用方法

⚠ 注意	❗ ご使用の前に、付属の③フェルトを脚底面にお貼りください。フローリング床などのキズつき防止、ガタつきの際の調整にご使用いただけます。
🙏 (その他 注意)	貼る前に貼る面のほこりなどの付着物をふき取ってください。付着物があると粘着力が低下します。貼った後は全体をしっかりと押さえて、ムラなく接着してください。

Beech armchair Round legs

User Guide

Thank you for your purchase.
Read this User Guide before use to ensure correct use of the product.
Store this guide in an easily accessible place for future reference.

30 January 2024

Directions for Use

Moving the Product

- Do not drag to move the product. Doing so may cause product damage, floor scratches and/or injury.

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Important Information (Safety Advice)

The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.

 Actions that are prohibited.

 Actions that must be taken.

 **WARNING** Hazards that may lead to death or serious injury

 DON'Ts

- Do not lay small children on the product. Doing so may cause them to suffocate or fall on the floor.
- Do not use in an unstable state, such as tilting while sitting on the product. Otherwise this may cause tip-over, damage, floor scratches and/or injury.
- Do not allow more than the specified number of people to use at the same time. Doing so may cause damage, resulting in injury. (See the Specifications for details.)
- Do not stand on the product. Doing so may cause you to fall, the product to become unstable and fall over or become damaged, leading to injury.
- Do not let children use without supervision. Doing so may result in unexpected injury.
- Do not sit on any part other than the seat. Doing so may cause unexpected injury.
- Do not use for other than its intended purpose of sitting on. Doing so may cause unexpected injury.
- Do not sit near the edge of the seat. Doing so may cause tip-over, damage and/or injury.
- Do not put excessive load only on one side (of the legs). Doing so may damage the parts and lead to injury.
- Do not use if damaged or deformed. Doing so may cause insufficient strength and may lead to injury.
- Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury.
- Do not place on the power cord of an electrical appliance. Doing so may damage the cord, leading to electric shock or a fire.

 **WARNING (Continued)** Hazards that may lead to death or serious injury

 DOs

- Use on a flat and stable surface. Otherwise it may cause product distortion or damage.

 **CAUTION** Hazards that may result in injury or damage to the property

 DON'Ts


- Do not use outdoors. Doing so may cause deformation or severe degradation, resulting in injury.
- Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate.
- Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.

 DOs

- Ventilate the room well at the early stage of use. The product may contain a small amount of Formaldehyde, and those with chemical sensitivity or small children may experience allergic reactions.
- Avoid exposure to direct sunlight and heat or air from heating and cooling appliances such as an air conditioner and a heater. Not doing so may cause warping, cracking and discolouration.
- Wipe off immediately when alcohol-containing disinfectant is spilled on the coating or plastic parts. Do not excessively wipe with alcohol disinfectant. Doing so may cause discolouration or deterioration of the surface.

Names of Parts / Fitting Part

① Chair × 1



Backrest

Seat

Leg

Fitting Part


② Felt Pad × 4



Directions for Use

 **CAUTION**

① Attach the provided ② felt pads to the bottoms of the legs before start of use. This will help protect the wood flooring, etc. from scratches and adjust the height of the legs to fix the wobbling.



② Felt Pad

Leg

Note
(Other Caution)

Remove any dust and other debris from the attachment surface before attaching ② felt pad. It may not adhere well if there is anything on the surface. Press the whole pad firmly so it adheres evenly.