【校正承認No.】 EZ20230529-01-R01 共聚酯便携随行杯说明书 【サイズ】112(W) x 154(H)mm 文字色 黒

英数字体: MUJI Font

CLEAR BOTTLE SLIM TYPE User Manual

MUJI 無印良品

OPlease read this manual carefully before using the product. In addition, please keep this manual proper-

To prevent accidents due to misuse, the following graphic symbols are used to illustrate the contents to be observed.

Meanings of symbles are as following:

△Pay attention to the content that may cause minor injuries or product damage.

Before use

- ©Do not use the product if any small scars or cracks. Otherwise, the product may be damaged. &Before use, all parts should be cleaned with warm water, and keep parts assembly correctly.
- ☼Do not feed boiling water for disinfection, which may cause the product deformed.
 ☼Do not keep the following objects inside the product.
- •Dry ice, carbonated drinks, fermented food. The product may break due to the increase of internal air
- Milk, milk-containing beverages, fruit juice, pulp, etc. Otherwise, this product may cause food spoilage and deterioration.

 •Tea, coffee powder, teabags with ropes, etc. If the residue is caught in the sealing, it may cause the
- product to leak.

•In use

ODo not put drinks with excessive temperature in this product. Otherwise, it may result in scalding, deformation, damage and water leakage of the product. When filling boiled drinks such as tea, it is recom-

mended to wait until the water temperature drops before filling. It is recommended that the drink temperature be below 50°C to avoid scalding.

- AWhen screwing on the lid, please keep it level with the main body. Otherwise, there will be gaps, resulting in water leakage.
- ODo not use it as a storage container. Otherwise, this product may cause food spoilage and deterioration. ODo not use this product in the freezing room or cold room below the ice node. Otherwise, the liquid will expand due to freezing, which may cause the main body damaged.
- OPlease avoid strong impact such as falling or overturning or excessive pressure on the product. Otherwise, the product may be damaged or water leakage.
- ODo not use it during car running. Otherwise, the car and clothes may be stained. In addition, when driving, it will cause inattention and may cause great danger.
- ODo not heat, refrigerate or freeze in the state of filling drinks.
- Obo not put the product near fire sources and heat sources such as cooking ranges and stoves, or use it in microwave ovens and baking ovens. Otherwise, the product may be desformed or damaged. OMinors should use this product under the guidance of adults.

After use

OWhen cleaning, do not use sponges, metal cleaning balls, detergent powder, containing abrasives,etc.

May damage the surface layer of the product, resulting in product breakage.

- △When the dirt is serious, use appropriate diluted neutral detergent for cleaning.
 ○Do not cover the main body with detergent. Otherwise, the product may be damaged.
- ODo not boil this product. Otherwise, the product may be deformed, cracked, whitened or discolored due
- ODo not use dishwasher to clean this product. Otherwise, the product may be deformed, cracked, whitened or discolored due to heat.

 Obo not use thinner, gasoline, alcohol, kerosene, etc. Otherwise, the product may be damaged.

SMILE CORP

2023.06.03

