MUJI 無印良品

ユニットソファ本体 オットマン

取扱説明書

この度は本商品をお買い上げいただき、誠に ありがとうございます。

ご使用前に本書をよくお読みいただき、内容 を理解した上で、正しくお使いください。 また、本書はいつでも確認できるように大切 に保管してください。

2021年3月3日 [原産国]中国

品 名	ユニットソファ本体 オットマン		
規 格	大幅77cm	小	
JAN	4550182961539	4550182961508	
製品寸法	幅770mm×奥行770mm×高さ370mm	幅610mm×奥行610mm×高さ370mm	
座面の高さ	370mm		
製品重量	約12kg	約9kg	
用 途	オットマン (足のせ用)・1人用		
材質	構造 部 材 本体:合板、繊維板、ポリプロピレン 脚部:ポリプロピレン 張 り 材 :ポリエステル100% クッション材 :ウレタンフォーム、ポリエステルわた、鋼製ばな(コイルスプリング)		
盾 庭 国	山田		

ご使用方法

1人では移動を行わないでください。ケガや 破損、床面へのキズの原因になります。

●移動させる際は、必ず座部の下に両手を かけて、大人2人以上で、床面をひきずら ないように持ち上げて運んでください。

廃棄について

●廃棄の際は、居住地域の自治体のルール に従い、処分してください。

お手入れ方法

保守・点検

- ●各部にゆるみがないか定期的に点検し、 ゆるみはじめたらしっかり締め直してくだ さい。ゆるんだまま使用すると、ケガや破損 のおそれがあります。
- ●害虫を発見した場合は、直ちに殺虫や防虫 処理をしてください。放置すると虫害が拡大 するおそれがあります。

汚れについて

保存用 製品仕様

【カバーのお手入れ】

- ●通常のお手入れはやわらかい布で乾ぶき してください。ほこりなどはブラシや掃除機 (弱設定)などを使って取り除いてください。 ●コーヒーなどの汚れがひどい時は、ぬるま湯
- を使って3~5%程度に薄めた中性洗剤 に、やわらかい布を浸し、よく絞って表面を叩くようにふき取ってください。その後、 水を浸した布で洗剤をよくふき取り、自然 乾燥してください。

●カバーの洗濯方法については、カバーの 品質表示ラベルに従い、正しく取り扱い ください。

【脚のお手入れ】

- ●塗装面のホコリは、やわらかい布または、 ハタキなどで軽く払ってください。硬い布や ほこりなどが付着した状態でこすると細かな キズがつく原因となります。
- ●汚れのひどい時は、3~5%に薄めた中性 洗剤を浸した布で汚れを落とし、その後、 水で浸した布で洗剤分をよくふき取ってくだ さい。次に乾いた布で軽くふいた後、自然 乾燥させてください。

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店 もしくは下記お客様相談室までご連絡くだ さい。

良品計画 株式会社

T170-8424

東京都豊島区東池袋 4-26-3

お客様相談室でんわ

00,0120-14-6404

重要なお知らせ(安全上のご注意)

実行しなければならない 内容です。

- ●不要になった梱包材は、幼児の手の届くところに置かないでください。頭から
- かぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。 ●ストーブなど引火するおそれのあるものを近くに置かないでください。火災の 原因になります
- ●商品で電化製品の電源コードを踏まないでください。コードが破損し、感電や 火災の原因となるおそれがあります。
- ●乳幼児を寝かさないでください。床への落下や窒息の原因となることがあり 生す.
- ●保護者の目の届かないところで、お子さまだけでは使用させないでください。
- 思わぬケガの原因となります。
- ●タバコの火などを商品に落とさないでください。火災の原因となります。

死亡や重傷などに結びつくおそれがあるもの

- ●本来の用途以外では使用しないでください。思わぬ事故やケガの原因となり ます。
- ●座った状態で商品を傾けるなど不安定な状態では使用しないでください。転倒
- や商品の破損によりケガをしたり、床をキズつける原因となります。 ●商品の上に立ったり、飛びはねたり、踏み台代わりに使用したりしないでください。バランスをくずし転倒したり、商品の破損によりケガをするおそれがあり ます。
- ●破損、変形した状態では使用しないでください。商品の強度が弱くなりケガを するおそれがあります
- ●修理および改造はしないでください。商品の強度が弱くなり、ケガをするおそれ があります。
- ●座面に浅く腰掛けないでください。転倒してケガをする原因となります。

/ 注意 損害を負う可能性や物的損害が生じるおそれがあるもの

- ●直射日光や照明、ストーブやエアコンなどの冷暖房器具の熱や風を商品に直接
- あてないでください。反りやゆがみ、割れ、変色などの原因になります。

 ●多湿な場所(目安:湿度70%以上でかつ室温20℃以上)に長期間設置はしないでください。カビやダニなどが発生し、健康を害することがあります。
- ●商品の設置場所の上部に物を置かないでください。地震時などにその物が落下 してケガをする原因となります
- ●移動する際は、引きずったり落としたりしないでください。商品の破損、床面 へのキズの原因となります
- ●商品を長時間同じ場所に設置し使用されますと、床と脚の設置面が凹んだり して床をいためる場合があります。必ずカーペットなど敷物の上にソファを設置 してください。本部の塗料と床面との化学反応による汚れ防止になります。 ●壁から少し離して設置してください。風通しが悪くて空気が滞留したり、壁側
- の結露や外気の影響でカビが発生しやすくなり健康を害することがあります。 また、壁に直接触れていると、壁紙が変色するおそれがあります。
- ●使い始める時は、室内の換気を十分にしてください。 接着剤などに含まれる ホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や 乳幼児などアレルギー症状をおこすおそれがあります。
- ●移動する際は、大人2人以上で移動させてください。 1人で無理に移動させる とケガや商品の破損、また床をキズつける原因となります。

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

シックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭 のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。 ホルムアルデヒドに汚染された室内に長期間いると目がチカチカ 少しづつ放散されるため、 したり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす 場合もあります。

●お部屋の換気について

家具を設置の際は、室内の換気を十分にしてください。 化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行う ようにしてください。 特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、 十分な換気を行ってください。 室内の温度が高くなると、ホルムアルデヒドは多く放散 される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をする ようにご注意ください。換気効率をあげるため複数の窓を開けたり、換気扇、扇風機、サー キュレーターの利用をおすすめします。

●化学物質に敏感な体質のお客さまへ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があります。よって、室内濃度指針値(健康上望ましいとされるホルムアルデヒドの室内 濃度値)以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品 の家具におきましても、ホルムアルデヒド放散量の少ない材料を極力使用しております まったく放散されないわけではありませんので、 ご注意ください。 アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

●ホルムアルデヒド吸着・分解シートについて

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります ると、 お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、 無印良品の家具には、 ホルムアルデヒド吸着・ 分解シートを同梱しています。


※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃える ゴミとして処分してください。

お願い(その他 注意)

- ●平らで安定した場所に設置してください。不安定な場所での使用は、商品が
- ゆがんだり、破損の原因になることがあります。 ●シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。 変色や変形の原因となります。
- ●化学雑巾を長時間接触させたままにしないでください。変色したり、表面が はがれたりするおそれがあります。
- ●フェルトを貼った状態で、凹凸や継ぎ目などの段差のある床面では使用しない でください。フェルトがはがれて、床面を汚したり、キズつけたりする原因と なります。

各部の名称

このイラストは「ユニットソファ本体 オットマン 大幅77cm」を使用しています。



お願い (その他 注意)

- ●必ず別売りの専用カバーを装着してご使用ください。
- ●カバー装着方法は、別売りのカバーに付属の説明書をご確認 ください。

MUJI 無印良品

Retain for future reference

Unit sofa Ottoman

User Guide

Thank you for your purchase.

Read the User Guide before use to ensure correct use of this product.

Store this guide in an easily accessible place for future reference.

3 March 2021

Specifications

Product Name	Unit sofa Ottoman		
Specifications	L W77 cm	S	
JAN	4550182961539	4550182961508	
Product Dimension	W770 × D770 × H370 mm	W610 × D610 × H370 mm	
Seat Height	370 mm		
Product Weight	Approx. 12 kg	Approx. 9 kg	
Usage	Ottoman (Footstool) for One Person		
Structural Elements: Body: Plywood, Fibre Board, Polypropyle Legs: Polypropylene Covering Material: 100% Polyester Cushioning Materials: Urethane Foam, Polyester Filling, Steel Spring (Coil Spring)			
Place of Origin	CHINA		

Directions for Use

Relocating the Product

- Do not move the product alone. Otherwise, this may cause injury, damage to the product, or scratches on the floor.
- When moving the product, be sure to hold the underside of the seat with both hands. The product must be moved by at least 2 people. Do not drag the product on the

Disposal

• To dispose of the product, follow the rules implemented by your local government.

Care Instructions

Maintenance and Inspection

- · Periodically check for any looseness in all parts, and retighten them if looseness is found. Continued use in this state may result in injury or damage to the product.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Cleaning

For regular cleaning, wipe with a soft, dry cloth. Remove dust with a brush or a vacuum cleaner (at low setting).

mouth and/or nose, causing suffocation.

suffocate or fall on the floor.

unexpected accident or injury.

scratches on the floor or injury.

product and may cause injury.

product and may cause injury.

in unexpected injury.

damage the cord and cause electric shock or a fire.

 \bigwedge <code>Warning</code> Hazards that may lead to death or serious injury

Do not leave unnecessary packaging materials within reach of small children.

Small children may accidentally pull them over their heads and cover their

• Do not place near a heat source such as a heater. Doing so may cause a fire

• Do not place on the power cord of an electrical appliance. Doing so may

• Do not lay small children on the product. Doing so may cause them to

• Do not let children use the product without supervision. Doing so may result

• Do not drop lit cigarettes, etc. onto the product. Doing so may cause a fire.

 \bullet Do not use for other than its intended purpose. Doing so may cause

• Do not use in an unstable condition, such as tilting the product while sitting on

• Do not stand or jump on the product or use it as step stool. Doing so may

• Do not use if damaged or deformed. Doing so will reduce the strength of the

• Do not attempt to repair or modify. Doing so will reduce the strength of the

• Do not sit near the edge of the seat. Doing so may cause tip-over, resulting in

cause it to lose balance and tip over or become damaged, resulting in injury.

it. Doing so may cause tip-over or damage to the product, resulting in

• If the product is particularly dirty, such as with coffee stains, soak a soft cloth in a warm 3% to 5% solution of neutral detergent, wring it out thoroughly and pat the stained surface with the cloth to remove the stains. Then, wipe off any detergent residue with a damp cloth and let the product dry naturally.

 When washing the cover, follow the washing instructions on the cover and handle it properly.

[Legs]

• Gently wipe off dust from coated surfaces using a soft

cloth or duster. Rubbing dusty surfaces with a hard cloth may result in small scratches


• If the product is heavily soiled, clean it with a cloth soaked in 3% to 5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let it dry naturally.


Contact Information

For enquiries regarding the product, please contact the

Important Information

The warnings and cautions indicated here are intended to prevent harm to





(Safety Advice)

the users and other individuals or damage to the property. The instructions must be followed.

DON'Ts

• Do not expose to direct sunlight or lighting, or heat or air from heating and cooling appliances such as air conditioner and heater. Doing so may cause warping, distortion, cracking or discolouration.

- Do not install in a room with high humidity (approx. humidity of 70% or higher and room temperature of 20 $^{\circ}\text{C}$ or higher) for a long time. Doing so may cause mould and mites to grow, resulting in health hazards
- Do not place anything above the product. It may fall and cause injury in the event of an earthquake, etc.
- Do not drag or drop when moving the product. Doing so may cause damage to the product and/or scratches to the floor.
- 0
- Always place the product on a rug or any other underlay. Using the product in the same location for a long time may result in dents or other damage on the floor surface. Also chemical reactions between the coating on the legs and floor may occur, resulting in marks on the floor. • Install slightly away from the wall. Not doing so may cause mould growth due
- to air stagnation from poor ventilation or condensation on the wall, resulting in health hazards. Also, placing the product directly in contact with the wall may cause discolouration of the wall paper.
- Ventilate the room well at the early stage of use. Formaldehyde contained in adhesive may still remain, and those with chemical sensitivity or small children may experience allergic reactions.
- The product must be moved by two or more adults. Attempting to move the product alone may result in injury, damage to the product or scratches on the

Formaldehyde Countermeasures

What is Formaldehyde?

Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent-smelling chemical often found in furniture, building materials, wallpaper adhesives, etc. that vaporises at room temperature. As it is gradually released into the air, spending a long time in a room contaminated with formaldehyde can result in eye and throat irritation. Also, exposure to a high concentration of formaldehyde may cause breathing difficulties.

Room Ventilation

Ventilate the room well when installing the furniture. Some individuals sensitive to chemicals and small children may experience allergic symptoms.

Be sure to frequently ventilate the room regularly as formaldehyde is easily released into the air. Especially when multiple pieces of furniture are installed at the same time, open the windows wide enough to allow adequate ventilation. Formaldehyde emission tends to increase with temperature rise of the room. Therefore, be sure to ventilate thoroughly after the room has been closed up for a long time during summer. It is recommended that you open multiple windows and use a ventilation fan or an air circulator to increase ventilation efficiency.

• For Individuals Sensitive to Chemicals

There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even if the actual concentration in the room is equal to or lower than the indoor concentration guideline value (acceptable safe level of formaldehyde indoors), some people may react to formaldehyde. MUJI furniture are made with materials that contain as little formaldehyde as possible, but note this does not guarantee that no formaldehyde is emitted. It is recommended that you seek medical attention if you experience any allergic symptoms.

• Formaldehyde Adsorption/Decomposition Sheet


Formaldehyde is readsorbed onto materials when there is nowhere for it to dissipate in a confined space. Therefore, a formaldehyde adsorption/decomposition sheet is included in the packaging to reduce formaldehyde concentration as much as possible before the product reaches the customer.

The effect of the sheet will be diminished by the time the product reaches the customer. Dispose of the sheet as burnable waste after unpackaging.

Note (Other Caution)

- Install on a flat and stable surface. Using on an unstable surface may cause distortion or damage to the product.
- Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.
- Do not use on an uneven floor when felt pads are attached to the product. Doing so may cause the felt pads to come off, resulting in dirt or scratches on the floor surface.

Part Names



Note (Other Caution)

- Be sure to use with a MUJI's cover (sold separately) attached.
- For instructions on how to attach the cover, refer to the User Guide enclosed with the cover (sold separately).