

竹材 コーナーラック

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

2023年6月28日

ご使用方法

廃棄について

●廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お手入れ方法

保守・点検

- 各部にゆれみがないか定期的に点検し、ゆるみはじめたらしっかり締め直してください。ゆるんだまま使用すると、ケガや破損のおそれがあります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

製品仕様

品名	竹材 コーナーラック1段	竹材 コーナーラック3段
JAN	4550182995169	4550344171707
製品寸法	幅260×奥行260×高さ210 mm	幅260×奥行260×高さ600 mm
製品重量	0.5 kg	1.3 kg
用途	室内用 収納棚	
耐荷重	約7 kg	1棚あたり7 kg、全耐荷重 21 kg
材質	本体：竹、 フィッティングパーツ：金属（鋼）	
表面加工	本体：アクリル樹脂塗装、 パーツ：めっき（亜鉛末クロム酸化皮膜）	
原産国	中国	

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ
0120-14-6404

重要なお知らせ(安全上のご注意)

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

☞ してはいけない「禁止」の内容です。

❗ 実行しなければならない内容です。

警告 死亡や重傷などに結びつくおそれがあるもの

- 保護者の目の届かない場所で、お子さまだけで使用させないでください。思わぬケガの原因となります。
 - 指定の用途以外で使用しないでください。破損してケガをするおそれがあります。
 - 耐荷重を超えて物をのせたり、耐荷重内でも一部に片寄ってのせたりしないでください。変形や破損の原因となり、ケガをするおそれがあります。
 - 製品の上にのらないでください。バランスをくずして転倒する、製品の破損によりケガをするおそれがあります。
- 各部にゆれみがないか定期的に点検し、ゆるんでいたらしっかり締め直してください。ケガや製品の破損防止になります。

注意 傷害を負う可能性や物的損害が生じるおそれがあるもの

- 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。
- 高温多湿な場所に長期間設置しないでください。カビやダニなどが発生し、健康を害することがあります。

注意(つづき) 傷害を負う可能性や物的損害が生じるおそれがあるもの


- シンナーなどの有機溶剤や漂白剤などの薬剤で手入れしないでください。変色や変形の原因となります。
- 製品の端のほうに物を置かないでください。バランスをくずし製品ごと倒れるおそれがあります。
- アルコールを含む消毒剤などが垂れた場合にはすぐにふき取ってください。また、過度なアルコール消毒剤でのふき掃除はお避けください。表面が変色や変質することがあります。
- 平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になります。
- 直射日光を避け、冷暖房具の熱や風に当たらないようにしてください。反り、割れ、変色の原因になります。
- 製品が濡れたり湿ったりした場合は、水分をよくふき取り、乾かしてからご使用ください。劣化の原因となります。
- 組み立ての際は、手袋などをつけて作業してください。思わぬケガの防止になります。

パーツリスト

① 右側フレーム × 1			
② 左側フレーム × 1			
左側フレームのほうが少し横幅が広いです			
③ 棚			
1段 × 1			
3段 × 3			
フィッティングパーツ			
④ ボルト(長)	⑤ ボルト(短)	⑥ レンチ	⑦ フェルト
3 mm用	20×10×2 mm		
1段 × 2	× 3	× 1	× 3
3段 × 3	× 9	× 1	× 3

組立方法

イラストには竹材 コーナーラック3段を使用しています。



Bamboo Corner rack

User Guide

Thank you for your purchase.
Read this User Guide before use to ensure correct use of the product.
Store this guide in an easily accessible place for future reference.

28 June 2023

Directions for Use

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Contact Information

For enquiries regarding the product, please contact the store of purchase.

Specifications

Product Name	Bamboo Corner rack 1 Tier	Bamboo Corner rack 3 Tiers
JAN	4550182995169	4550344171707
Product Dimension	W260 × D260 × H210 mm	W260 × D260 × H600 mm
Product Weight	0.5 kg	1.3 kg
Usage	Storage shelf for indoor use	
Withstand Load	Approx. 7 kg	7 kg per shelf, 21 kg in total
Material	Body: Bamboo, Fitting Part: Metal (Steel)	
Surface Finish	Body: Acrylic Resin Coating, Part: Plating (zinc chromate passivation coating)	
Place of Origin	CHINA	

Care Instructions

Maintenance and Inspection

- Regularly check for any looseness in all parts, and retighten them if looseness is found. Continued use in this state may result in injury or damage to the product.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Maintenance of Bamboo Parts

- For daily care, wipe with a soft, dry cloth.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.

Important Information (Safety Advice)

The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.

Actions that are prohibited.

Actions that must be taken.

WARNING Hazards that may lead to death or serious injury

	<ul style="list-style-type: none"> Do not let children use without supervision. Doing so may cause unexpected injury. Do not use for other than its intended purpose. Doing so may cause product damage and lead to injury. Do not place anything exceeding the withstand load or anything only on one side even if it is within the withstand load. Doing so may cause product deformation or damage and lead to injury. Do not stand on the product. Otherwise it may cause you to fall, or the product to become unstable and fall over or become damaged, leading to injury.
	<ul style="list-style-type: none"> Regularly check for any looseness in all parts, and retighten them if looseness is found. This is to prevent injury and product damage.

CAUTION Hazards that may result in injury or damage to the property

	<ul style="list-style-type: none"> Do not use outdoors. Doing so may cause deformation or severe degradation, resulting in injury.
--	---

CAUTION (Continued) Hazards that may result in injury or damage to the property

	<ul style="list-style-type: none"> Do not install in locations with high temperatures and humidity for a long time. Doing so may cause mould and mites to grow, leading to health hazards. Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation. Do not place objects only on the edges of the product. Doing so may cause the product to lose balance and fall.
	<ul style="list-style-type: none"> Wipe off immediately when disinfectant containing alcohol is spilled on the product. Avoid wiping excessively with alcohol disinfectant. Doing so may cause discolouration or deterioration of the surface. Use on a flat and stable surface. Otherwise it may cause product distortion or damage. Avoid exposure to direct sunlight and heat or air from heating and cooling appliances such as an air conditioner and a heater. Not doing so may cause warping, cracking and discolouration. If the product becomes wet/damp, wipe off and dry it before use. Not doing so may cause deterioration. Wear gloves during assembly of the product. This is to prevent unexpected injury.

Parts

(A) Right frame × 1

1 Tier 3 Tiers

(B) Left frame × 1

Left frame is slightly wider than the right frame.

Bolt Hole Bolt Hole

1 Tier 3 Tiers

(C) Shelf board

1 Tier × 1 3 Tiers × 3

Fitting Parts

(a) Bolt (Long) 	(b) Bolt (Short) 	(c) Wrench 	(d) Felt Pad
For 3 mm	20 × 10 × 2 mm		
1 Tier × 2 3 Tiers × 3	× 3 × 9	× 1 × 1	× 3 × 3

Assembly Instructions * Bamboo Corner Rack 3 Tiers is used in the illustrations.

1 Attach (A) right frame and (B) left frame.

Align the bolt holes on (A) right frame and (B) left frame, and loosely tighten (a) using (c).

Parts to be used

(A) Right Frame × 1	(a) Bolt (Long)
(B) Left Frame × 1	1 Tier × 2
	3 Tiers × 3

(c) Wrench

2 Attach (C) shelf boards to 1.

Align the bolt holes of 1 and (C) shelf boards, and loosely tighten (b) using (c).

After loosely tightening all the bolts, attach (d) to the bottoms and make sure there is no wobbling.

When the product is stable, slowly tighten all the bolts that were loosely tightened in 1 and 2.

Parts to be used

(C) Shelf Board	(b) Bolt (Short)
1 Tier × 1	1 Tier × 3
3 Tiers × 3	3 Tiers × 9

(d) Felt Pad × 3
(c) Wrench