

木製デスク Wooden Desk

組立・取扱説明書 User Guide

日本語

この度は本製品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 10.

木製デスク

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2～4
パーツリスト	5
各部の名称	5
組立方法	6～7
ご使用方法	7
お手入れ方法	8
ご使用に際して	8～9
製品仕様	9
お問い合わせ先	9

重要なお知らせ（安全上のご注意）

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び治療に入院、長期の通院を要するものをさします。

※2 傷害とは、治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。



警告



禁止

- 乳幼児を寝かさなideてください。床へ落下したり、窒息の原因となることがあります。
- 保護者の目の届かない場所で、お子さまだけで使用させないでください。思わぬケガの原因となります。
- 製品の上にのらないでください。バランスをくずして転倒したり、製品の破損によりケガをするおそれがあります。
- 不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。
- 製品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因となります。
- 引出しの上に腰掛けたり、ぶら下がったり、無理な力で引っ張ったりしないでください。転倒や破損、ケガをするおそれがあります。
- 引出しが複数ある場合、同時に開けないでください。バランスがくずれて倒れ、ケガをするおそれがあります。
- フィッティングパーツは幼児の手の届くところには置かないでください。また、なくさないでください。これらは小さく、誤飲してしまうと窒息などのおそれがあります。






注意



禁止

- 引出しを強く引っ張らないでください。破損したり、引出しが抜け落ちてケガをする原因となります。
- 耐荷重を超えて物をのせたり、耐荷重内でも一部に片寄ってのせたりしないでください。変形や破損の原因となり、ケガをするおそれがあります。
- 組み立てが不完全なまま使用しないでください。固定部分がはずれてケガの原因になることがあります。













⚠ 注意 (つづき)	
 禁止	<ul style="list-style-type: none"> ● 高温な場所、乾燥した場所で長期間設置しないでください。製品の反りやゆがみ、割れなどの原因になります。 ● 移動させる際は、製品を引きずらないでください。製品破損や床面へのキズ、ケガしたりするおそれがあります。 ● 指定の用途以外で使用しないでください。破損してケガをするおそれがあります。 ● フェルトを貼った後、凹凸や継ぎ目などの段差のある床面では使用しないでください。フェルトがはがれると、床面を汚したり、キズつけたりする原因となります。 ● 破損や変形した状態では使用しないでください。 ● 修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。 ● 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。 
 行う	<ul style="list-style-type: none"> ● 引出し開閉時、手や指が可動部や隙間に触れないようにしてください。指や手がはさまれて、ケガをするおそれがあります。 ● 使い始める時は、室内の換気を十分にしてください。接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状をおこすおそれがあります。 ● 壁から少し離して設置してください。空気の滞留や壁側の結露を防ぎ、カビの発生防止になります。また、壁に直接触れないことで、壁紙の変色防止にもなります。 ● 使用時は、脚底面にフェルトなどの保護材を貼ったり、敷物を敷いたりしてご使用ください。床へのキズ防止、また、クッションフロアなどの場合は木部の塗料とクッションフロアの反応による変色を防いでくれます。 ● 移動させる際は、収納物を取り除き、大人2人以上で移動させてください。1人で無理に移動させると、破損、ケガをするおそれがあります。 ● 各部にグラつきや破損がないか定期的に点検し、異常が認められたら使用を中止してください。そのまま使用すると、ケガや破損の原因となります。 ● 引出しの取りはずしや取り付けは、中の収納物を全て出してから行ってください。収納物が入ったまま取りはずそうとすると、破損したり、収納物が落下してケガをするおそれがあります。

お願い (その他 注意)	
	<ul style="list-style-type: none"> ● 平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になることがあります。 ● 直射日光や冷暖房器具などの熱や風が製品に直接当たらないようにしてください。反りやゆがみ、割れ、変色などの原因になります。 ● 暖房器具使用時は、室内温湿度を適正に保ってください。冬場などの暖房器具による室内の極端な乾燥は、天然木材の割れや反りの原因となります。 ● 製品に直接熱い物や濡れた物を置かないでください。反りやゆがみ、割れ、変色、カビなどの原因となります。 ● 飲食時は、ランチョンマットやコースターなどを敷いてお使いください。濡れた物、熱い物が置かれると、変形や変色の原因となります。 ● テーブルの上で筆記などの作業を行う時は、必ずマットなどを敷いてください。天板に凹みやキズがつく原因となります。


お願い（その他 注意）（つづき）

- 製品の上で陶器など底のざらついた物を直接置いて引きずらないでください。天板がキズがついたり、凹む原因となります。
- 突板や天然木の上にビニール製品（塩化ビニル樹脂など）を直接、長期間置かないでください。変色したり、塗装がはがれる原因となります。
- 長時間、化学雑巾を接触させたままにしないでください。変色したり、表面がはがれる原因となります。
- シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。変色や変形の原因となります。
- 廃棄の際は、居住地域の自治体のルールに従い、処分してください。

パーツリスト

<p>①天板×1</p> 	<p>②脚-①×2 (向かって左前 ／向かって右後)</p>  <p>①シール貼付有</p>	<p>③脚-②×2 (向かって右前 ／向かって左後)</p>  <p>②シール貼付有</p>	<p>④フック×2</p>  <p>※①に取り付けてあります</p>
<p>フィッティングパーツ</p>			
<p>⑤ワッシャー×8 (φ23mm)</p> 	<p>⑥スプリングワッシャー×8 (φ13mm)</p> 	<p>⑦ボルト×8 (5/16インチ×57mm)</p> 	<p>⑧ボルト×2 (1/4インチ×13mm)</p>  <p>※①に取り付けてあります</p>
<p>⑨ストッパー×2</p>  <p>※①に取り付けてあります</p>	<p>⑩フェルト×4 (30×30mm)</p> 	<p>⑪六角レンチ(大)×1 (5mm)</p> 	<p>⑫六角レンチ(小)×1 (4mm)</p> 

各部の名称



組立方法



注意




- ❶ 組み立ては、大人2人以上で行ってください。1人で作業すると、転倒や破損、ケガをしたり、床をキズつける原因となります。
- ❷ 組み立てには電動工具は使用しないでください。無理な負荷がかかると、製品破損によりケガをするおそれがあります。
- ❸ 組み立て後、1週間程度経過しましたら、ボルトを締め直してください。使い始めはゆるんでいる場合があり、そのまま使用すると破損やケガの原因となります。

脚の取り付け

1

引出しが飛び出さないよう押さえながら④天板を下にして置いてください。⑤脚の向きを【図1】【図2】を確認して合わせ、⑤脚を⑥ワッシャー、⑦スプリングワッシャー、⑧ボルトを使い④天板に取り付けます。⑨六角レンチ(大)でしっかり締め付けてください。脚は天板と隙間なく取り付けられていることを確かめてから⑤脚底面に付属の⑩フェルトを貼り付けます。その後に引出しの飛び出しに注意しながら、2人以上で静かに起こしてください。

【図1】⑤脚取り付け位置 (天板裏からの図)




お願い
(その他 注意)

脚の取り付け位置にご注意ください。

【図2】 ⑤脚取り付け位置の説明


※⑤脚の番号と取り付け位置をよく確認して配置し、下の右図のように取り付けてください。



(天板を裏にした状態の図)



正しい向き



組立方法（つづき）

フックの再取り付け方法／説明



2

※敷物を敷くなどして、床や既存の家具にキズがつかないように、注意して行ってください。


◎フックは出荷時に①天板に取り付けられています。フックがイラストのように外側になるように回転させ、再度④ボルトでしっかり締め付けてください。

（※用途に合わせ、フックの向きを内側に向けて取り付けることも可能です。）

【拡大図】



注意



◎ デスクを起す際は、一部の脚に片寄る過度な荷重は加えないでください。部材の破損の原因となり、ケガをするおそれがあります。

ご使用方法

●引出しの取りはずし方



※引出しを引き出し、内側上部に取り付けられている

◎ストッパーを回しながらはずしてください。



注意

❗ 指をはさまないようにご注意ください。



お手入れ方法

保守点検

- 各部にグラつきや破損がないか定期的に点検し、異常が認められたら使用を中止してください。そのまま使用すると、ケガや破損の原因となります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

木部のお手入れ

- 塗装面のほこりはやわらかい布または、はたきで軽く払ってください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。
- 長時間、化学雑巾を接触させたままにしないでください。変色したり、表面がはがれる原因となります。

金属部のお手入れ

- 毎日のお手入れはやわらかい布で乾きさせてください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。
- 金属部には、防錆潤滑油を薄く塗り、やわらかい布で軽くふき取ってください。

ご使用に際して

天然木について

- 本製品は天然木（突板）を使用しているため、製品ごとに天然木材特有の個体差（木目や色合いなど）がありますが、あらかじめご了承ください。
- 天然木（突板）は下記の条件により、割れや反りなどが発生することがありますので、ご注意ください。
 - ・直射日光の当たる場所でのご使用は出来る限りお避けください。どうしても直射日光が当たる場合は、カーテンなどで出来る限り避けてご使用ください。
 - ・冷暖房器具の近くでのご使用は出来る限り避け、必ず冷暖房の風が直接当たらないようにしてください。
 - ・特に冬の暖房による室内の極端な乾燥は、天然木の割れ、反りを発生させる原因となります。

ホルムアルデヒドの対策について

- ホルムアルデヒドとは
シックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

- お部屋の換気について



注意

- 家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をするようにご注意ください。換気効率をあげるため複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

ご使用に際して（つづき）

●化学物質に敏感な体質のお客さまへ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましても、ホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。

アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

●ホルムアルデヒド吸着・分解シートについて

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、無印良品の家具には、ホルムアルデヒド吸着・分解シートを同梱しています。

※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

製品仕様

品 名	木製デスク	
規 格	オーク材	
J A N	4550344873939	
製 品 寸 法	幅1100×奥行550×高さ700mm	
引出しの奥行	395mm	
製 品 質 量	約21 kg	
用 途	デスク	
耐 荷 重	天 板	約40 kg
	引出し	各約3 kg
	フック	各約3 kg
材 質	甲板の表面材：天然木（オーク材） 脚 部：天然木（オーク材） 引 出 し：前板 天然木（オーク材） 内箱 積層材 フ ッ ク：金属（鋼） 表 面 加 工：木 部 ウレタン樹脂塗装 フック ポリエステル樹脂粉体塗装	
原 産 国	中国	

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

〒170-8424

東京都豊島区東池袋 4-26-3

お客様相談室でんわ



0120-14-6404

Wooden Desk

User Guide

Thank you for your purchase.
Read this User Guide before use to ensure correct assembly and use of the product.
Please store this guide in an easily accessible place for future reference.



Table of Contents	Pages
Important Information (Safety Advice)	11 - 13
Parts	14
Part Names	14
Assembly Instructions	15 - 16
Directions for Use	16
Care Instructions	17
General Notes	17 - 18
Specifications	18
Contact Information	18

Important Information (Safety Advice)

The instructions must be followed.

This User Guide contains important information for safe use of the product in order to prevent harm to users and other individuals as well as damage to property.
Please note the following contents (indications and graphic symbols) before reading the main contents of this guide and follow the given instructions.



- **Explanations of Indications**
The extent of injury and damage that may arise when the product is used incorrectly is classified and explained with the following symbols.





 Warning Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury* ¹ to the user.	 Caution Indicates a hazard with a level of risk which, if not avoided, could result in injury* ² to the user or property damage* ³ .
---	--

- **Explanations of Graphic Symbols**
Instructions are given in the form of the following graphic symbols. (Examples of graphic symbols are as follows.)

 Actions that are prohibited.	 Actions that must be taken.
--	---

*1 "Serious injury" indicates injuries, such as blindness, traumas, burns, bone fractures, poisoning, or electric shocks, that have long-term effects and require hospitalisation and/or long-term hospital visits for treatment.
*2 "Injury" indicates traumas or burns that do not require hospitalisation or long-term hospital visits for treatment.
*3 "Property damage" indicates extended damage that involves the house or household property.





 Warning	
 DON'Ts	<ul style="list-style-type: none">• Do not lay small children on the product. Doing so may cause them to suffocate or fall on the floor.• Do not let children use without supervision. Doing so may result in unexpected injury.• Do not climb on the product. Doing so may cause tip-over from loss of balance or product damage and may lead to injury.• Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate.• Do not place on the power cord of an electrical appliance. Doing so may damage the cord, leading to electric shock or a fire.• Do not sit on or hang from the drawers, or pull them with excessive force. Doing so may cause tip-over, damage and/or injury.• Do not open multiple drawers at the same time. Doing so may cause the product to lose its balance and tip over, leading to injury.• Do not keep the fitting parts within reach of small children and be careful not to lose them. Children may accidentally swallow small parts and choke.









 Caution	
 DON'Ts	<ul style="list-style-type: none"> • Do not forcefully pull the drawers out. Doing so may cause the product to become damaged or the drawers to fall out and lead to injury. • Do not place anything exceeding the withstand load or anything only on one side even if it is within the withstand load. Doing so may cause product deformation or damage and lead to injury. • Do not use unless fully assembled. Doing so may cause the fixed parts to come off and lead to injury. • Do not place in locations with high temperatures or low humidity for a long time. Doing so may cause warping, distortion or cracking. • Do not drag to move the product. Doing so may cause product damage, floor scratches and/or injury. • Do not use for other than its intended purpose. Doing so may cause product damage and lead to injury. • Do not use the product on an uneven floor when felt pads are applied to it. Doing so may cause them to come off, leading to dirt or scratches on the floor surface. • Do not use if damaged or deformed. • Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury. • Do not use outdoors. Doing so may cause deformation or severe degradation, leading to injury. 
 DOs	<ul style="list-style-type: none"> • Do not touch the moving parts and gaps when opening/closing the drawers. Doing so may cause your hands or fingers to get caught and injured. • Ventilate the room well at the early stage of use. Formaldehyde contained in adhesive may still remain, and those with chemical sensitivity and small children may experience allergic reactions. • Install slightly away from the wall. This is to prevent air stagnation and condensation on the wall, and eventually mould growth. Avoiding direct contact with the wall also prevents discolouration of the wall paper. • Apply felt pads or any protective materials to the bottom of the legs, or use an underlay. This is to protect the floor from scratches and discolouration due to reaction between the coating on the wooden parts and the floor when the product is installed on a cushioned vinyl flooring. • When moving the product, remove all stored items and be sure to move it with at least two adults. Moving it alone may result in product damage and/or injury. • Regularly check for any looseness or damage in all parts, and stop use if any abnormalities are found. Continued use under this condition may cause injury or product damage. • Take out all the contents inside the drawers before installing into or removing from the desk. Not doing so may cause the drawers to become damaged or the contents to fall and lead to injury.

Note (Other Caution)


- Install on a flat and stable surface. Using on an unstable surface may cause product distortion or damage.
- Do not expose to direct sunlight and heat or air from heating and cooling appliances such as an air conditioner and a heater. Doing so may cause warping, distortion, cracking, or discolouration.
- Keep the room at an appropriate temperature and humidity level when using a heating appliance. Using heating appliances in winter may cause the room to become extremely dry, resulting in cracking or warping of natural wood.
- Do not place hot or wet items directly on the product. Doing so may cause warping, distortion, cracking, or discolouration.
- Lay place mats and coasters on the product when eating. Placing wet or hot items directly on the product may cause deformation or discolouration.
- Be sure to use a mat, etc. when writing or drawing on the desk. Not doing so may cause dents or scratches on the desktop.
- Do not place and drag items with rough bottom surfaces, such as ceramics, directly on the product. Doing so may cause scratches and dents on the desktop.
- Do not place plastic items (vinyl chloride resin, etc.) directly on veneer or natural wood for a long time. Doing so may cause discolouration or peeling of the coating.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.
- Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation.
- To dispose of the product, follow the rules implemented by your local government.

Parts

<p>Ⓐ Desktop × 1</p>  <p>Drawer</p> <p>(Underside)</p>	<p>Ⓑ Leg-① × 2 (For the front left / back right when facing the desk)</p>  <p>① Sticker attached</p> <div>①</div>	<p>Ⓑ Leg-② × 2 (For the front right / back left when facing the desk)</p>  <p>② Sticker attached</p> <div>②</div>	<p>Ⓒ Hook × 2</p>  <p>* Pre-attached to Ⓐ</p>
---	--	---	--

Fitting Parts			
<p>Ⓐ Washer × 8 (φ23 mm)</p> 	<p>Ⓑ Spring Washer × 8 (φ13 mm)</p> 	<p>Ⓒ Bolt × 8 (5/16 inch × 57 mm)</p> 	<p>Ⓓ Bolt × 2 (1/4 inch × 13 mm)</p>  <p>* Pre-attached to Ⓐ</p>
<p>Ⓔ Stopper × 2</p>  <p>* Pre-attached to Ⓐ</p>	<p>Ⓕ Felt Pad × 4 (30 × 30 mm)</p> 	<p>Ⓖ Hexagonal Wrench (L) × 1 (5 mm)</p> 	<p>Ⓖ Hexagonal Wrench (S) × 1 (4 mm)</p> 


Part Names






Attaching the Legs

[Fig. 1] Positions of \otimes legs



Note (Other Caution)	Be sure to attach the legs to the correct positions.
--------------------------------	--

[Fig. 2] Positions of (B) Legs



Assembly Instructions (Continued)

Reattaching the Hooks


2

*** Place an underlay to protect the floor and other furniture from scratches.**


© Hooks are pre-attached to ① desktop. Rotate the hook as shown in the figure so that its tip faces outwards. Firmly fix with a ② bolt.

(* The hooks can also be attached facing inwards according to the purpose of use.)

[Enlarged Figure]



Caution



⊘ Do not put excessive load only on one side (of the legs) when turning the desk upright. Doing so may damage the parts and lead to injury.



Directions for Use

• Removing the Drawers

*** Pull out the drawer and rotate the stopper on the reverse side of the top board to remove it.**

Caution

⚠ Be careful not to get your fingers caught.



Care Instructions

Maintenance and Inspection

- Regularly check for any looseness or damage in all parts, and stop use if any abnormalities are found. Continued use under this condition may cause injury or product damage.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Maintenance for Wooden Parts

- Gently wipe off dust from coated surfaces using a soft cloth or duster.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.

Maintenance for Metal Parts

- For regular cleaning, wipe with a soft, dry cloth.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.
- Apply a thin coating of anti-rust lubricant to metal parts, and lightly wipe the excess off with a soft cloth.

General Notes

Care Tips for Natural Wood Products

- As this product is manufactured using natural wood (veneer), there are individual differences (grain, colour, etc.) unique to natural wood.
- Cracking and warping may occur in natural wood (veneer) under the following conditions.
 - Avoid use at locations exposed to direct sunlight. If exposure to direct sunlight is unavoidable, use curtains, etc. to reduce the amount of sunlight.
 - Avoid use near heaters or air conditioners and make sure that the air from heater or air conditioner does not come into direct contact with the product.
 - In particular, use of heating appliances during winter causes the room to become extremely dry and may lead to cracking or warping of natural wood.

Formaldehyde Countermeasures

- What is Formaldehyde?

Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent-smelling chemical often found in furniture, building materials, wallpaper adhesives, etc. that vaporises at room temperature. As it is gradually released into the air, spending a long time in a room contaminated with formaldehyde can result in eye and throat irritation. Also, exposure to a high concentration of formaldehyde may cause breathing difficulties.
- Room Ventilation



❗ Ventilate the room well when installing the furniture. Some individuals sensitive to chemicals and small children may experience allergic symptoms.

Be sure to frequently ventilate the room regularly as formaldehyde is easily released into the air. Especially when multiple pieces of furniture are installed at the same time, open the windows wide enough to allow adequate ventilation. Formaldehyde emission tends to increase with temperature rise of the room. Therefore, be sure to ventilate thoroughly after the room has been closed up for a long time during summer. It is recommended that you open multiple windows and use a ventilation fan or an air circulator to increase ventilation efficiency.

General Notes (Continued)

- For Individuals Sensitive to Chemicals

There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even if the actual concentration in the room is equal to or lower than the indoor concentration guideline value (acceptable safe level of formaldehyde indoors), some people may react to formaldehyde. MUJI furniture are made with materials that contain as little formaldehyde as possible, but note this does not guarantee that no formaldehyde is emitted. It is recommended that you seek medical attention if you experience any allergic symptoms.

- Formaldehyde Adsorption/Decomposition Sheet

Formaldehyde is readsorbed onto materials when there is nowhere for it to dissipate in a confined space. Therefore, a formaldehyde adsorption/decomposition sheet is included in the packaging to reduce formaldehyde concentration as much as possible before the product reaches the customer.

* The effect of the sheet will be diminished by the time the product reaches the customer. Dispose of the sheet as burnable waste after unpackaging.

Specifications

Product Name	Wooden Desk	
Specification	Oak	
JAN	4550344873939	
Product Dimension	W1100 × D550 × H700 mm	
Drawer Depth	395 mm	
Product Weight	Approx. 21 kg	
Usage	Desk	
Withstand Load	Top Board	Approx. 40 kg
	Drawer	Approx. 3 kg each
	Hook	Approx. 3 kg each
Material	Top Board Surface Material : Natural Wood (Oak) Leg : Natural Wood (Oak) Drawer : Front Board Natural Wood (Oak) Inner Box Laminated Wood Hook : Metal (Steel) Surface Finish : Wooden Part Urethane Resin Coating Hook Polyester Resin Powder Coating	
Place of Origin	CHINA	

Contact Information

For enquiries regarding the product, please contact the store of purchase.