4550512841098

[A]Wooden Round Chair

Retain for Future Reference

User Guide

Thank you for your purchase.

Read this User Guide before use to ensure correct assembly and use of the product.

Store this guide in an easily accessible place for future reference.

<u>/!\</u>

0

WARNING

Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury to the user.



Indicates a hazard with a level of risk which, if not avoided, could result in injury or damage to house or household property.

MARNING Hazards that may lead to death or serious injury

- Do not lay small children on the product. Doing so may cause an unexpected accident, such as suffocation or falling on the floor.
- Do not let children use without supervision.
- Do not allow anyone to sit on any part other than the seat. Doing so may cause injury.
- Do not stand or jump on the product or use it as a step stool. Doing so may cause you to lose balance and fall or the product to tip over and become damaged, resulting in injury.
- Do not sit near the edge of the seat. Doing so may cause injury.
- Do not place near a heat source such as a heater. Doing so may cause a fire.
- Do not drop lit cigarettes, etc. onto the product. Doing so may cause a fire.
- Do not use in an unstable state or location. Doing so may result in injury due to tip-over.
- Do not place the product on the power cord of an electrical appliance.
 Doing so may damage the cord, leading to electric shock or a fire.
- Do not allow more than one person to use the product at the same time. Doing so may cause tip-over or damage, resulting in injury.
- Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate.
- Do not use outdoors. Doing so may cause deformation or severe degradation, resulting in injury.


! CAUTION Hazards that may result in injury or damage to the property

- Do not install in locations with high temperatures and humidity for a long time. Doing so may cause discolouration or infestation of mould and mites, resulting in health hazards.
- Do not use for other than its intended purpose. Doing so may cause an unexpected accident and/or injury.
- Do not use if damaged or deformed. Doing so may result in an unexpected injury.
- Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury.
- Do not move the product while sitting on it. Doing so may cause product damage and/or floor scratches.
- Do not expose to direct sunlight or lighting, or heat or air from heating and cooling appliances such as air conditioner and heater. Doing so may cause warping, distortion, cracks or deformation, resulting in injury.
- Do not use the product on an uneven floor when felt pads are applied to it. Doing so may cause them to come off, leading to dirt or scratches on the floor surface.

Note (Other Caution)


- Ventilate the room well at the early stage of use. Wooden materials that emit as little formaldehyde as possible are used. However, formaldehyde may still remain, and those with chemical sensitivity or small children may experience allergic reactions.
- Formaldehyde Adsorption/Decomposition Sheet
 Formaldehyde is re-adsorbed onto materials when there is nowhere for it to dissipate in a confined space. Therefore, a formaldehyde adsorption/decomposition sheet is included in the packaging to reduce formaldehyde concentration as much as possible before the product reaches the customer.
- * The effect of the sheet will be diminished by the time the product reaches the customer. Dispose of the sheet as burnable waste after unpackaging.

Completion Image




Part

 \oslash



Direction for Use



Attach the provided (A) to the bottom of each leg before start of use. The pads can be used for protecting the floor from becoming scratched, and adjusting the height of a leg to prevent wobbling.

Contact Information