

ゆったり座れる
アームレスソファ用
オットマン

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

2024年12月11日

お手入れ方法

保守・点検

- 各部にゆるみがないか定期的に点検し、ゆるみははじめたらしっかり締め直してください。ゆるんだまま使用すると、ケガや破損のおそれがあります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

木部のお手入れ

- 塗装面のほこりはやわらかい布または、はたきで軽く払ってください。
- 汚れのひどい時は、3～5%に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。

生地のお手入れ

- 部分的に側生地が汚れた場合は、中性洗剤でつまみ洗いをしてください。
- カバーの洗濯方法については、カバーの品質表示ラベルに従い、正しくお取り扱いください。

製品仕様

品名	ゆったり座れるアームレスソファ用 オットマン ポリエステル平織		
	ブラウン	グレー	ベージュ
J A N	4550584391675	4550584391682	4550584391699
製品寸法	約幅625 ×奥行485 ×高さ370 mm		
座面の高さ	約370 mm		
製品重量	約7.4 kg		
用途	オットマン(足のせ用)・1人用		
材質	構造部材 表面材：天然木（ラバーウッド材） 座面：積層材 木脚・座フレーム：天然木（ラバーウッド材） 表面加工 側生地クッション：ポリエステル100% 張り材 クッションカバー：ポリエステル100% クッション材 座クッション：ウレタンフォーム、ポリエステルわた		
原産国	ベトナム		

ご使用方法

移動について

- 移動させる際は、製品を引きずらないでください。製品破損や床面へのキズ、ケガしたりするおそれがあります。

廃棄について

- 廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ

0120-14-6404

重要なお知らせ(安全上のご注意)

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

⊘ してはいけない「禁止」の内容です。

❗ 実行しなければならない内容です。

⚠ 警告 死亡や重傷などに結びつくおそれがあるもの

- 不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。
- 製品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因となります。
- 乳幼児を寝かさなでください。床へ落下したり、窒息したりする原因となります。
- 保護者の目の届かない場所で、お子さまだけで使用させないでください。思わぬケガの原因となります。
- 指定の用途以外で使用しないでください。破損してケガをするおそれがあります。
- 座りながら製品を傾けたり、不安定な体勢で使用したりしないでください。転倒や破損、床をキズつける、ケガの原因となります。
- 製品の上に立たないでください。バランスをくずして転倒する、製品の破損によりケガをするおそれがあります。
- 破損や変形した状態では使用しないでください。製品の強度が弱くなりケガをするおそれがあります。
- 修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。
- 座面に浅く腰掛けしないでください。転倒や破損、ケガをするおそれがあります。

⚠ 注意 傷害を負う可能性や物的損害が生じるおそれがあるもの


- ⊘ 禁止 ●高温多湿な場所に長期間設置しないでください。カビやダニなどが発生し、健康を害することがあります。
- ❗ 行う ●使い始めは室内の換気を十分に行ってください。製品に微量にホルムアルデヒドが含まれることがあります。敏感な方や乳児などはアレルギー症状を起こすおそれがあります。
- 直射日光を避け、冷暖房具の熱や風に当たらないようにしてください。反り、割れ、変色の原因になります。

お願い(その他 注意)


- 平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になることがあります。
- シンナーなどの有機溶剤や漂白剤などの薬剤で手入れしないでください。変色や変形の原因となります。
- 長時間、化学雑巾を接触させたままにしないでください。変色や表面がはがれる原因となります。
- フェルトを貼った脚は、凹凸や継ぎ目などの段差のある床面では使用しないでください。フェルトがはがれると、床面を汚したり、キズつけたりする原因となります。
- 組み立ての際は、手袋などをつけて作業してください。思わぬケガの防止になります。

パーツリスト


① 座面 × 1



② 座クッション × 1



③ 座クッションカバー × 1



※クッションに装着済です。

④ 丸脚 × 4




※無印良品の木製脚12 cm、20 cm、26 cmは取り付けられません。
脚底面にフェルト貼り済です。

組立方法


⚠ 注意

- ❗ 組み立て時は、組み立てに必要なスペースを十分に確保し、敷物を敷いてください。床や既存の家具のキズ防止になります。

1 ① 座面に④脚を取り付けます。




2 1をひっくり返して③座クッションカバーを装着した②座クッションを設置したら完成です。



完成

カバーの装着方法

1 ③座クッションカバーのファスナーを開き、下図のように②座クッションを少し曲げるようにして入れてファスナーを閉めてください。



2 最後にクッション全体の形を整えてください。

3 組立方法を確認し、再度設置してください。

Spacious Armless Sofa Ottoman

User Guide

User Guide
Thank you for your purchase.
Read this User Guide before use to ensure correct assembly and use of the product.
Store this guide in an easily accessible place for future reference.

11 December 2024

Contact Information

For enquiries regarding the product, please contact the store of purchase.

Specifications

Product Name	Spacious Armless sofa Ottoman Polyester plain weave		
	Brown	Grey	Beige
JAN	4550584391675	4550584391682	4550584391699
Product Dimensions	Approx. W625 × D485 × H370 mm		
Seat Height	Approx. 370 mm		
Product Weight	Approx. 7.4 kg		
Usage	Ottoman (footstool) for 1 person		
Materials	Structural Element	Surface : Natural Wood (Rubberwood)	
		Seat Base : Laminated Wood	
		Wooden Leg, Seat Frame : Natural Wood (Rubberwood)	
	Surface Finish	Urethane Resin Coating	
	Covering Material	Cushion Outer Shell : 100% Polyester	
Cushioning Material		Cushion Cover : 100% Polyester	
		Seat Cushion : Urethane Foam, Polyester Filling	
Place of Origin	VIETNAM		

Directions for Use

Moving the Product

- Do not drag to move the product. Doing so may cause product damage, floor scratches and/or injury.

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Care Instructions

Maintenance and Inspections

- Regularly check for any looseness in all parts, and retighten them if looseness is found. Continued use in this state may result in injury or damage.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Maintenance of Wooden Parts

- Gently wipe off dust from coated surfaces using a soft cloth or duster.
- If the product is heavily soiled, clean it with a cloth soaked in 3-5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a dry cloth and let the product dry naturally.

Maintenance of Fabric

- If the outer shell is partially stained, spot-treat the stain with neutral detergent.
- When washing the cover, follow the wash-care label on the cover and handle it properly.

Important Information (Safety Advice)

The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.



Actions that are prohibited.



Actions that must be taken.

⚠ WARNING Hazards that may lead to death or serious injury



DON'Ts

- Do not leave unnecessary packaging materials within reach of small children. They may accidentally pull them over their heads, cover their mouths and/or noses and suffocate.
- Do not place on the power cord of an electrical appliance. Doing so may damage the cord, leading to electric shock or a fire.
- Do not lay small children on the product. Doing so may cause them to suffocate or fall on the floor.
- Do not let children use without supervision. Doing so may cause unexpected injury.
- Do not use for other than its intended purpose. Doing so may cause damage, resulting in injury.
- Do not use in an unstable state, such as tilting the product while sitting on it. Doing so may cause tip-over, damage, floor scratches and/or injury.
- Do not stand on the product. Doing so may cause you to lose your balance and fall, or the product to become unstable and fall over or become damaged, leading to injury.
- Do not use if damaged or deformed. Doing so reduces the strength of the product and may lead to injury.
- Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury.
- Do not sit near the edge of the seat. Doing so may cause tip-over, damage and/or injury.

⚠ CAUTION Hazards that may result in injury or damage to the property



DON'Ts

- Do not install in locations with high temperatures and humidity for a long time. Doing so may cause mould and mites to grow, leading to health hazards.



DOs

- Ventilate the room well at the early stage of use. The product may contain a small amount of Formaldehyde, and those with chemical sensitivities or small children may experience allergic reactions.
- Avoid exposure to direct sunlight and heat or air from heating and cooling appliances such as an air conditioner and a heater. Not doing so may cause warping, cracking and discolouration.

Note (Other Caution)

- Use the product on a flat and stable surface. Otherwise, it may cause distortion or damage.
- Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.
- Do not use on an uneven floor when felt pads are attached to the legs. Doing so may cause them to come off, leading to dirt or scratches on the floor surface.
- Wear gloves during assembly of the product. Doing so prevents unexpected injury.


Assembly Instructions




CAUTION

- Secure enough space and place an underlay when assembling the product. This prevents the floor and other furniture from scratches.

- 1
- Attach ④ round legs to ① seat base.




- 2
- Turn 1 over, and install ② seat cushion with ③ seat cushion cover on. Then the assembly is complete.




Completed

Parts


① Seat Base × 1



② Seat Cushion × 1



③ Seat Cushion Cover × 1



* Already put on the cushion


④ Round Leg × 4



* Cannot attach MUJI's Wooden Legs 12 cm, 20 cm and 26 cm. A felt pad is pre-attached.

Putting the Cover on

- 1
- Open the fastener of ③ seat cushion cover. Slightly bend and insert ② seat cushion into the cover as shown in the illustration below, then close the fastener.



- 2
- Reshape the cushion.

- 3
- Referring to Assembly Instructions, reinstall the cushion on the seat base.