MUJI OTTOMAN for HIGH-BACK RECLINING SOFA Instruction for Use

Thank you very much for purchasing this product.

To ensure you can use this product safely for a long time, please carefully read and follow the Instruction for Use.

Please keep this sheet and the included washing tapes in a safe place for future use.

[Safety Advice]

This Safety Advice aims to ensure that our product is safely assembled to use for a longer period of time, and to prevent any injury or damage. Depending on the content, advice is classified into a [Warning] or [Caution]. Symbols and meanings are as follows:

Marning	Failure to follow the indicated guidelines could result in serious injury or death.
Caution	Failure to follow the indicated guidelines could result in injury and/or damage to property.

[Precautions before Use]

M Warning

After unpacking, immediately dispose of unnecessary packing materials; keep them out of the reach of children.

Caution

• When replacing the cover, to protect the floor from damage, work on a carpet or protective covering.
• After unpacking, check all parts are present and correct; if any parts are missing or defective, immediately stop assembly and contact the store where you purchased the product.

[Precautions for Use]



Only use the ottoman with the wooden legs fitted.

Caution Failure to do so may cause damage or the ottoman to break.



Do not drag the ottoman.



This may damage the floor or ottoman.

Warning

Do not stand on the ottoman as it is extremely dangerous.



This may cause serious injury or damage.

Marning

Do not sit on the edge of the ottoman as it is extremely dangerous.



This may cause serious injury or damage.


№ Warning

This product is designed for one person only. Never have two or more people sit on the ottoman as it is extremely dangerous.




This may cause serious injury or damage.


[Precautions before Use]



[Maintenance]

■ How to remove/fit the cover





■ How to clean

The removable cushion cover can be dry-cleaned.

* Dry cleaning may shrink the cover slightly.

The washing tape is designed to prevent catching or scratching of the main unit fabric when removing the cover for cleaning or refitting the cover.

Feather cushioning is used inside the ottoman. Please note that this cushion cannot be removed.

Precautions for handling the feather cushion section

♦ The feathers have been cleaned to the highest standards, but feathers smell may still linger. Particularly, in humid weather, feathers may smell on rare occasions. Dry the main unit in a shady and airy place; then plump up the cushion to change the inner air with fresh air, and dry again for 3 to 4 hours in the sun.

♦ The filling of the feather cushion tends to lump in one corner.

To maintain the cushion shape, regularly plump up the cushion and fluff up the feathers inside.