

Read Carefully Before Assembling

- Please assemble with more than 2 people.
- Please assemble in adequate space. Use a rug to protect floor from damage
- Do not drag this product when you move it, as it may cause damage to the floor and injury.
- Use an appropriate-sized screw driver for each screw.
- Although screws should be tightened for better results, over-tightening them may result in cracks.


PARTS

(1) Long Side Board (Caster Side) × 1 * Groove on the back	(2) Long Side Board (Handle Side) × 1 * Groove on the back	(3) Short Side Board (Caster Side) × 1 * Groove on the back	(4) Short Side Board (Handle Side) × 1 * Groove on the back	(5) Middle Board × 1 * Groove on both sides	(6) Shelf Board × 3
(7) Back Board × 2 	(8) Screws (Wood) × 12 	(9) Screws (Handle) × 2 	(10) Handle × 1 	(11) Hanger × 6 	(12) Casters × 5
				(13) Caster Guides × 5 	(14) Cover Seals × 14


Have a Philips Screwdriver ready at hand.



- 1** When the shelf comes on the left side of the handles
Use (8) Wooden Screws to attach (3) Short Side Board (Caster Side) to (1) Long Side Board (Caster Side), and (4) Short Side board (Handle Side) to (5) Middle Board.




- When the shelf comes on the right side of the handles
Use (8) Wooden Screws to attach (3) Short Side Board (Caster Side) to (1) Long Side Board (Caster Side), and (4) Short Side board (Handle Side) to (5) Middle Board.



The grooves on the Long and Short Side Boards should match

- 2** Raise the main body built in (1) and slide (7) Back Board along the grooves of (3) Short Side Board (Caster Side), (4) Short Side Board (Handle Side), and (5) Middle Board.




- 3** Attach (2) Long Side Board (Caster Side) with (8) Screws (Wood).
Before completely tightening the screws, make sure that the back boards fit into the groove of the side board, as illustrated in Diagram 1.




Diagram 1

- 4** Bring (1) Long Side Board (Caster Side) to the top, and attach (13) Caster Guides.
Use thick magazines to push down the caster guides if there is any difficulty, but be careful not to get any finger caught.

The caster guides cannot be removed once they are attached, so please reconfirm whether the shelf is vertical or horizontal.




- 5** Insert (12) Casters to the holes in the caster guides.
Then flip over the shelf so that the casters come on the bottom.



- 6** Attach (10) Handle using (9) Screws (Handle).


The diagram is for left-side shelf



- 7** Attach (11) hangers to your desired places, and slide the (6) shelf boards along the grooves.

There is a limit to the number of hangers when building the shelf for vertical use

Caution: Putting pressure on the shelf boards from the top or bottom may result in damage.



Cover the unused caster holes, handle holes with (14) caster seals. Store any unused caster seals safely.

Caution: Do not move the product with objects on the top board. This can cause objects to fall off the board, resulting in damage or injury.

Caution

When using with a cardboard drawer for Polybox Box A4 size

- When pulling the drawer out, do so gently to avoid it from falling out onto the floor.
- In cases when heavy objects are inside, putting pressure from the top while the object is stuck on the top board may cause the product to fall over.



Load Capacity Middle Board 33.07 lbs
Shelf Board 17.64 lbs
Whole Shelf 44.09 lbs



Finished Product (Left Side Shelf)

Read Carefully Before Assembly

- Please assemble with more than 2 people.
- Please assemble in adequate space. Use a rug to protect floor from damage
- Do not drag this product when you move it, as it may cause damage to the floor and injury.
- Use an appropriate-sized screw driver for each screw.
- Although screws should be tightened for better results, over-tightening them may result in cracks.


PARTS

(1) Long Side Board (Caster Side) × 1	(2) Long Side Board (Handle Side) × 1	(3) Short Side Board (Caster Side) × 1	(4) Short Side Board (Handle Side) × 1	(5) Middle Board × 1	(6) Shelf Board × 3
* Groove on the back	* Groove on the back	* Groove on the back	* Groove on the back	* Groove on both sides	
(7) Back Board × 2	(8) Screws (Wood) × 12	(9) Screws (Handle) × 2	(10) Handle × 1	(11) Hanger × 6	(12) Casters × 5
				(13) Caster Guides × 5	(14) Cover Seals × 14

Have a Philips Screwdriver ready at hand.




- 1** • When the shelf comes on the left side of the handles
Use (8) Wooden Screws to attach (3) Short Side Board (Caster Side) to (1) Long Side Board (Caster Side), and (4) Short Side board (Handle Side) to (5) Middle Board.




The grooves on the Long and Short Side Boards should match

- When the shelf comes on the right side of the handles
Use (8) Wooden Screws to attach (3) Short Side Board (Caster Side) to (1) Long Side Board (Caster Side), and (4) Short Side board (Handle Side) to (5) Middle Board.



- 2** Raise the main body built up(1), and slide (7) Back Board along the grooves of (3) Short Side Board (Caster Side), (4) Short Side Board (Handle Side), and (5) Middle Board.



- 3** Attach (2) Long Side Board (Caster Side) with (8) Screws (Wood).
• Before completely tightening the screws, make sure that the back boards fit into the groove of the side board, as illustrated in Diagram 1.






Diagram 1

- 4** Bring (3) Short Side Board (Caster Side) to the top, and attach (13) Caster Guides.
• Use thick magazines to push down the caster guides if there is any difficulty, but be careful not to get any finger caught.

• The caster guides cannot be removed once they are attached, so please reconfirm whether the shelf is vertical or horizontal.



- 6** Attach (10) Handle using (9) Screws (Handle).




The diagram is for left-side shelf

- 7** Attach (11) hangers to your desired places places, and slide the (6) shelf boards along the grooves.

There is a limit to the number of hangers when building the shelf for vertical use

Caution: Please attach at least one shelf board for better stability



Cover the unused caster holes, handle holes with (14) caster seals. Store any unused caster seals safely.

Caution: Do not move the product with objects on the top board.

This can cause objects to fall off the board, resulting in damage or injury.

- 5** Insert (12) Casters to the holes in the caster guides.

Then flip over the shelf so that the casters come on the bottom.




Caution

When using with a cardboard drawer for Pulpboard Box A size

- When pulling the drawer out, do so gently to avoid it from falling out onto the floor.
- In cases when heavy objects are inside, putting pressure from the top while the object is stuck on the top board may cause the product to fall over.



Load Capacity Middle Board 33.07 lbs
Whole Shelf 44.09 lbs



Finished Product (Left Side Shelf)