

<表>



取扱説明書 粉もの保存容器

4550002526849 実容量 660 mL
4550002526832 実容量 710 mL
4550002526825 実容量 1.5 L
4550002526818 実容量 2.2 L

○この取扱説明書をよくお読みいただき、正しくご使用ください。
また、すぐに取り出せるところに大切に保管し、必要なときにお読みください。

取扱上の注意

本紙では、誤った取扱いによる事故を未然に防ぐための注意事項を、マークをつけて表示しています。
マークの意味は以下の通りです。

●実行しなければならない内容です。

○してはいけない内容です。

△注意 軽傷を負うおそれ、または製品が故障することが想定される内容を示しています。

●ご使用前

○洗浄の際、研磨剤入りのスポンジ、金属たわし、クレンザー等は使用しないでください。
表面をキズつけ本品が破損するおそれがあります。

●ご使用時

○コンロやストーブなど、火や熱源のそばに置かないでください。
●持ち運びの際は必ず本体をお持ちください。蓋と本体が外れて中身がこぼれるおそれがあります。
○本品に細かいキズや割れ等を発見した場合は使用しないでください。破損するおそれがあります。
○電子レンジは使用できません。本品が破損するおそれがあります。
○強い衝撃を与えないでください。破損するおそれがあります。
○食器洗い乾燥機は使用できません。熱による変形、ひび割れ、白濁または変色のおそれがあります。

●ご使用後

○直射日光を避けて保管してください。変色等の原因になります。
●汚れがひどい場合は、塩素系または酸素系の漂白剤を薄めたぬるま湯に浸してください。
漂白剤を使用する際は漂白剤に記載されている用法、用量を守りご使用ください。
○本品を煮沸しないでください。熱による変形、ひび割れ、白濁または変色のおそれがあります。
○シンナー、ベンジン、アルコール、灯油などは使用しないでください。破損するおそれがあります。
●ニオイや色の強い食品等と一緒にご使用になりますと、ニオイ移り色移りのおそれがあります。

各部名称



ご使用方法

- ご使用前に水やぬるま湯で洗浄してください。
- 洗浄する際は、柔らかいスポンジに薄めた中性洗剤で洗浄してください。
- 洗浄後は柔らかい布で水滴を拭き取ってください。
- 液体は入れないでください。漏れるおそれがあります。

本品の廃棄について

○廃棄方法は自治体の定める方法に従って処理してください。

品質表示			
部品	本体	蓋	
		外周部	中央部
原料樹脂	ポリプロピレン	ポリスチレン 熱可塑性エラストマー	ポリプロピレン
耐熱温度	90 °C	70 °C	
耐冷温度		-20 °C	
実容量	660 mL	710 mL	1.5 L
			2.2 L
日本製			

お問い合わせ先
株式会社 良品計画 www.muji.com
お客様相談室でんわ 0120-14-6404
ver.202311

ver.202311

MUJI 無印良品



使用説明書 干貨保存容器

4550002526849 660 mL
4550002526832 710 mL
4550002526825 1.5 L
4550002526818 2.2 L

○请在充分阅读本使用说明书的基础上再正确使用。
另外，请将说明书存放于随时可以取出的场所，以备必要时再次阅读。

使用注意事項

为了预防错误使用所造成的事故，将注意事项标注记号进行说明。

各标记的含义如下。

●必须执行的“强制”内容。

○不可执行的“禁止”内容。

△注意 表示可能导致轻伤或产品损坏的内容。

●使用前

○清洗时，请勿使用含研磨剂的海绵、金属刷帚、去污剂等。

否则可能造成表面损伤或产品损坏。

●使用时

○请勿放在炉灶、火炉等火源及热源附近。

●搬运时请务必手持本体。否则盖子和本体可能会脱落而导致内容物掉出。

○若产品发现细小伤痕或裂损等请勿使用。否则可能导致产品损坏。

○请勿用于微波炉。否则可能造成产品损坏。

○请勿施加强烈冲击。否则可能导致产品损坏。

○请勿用于洗碗机。否则可能由于受热导致变形、开裂、发白或变色。

●使用后

●保存时请注意避免直射阳光，否则可能导致变色等。

●污垢严重时，请用稀释氯系或氧系漂白剂的温水浸泡。


使用漂白剂时，请务必遵守漂白剂产品上指定的用法、用量。

○请勿煮沸本产品。否则可能由于受热导致变形、开裂、发白或变色。

○请勿使用稀释剂、汽油、酒精、煤油等。否则可能导致产品损坏。

●若与气味及颜色较重的食品一同使用，可能会异味及颜色转移。

各部位名称



使用方法

- 使用前请用冷水或温水清洗。
- 清洗时，请使用软质海绵加水稀释中性洗涤剂进行清洗。
- 清洗后，请用软布擦去水珠。
- 请勿存放液体。否则可能会漏出。

关于本产品的废弃

○废弃时，请根据所在地区规定的方式进行处理。

品質表示			
部件	主体	蓋	
		外周部分	中间部分
原料树脂	聚丙烯	聚苯乙烯 热塑性弹性体	聚丙烯
耐热温度	90 °C	70 °C	
耐冷温度		-20 °C	
容量	660 mL	710 mL	1.5 L
			2.2 L
日本制造			

联系方式
委托生产商：株式会社良品计画
经销商：无印良品（上海）商业有限公司
地址：上海市静安区南京西路1601号35楼
3501-3508室（邮编200040）
www.muji.com
执行标准：GB/T 32094-2015
GB 4806.7-2023
ver.202311

User Guide Flour storage container

MUJI 無印良品

4550002526849 Approx. 660 mL
4550002526832 Approx. 710 mL
4550002526825 Approx. 1.5 L
4550002526818 Approx. 2.2 L

Approx. 660 mL Approx. 710 mL Approx. 1.5 L Approx. 2.2 L

○Read this User Guide before using this product to ensure correct use of the product.
Store this guide in an easily accessible location for future reference.

Precautions for Use

The following symbols indicate possible dangers associated with misuse of this product.
The following are the symbols and their meanings.

- Actions that must be taken
○ Actions that are prohibited

△ Caution Misuse of this product contrary to these instructions may result in physical injury or damage to the product.

● Before use

○ Do not use an abrasive scouring pad, wire wool or cream cleanser to wash.
Doing so may cause scratches on the surface leading to damage of the product.


● When in use

○ Do not place near open flame or a heat source such as kitchen stove or room heater.
● Make sure to carry by holding the container. The container and lid may detach, and cause the contents to leak.
○ Do not use if there are scratches or cracks. Doing so may cause damage to the product.
○ Do not use in a microwave. Doing so may cause the product to become damaged.
○ Do not subject to strong shock. Doing so may damage the product.
○ Do not wash in a dishwasher. Doing so may cause deformation, cracks, cloudiness and/or discoloration.

● After use

● Store away from direct sunlight. Not doing so may cause discoloration.
● When the container is heavily stained, soak it in a chlorine-based bleach or a peroxide bleach diluted with lukewarm water. When using a bleach, follow the method and the quantity indicated on the product.
○ Do not boil the container. Doing so may cause deformation, cracks, cloudiness and/or discoloration.
○ Do not use thinner, benzene, alcohol or paraffin. Doing so may cause damage to the product.
● Use with strong-smelling or deeply coloured foodstuffs may result in the transfer of odours or colours.

Part Names



Directions for use

- Wash with water or lukewarm water before use.
- Wash the container with a soft sponge and a diluted neutral detergent.
- Wipe off water droplets with a soft cloth after wash.
- Do not put in liquids. It may leak from the container.

Disposal

○ Dispose of this product in accordance with the regulations of your local government.

Specifications			
PARTS	BODY	LID	
		SEAL	CENTRE
RAW RESIN	POLYPROPYLENE (UK)OLEFIN(US)	POLYSTYRENE THERMOPLASTIC ELASTOMER	POLYPROPYLENE (UK)OLEFIN(US)
HEAT-RESISTANT TEMPERATURE	90 °C	70 °C	
COLD-RESISTANT TEMPERATURE		-20 °C	
Capacity	Approx. 660 mL	Approx. 710 mL	Approx. 1.5 L
			Approx. 2.2 L
MADE IN JAPAN			

Contact Information

Please contact the store of purchase.

ver.202311