

ソファ本体
木製フレーム用カバー

フェザーポケットコイル用
ウレタンポケットコイル用

取扱説明書

この度は本商品をお買い上げいただき、誠にありがとうございます。ご使用前に本書をよくお読みいただき、内容を理解した上で正しくお使いください。また、本書はいつでも確認できるように大切に保管してください。

2020 年 12 月 25 日

製品仕様

品 名	ソファ本体 木製フレーム用 カバー
製品仕様	カバー 品質表示ラベルに記載
用 途	ソファ本体 木製フレーム用 カバー
原 産 国	ベトナム

ご使用方法

廃棄について

●廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お手入れ方法

●ソファ本体 木製フレーム（別売り）に付属の組立・取扱説明書及びカバーに縫いつけの品質表示ラベルを参照してください。

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

〒170-8424
東京都豊島区東池袋 4-26-3

お客様相談室でんわ

0120-14-6404

重要なお知らせ（安全上のご注意）

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

⊘ してはいけない「禁止」の内容です。

⚠ 警告 死亡や重傷などに結びつくおそれがあるもの







禁止


- 不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。
- ストーブなど引火するおそれがあるものを近くに置かないでください。火災の原因になります。
- タバコの火などを商品に落とさないでください。火事の原因となります。

お願い（その他 注意）

- 直射日光や照明、ストーブやエアコンなどの冷暖房器具の熱や風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になります。
- 濃色製品は使用中の強い摩擦により色移りすることがあります。汗などで濡れた状態で使用すると色移りや変色することがありますので、ご注意ください。

パーツリスト ※イラストは2シーターです。

パーツ No.	1	2	3	4
パーツ名	座クッション用カバー	背クッション用カバー	保護用テープ	保護用テープ収納袋
形 状				
2シーター	2	2	4	1
2.5シーター	2	2	4	1
3シーター	2	2	4	1



装着方法 ※イラストは2シーターです。




注意

- 保護用テープは面ファスナーによる生地へのひっかけや、すりキズから保護するためのものです。本体に装着する時は面ファスナーからはがさないでください。
- カバーの装着および取りはずし時は、セーターなどの衣類が面ファスナーにつかないようご注意ください。面ファスナーによって衣類がキズつくことがあります。

座クッション用カバー

1 座クッション用カバーのファスナーを開き、下図のように座クッションを少し曲げるようにしてカバーに入れて装着してください。




2 カバー内側にある保護用テープをはずし、面ファスナーを座クッションに貼り付けてからファスナーを閉めてください。

3 最後にクッション全体の形を整えてください。

4 はずした保護用テープは、保護用テープ収納袋に入れて保管し、カバー洗濯時には貼ってから洗濯してください。


背クッション用カバー

1 背クッション用カバーのファスナーを開き、下図のように背クッションを少し曲げるようにしてカバーに入れて装着しファスナーを閉めてください。



2 最後にクッション全体の形を整えてください。

3 ①座クッションを下図のように、側生地のファスナーが付いている方を下面にし、裏側の保護用テープをはがし、カバーに縫い付けてある面ファスナーと本体を固定しながら、設置してください。
②背クッションを下図のように、側生地のファスナーが付いている方を下面にして設置してください。



注意 ●ファスナーを強い力で無理に閉めると、ファスナーが破損するおそれがありますのでご注意ください。

Sofa Wooden frame Cover
Feather pocket coil
Urethane pocket coil

User Guide

Thank you for your purchase.
Read this User Guide before use to ensure correct use of the product.
Store this guide in an easily accessible place for future reference.

25 December 2020

Specifications

Product Name	Sofa Wooden frame Cover
Specifications	Stated on the care label of the cover
Usage	Cover for Sofa Wooden frame
Place of Origin	VIETNAM

Direction for Use

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Care Instruction

- Refer to the User Guide provided with Sofa Wooden frame (sold separately) and the care label on the cover.

Contact Information

For enquiries regarding the product, please contact the store of purchase.

Important Information
(Safety Advice)

The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.

⊘ Actions that are prohibited.

⚠ Warning Hazards that may lead to death or serious injury



DONTs


- Do not leave unnecessary packaging materials within reach of small children. Small children may accidentally pull them over their heads and cover their mouth and/or nose, causing suffocation.
- Do not place near a heat source such as a heater. Doing so may cause a fire.
- Do not drop lit cigarettes, etc. onto the product. Doing so may cause a fire.

Note (Other Caution)

- Do not expose to direct sunlight or lighting, or heat or air from heating and cooling appliances such as air conditioner and heater. Doing so may cause warping, distortion, cracking or discolouration.
- Colour may transfer from dark-coloured products when strong friction is applied during use. This can occur especially when used in wet conditions from rain or sweat.

Parts * The 2S type is used in the illustrations.

Part No.	1	2	3	4
Part Name	Seat Cushion Cover	Back Cushion Cover	Protective Tape	Protective Tape Storage Bag
Appearance				
2S	2	2	4	1
2.5S	2	2	4	1
3S	2	2	4	1



Completion Image

How to Put on the Covers * The 2S type is used in the illustrations.




Caution

- Protective tapes are used to prevent hook-and-loop fasteners from causing snags or scratches on the fabric. When putting on the seat cushion cover, do not remove the protective tape on the outside of the cover.
- Be careful not to get your clothing (sweaters, etc.) caught on the hook-and-loop fastener when putting on/taking off the cover. Otherwise, the fastener may damage your clothing.

Seat Cushion Cover

- Open the fastener of the seat cushion cover. Slightly bend and insert the seat cushion into the cover (see image below).



- Remove the protective tape on the inside of the cover. Press the hook-and-loop fastener against the seat cushion and close the fastener.

- Reshape the cushion.


- Keep the removed protective tapes in the protective tape storage bag. Be sure to put them back on when washing the covers.

Caution

- Be careful not to forcefully close the fastener, as doing so can break it.

Back Cushion Cover

- Open the fastener of the back cushion cover. Slightly bend and insert the back cushion into the cover (see image below).



- Reshape the cushion.

- ① Set the seat cushion with its fastener on the outer shell facing down as shown below. Remove the protective tape on the outside of the seat cushion cover and press the hook-and-loop fastener against the sofa base.
② Set the back cushion with its fastener on the outer shell facing down as shown below.

