

ソファ本体木製フレーム1S用カバー

ソファ本体木製フレームフェザーポケットコイル  
ソファ本体木製フレームウレタンポケットコイル  
1シーター用

この取扱説明書は、各色・各生地のカバーに共通です。

取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。  
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しくお使いください。  
また、本書はいつでも確認できるように大切に保管してください。

2024年4月25日

ご使用方法

廃棄について

●廃棄の際は、居住地域の自治体のルールに従い、処分してください。

お問い合わせ先

製品のお問い合わせは、お買い上げの販売店、もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ

0120-14-6404

お手入れ方法

●ソファ本体木製フレームフェザーポケットコイル、ソファ本体木製フレームウレタンポケットコイル1シーター（別売り）に付属の組立・取扱説明書及びカバーに縫いつけの品質表示ラベルを参照してください。

重要なお知らせ（安全上のご注意）

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

⊘ してはいけない「禁止」の内容です。

⚠ 警告 死亡や重傷などに結びつくおそれがあるもの

⊘ 禁止

●不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。  
●ストーブなど引火するおそれのある物を近くに置かないでください。火災の原因になります。  
●タバコの火などを商品に落とさないでください。火災の原因となります。

お願い（その他 注意）

●直射日光の当たる場所で使用や保管しないでください。変色の原因になります。  
●湿った状態で使用しないでください。色移りや変色の原因となります。（特に濃色製品は使用中の強い摩擦でも色移りすることがあります。）

パーツリスト

パーツ No.	1	2	3	4
パーツ名	座クッション用カバー	背クッション用カバー	保護用テープ	保護用テープ収納袋
形 状				
数 量	1	1	1	1

完成図

装着方法

⚠ 注意

⊘ 保護用テープは面ファスナーによる生地へのひっかけや、すりキズから保護するためのものです。本体に装着する時は面ファスナーからはがさないでください。  
❗ カバーの装着および取りはずし時は、セーターなどの衣類が面ファスナーにつかないようご注意ください。面ファスナーによって衣類がキズつくことがあります。

座クッション用カバー

1

座クッション用カバーのファスナーを開き、下図のように座クッションを少し曲げるようにしてカバーに入れて装着してください。

2

最後にクッション全体の形を整えてください。

背クッション用カバー

1

背クッション用カバーのファスナーを開き、右図のように背クッションを少し曲げるようにしてカバーに入れて装着しファスナーを閉めてください。

2

最後にクッション全体の形を整えてください。

3

①座クッションを下図のように、側生地のファスナーが付いている方を下面にし、裏側の保護用テープをはがし、カバーに縫い付けてある面ファスナーと本体を固定しながら、設置してください。  
②背クッションを下図のように、側生地のファスナーが付いている方を下面にして設置してください。

座クッション

背クッション

⚠ 注意

❗ ファスナーを強い力で無理に閉めると、ファスナーが破損するおそれがありますのでご注意ください。

4

はずした保護用テープは、保護用テープ収納袋に入れて保管し、カバー洗濯時には貼ってから洗濯してください。

Cover for Sofa Wooden frame 1S

For Sofa Wooden frame Feather Pocket coil  
For Sofa Wooden frame Urethane Pocket coil  
1S

This User Guide applies to all colours and fabric types.

User Guide

Thank you for your purchase.  
Read this User Guide before use to ensure correct use of the product.  
Store this guide in an easily accessible place for future reference.

25 April 2024

Direction for Use

Disposal

- To dispose of the product, follow the rules implemented by your local government.

Care Instruction


- Refer to the User Guide provided with Sofa Wooden frame Feather Pocket coil or Sofa Wooden frame Urethane Pocket coil 1S (sold separately) and the care label on the cover.


Contact Information


For enquiries regarding the product, please contact the store of purchase.

Important Information (Safety Advice)

The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.

 Actions that are prohibited.

 **WARNING** Hazards that may lead to death or serious injury






 DON'Ts

- Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate.
- Do not place a heat source such as a heater near the product. Doing so may cause a fire.
- Do not drop lit cigarettes, etc. onto the product. Doing so may cause a fire.


Note (Other Caution)



- Do not use or store in a place exposed to direct sunlight. Doing so may cause discolouration.
- Do not use in wet conditions. Doing so may cause colour transfer or discolouration. (In particular, colour transfer can occur even from strong friction in dark-coloured products.)

Parts

Part No.	1	2	3	4	 Completion Image
Part Name	Seat Cushion Cover	Back Cushion Cover	Protective Tape	Protective Tape Storage Bag	
Appearance					
pcs	1	1	1	1	


Attaching the Cover

 **CAUTION**

-  Do not remove the protective tapes from the hook-and-loop fasteners when attaching the covers. They are used to prevent snags or scratches to the fabric from the hook-and-loop fasteners.
-  Be careful not to get your clothing such as sweater caught on the hook-and-loop fasteners when attaching/removing the cover. Otherwise, the fasteners may damage your clothing.

Seat Cushion Cover


- 1
- Open the fastener of the seat cushion cover. Slightly bend and insert the seat cushion into the cover as shown below.



- 2
- Finally shape the cushion.

Back Cushion Cover


- 1
- Open the fastener of the back cushion cover. Slightly bend and insert the back cushion into the cover as shown below.




- 2
- Shape the cushion.


- 3
- ① Place the seat cushion with the fastener on the outer shell facing down as shown below. Remove the protective tape on the bottom of the seat cushion cover and press the hook-and-loop fastener against the sofa base to fix the cushion in place.

② Place the back cushion with the fastener on the outer shell facing down as shown below.



- 4
- Keep the removed protective tapes in the protective tape storage bag. Be sure to attach them back before washing the covers.

 **CAUTION**

-  Be careful because closing the fastener forcefully may cause it to break.