

ソファ本体・3シーター・ウレタン・ポケットコイル SOFA / URETHANE / POCKET COIL / 3S

組立・取扱説明書 User Guide

日本語

この度は本商品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 10.

4550182846263 SOFA / URETHANE / POCKET COIL / 3S

2024 / 3 / 21

853395553-017-001-JPEN

ソファ本体・3シーター・ウレタン・ポケットコイル

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ	ページ
重要なお知らせ（安全上のご注意）	2～4
パーツリスト	5
各部の名称	5
組立方法	6～7
お手入れ方法・ご使用に際して	8～9
製品仕様	8
お問い合わせ先	8

重要なお知らせ（安全上のご注意）

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び治療に入院、長期の通院を要するものをさします。

※2 傷害とは治療や入院や長期の通院を要しない、ケガ、やけどをさします。

※3 物的損害とは、家屋、家財にかかわる拡大損害をさします。



組み立て・分解の際のご注意



警告



禁止

●不要になった包装資材はすぐに処分するなど、お子さまの手の届く所に置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。



注意



行う

- 重量がありますので、作業は必ず2人以上で行ってください。重いものや長いものなど無理やり持ち上げたり、無理な姿勢で取り付けると商品破損やケガの原因となります。
- 組み立て中にパーツなどの不足、不備があった場合は、組み立てを中止してください。固定部分がはずれて、ケガの原因になります。
- 手で㊸ハンガーボルトを締める際は、手袋や当て布をしてください。㊸ハンガーボルトで指などケガをするおそれがあります。
- ご使用後一週間ほど経過しましたら、㊹蝶ネジにゆるみがないか確認し、ゆるみが生じている場合は、締め直してください。ゆるんだまま使用すると商品が破損したり、ケガをするおそれがあります。
- 引越しなどで移動する際は、組み立て前の状態に戻してから運んでください。㊹蝶ネジにゆるみが生じ商品が破損しケガをするおそれがあります。

お願い（その他 注意）

- 組み立てに十分な場所を確保し、敷物などを敷いて床や既存の家具にキズがつかないように、注意して行ってください。



設置環境についてのご注意



警告



禁止

- ストーブなど引火するおそれのあるものを近くに置かないでください。火災の原因となります。
- 商品の脚などで電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因になることがあります。

重要なお知らせ (安全上のご注意)

必ずお守りください。(つづき)

⚠ 設置環境についてのご注意 (つづき)

⚠ 注意	
禁止	●多湿な場所（目安：湿度70%以上でかつ室温20℃以上）で長期間設置はしないでください。カビやダニなどが発生し、健康を害することがあります。 ●壁から少し離して設置してください。（目安：10cm程度）風通しが悪くて空気が滞留したり、壁側の結露や外気の影響でカビが発生しやすくなり、健康を害することがあります。また、壁に直接触れていると、壁紙が変色するおそれがあります。

お願い (その他 注意)

	●直射日光や照明、ストーブやエアコンなどの熱や風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になります。 ●必ずカーペットなど敷物の上にソファを設置するか、ソファの脚にフェルトなどを貼って使用してください。商品を長時間同じ場所に設置し使用されますと床と、脚の設置面が凹んだりして床をいためる場合があります。木部の塗料と床面との化学反応による汚れ防止になります。 ●平らで安定した場所に設置してください。不安定な場所での使用は、製品がゆがんだり、破損の原因になることがあります。
--	---

⚠ 使用上のご注意

⚠ 警告	
禁止	●乳幼児を寝かさないでください。床への落下や窒息の原因になることがあります。 ●保護者の目の届かないところで、お子さまだけでは使用させないでください。 ●タバコの火などを商品に落とさないでください。火事の原因となります。 ●座る以外には使わないでください。思わぬケガの原因になることがあります。 ●座った状態でソファを傾けるなど、不安定な状態では使用しないでください。転倒や商品の破損により、思わぬケガをする原因となります。 ●商品の上に立ったり、飛びはねたり、踏み台代わりに使用したりしないでください。バランスを崩し転倒したり、商品の破損によりケガの原因になることがあります。 ●破損・変形したソファは使用しないでください。思わぬケガをするおそれがあります。 ●修理や改造はしないでください。製品の強度が弱くなり、ケガをする原因となります。 ●座面に浅く腰掛けしないでください。転倒してケガをする原因となります。 ●アームや背もたれには座らないでください。思わぬケガの原因となります。

⚠ 注意

禁止	●製品の周辺、または上部に物を置かないでください。落下しケガの原因になることがあります。 ●12cmを超える長さの脚、また、無印良品の木製脚/スチール脚（別売り）以外は取り付けしないでください。転倒や破損、ケガをするおそれがあります。
行う	●移動する際は、大人2人以上で移動させてください。1人で無理に移動させるとケガや商品の破損、また床をキズつける原因となります。 ●使い始めるときは、室内の換気を十分にしてください。 木材の接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。 ●木製脚/スチール脚（別売り）を取り付けてご使用ください。

重要なお知らせ（安全上のご注意）








必ずお守りください。（つづき）

使用上のご注意（つづき）


お願い（その他 注意）

- シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。
変色や変形の原因となります。
- 化学雑巾を長時間接触させたまにしないでください。
変色したり、表面がはがれたりすることがあります。
- フェルトを貼った状態では凹凸や継ぎ目などの段差のある床面では使用しないでください。
フェルトがはがれて、床面を汚したり、キズつけたりする原因となります。
- 組み立ての際は、手袋などをつけて作業してください。思わぬケガの防止になります。

パーツリスト

①ベース×1 	②背もたれ×1 	③アーム(右)×1 	
④アーム(左)×1 	⑤背クッション×2  タグ表示：HB3	⑥座クッション×2  タグ表示：HZ3	
フィッティングパーツ			
⑦ハンガーボルト×6 (M8×70mm) 	⑧ワッシャー×6 (外径18mm) 	⑨スプリングワッシャー×6 (外径15mm) 	⑩蝶ネジ×6 (M8) 

各部の名称



※別売りのカバーを必ず装着してご使用ください。
 ※カバー装着方法は、別売りのカバー付属の説明書をご確認ください。
 ※脚は別売りです。無印良品の木製脚/スチール脚をご使用ください。

組立方法


お願い
(その他 注意)

組み立ての前に必ずお読みください。

- 組み立てに十分な場所を確保し、敷物などを敷いて床や既存の家具にキズがつかないように注意してください。
- 組み立ては必ず2人以上で行ってください。


1

- ⑧背もたれをタグが後ろ側になるように置いてください。
⑧背もたれの連結金具に③アーム(右)、④アーム(左)の連結金具を下図のように上から引っかけます。




注意

- ⑧背もたれには前・後があります。
タグが後ろ側にくるように置いてください。



2

- ⑧背もたれ、③アーム(右)、④アーム(左)に①ハンガーボルトを取り付けます。




注意

- ①手で①ハンガーボルトを締める際は、手袋や当て布をしてください。
①ハンガーボルトで指などケガをするおそれがあります。

3

- ①(A)ベースのファスナーを開けます。
- ②①ハンガーボルトを(A)ベースの穴から通し、②ワッシャー、③スプリングワッシャー、④蝶ネジを使い固定します。
※①ハンガーボルトがベースの穴に入りにくい場合は、無理に押し込まず、全体の位置を調整しながら差し込んでください。
- ③(A)ベースのファスナーを閉じ、ファスナーのスライダーをポケットに入れます。




注意

- ④ご使用後一週間ほど経過しましたら、④蝶ネジにゆるみがないか確認し、ゆるみが生じている場合は、締め直してください。ゆるんだまま使用すると商品が破損したり、ケガをするおそれがあります。

組立方法（つづき）


4

④ ④ベースの脚取り付け穴に木製脚/スチール脚（別売り）のボルトを入れ、しっかり締めてから本体を起こしてください。



注意

- ❶ 起こす際に脚の片側に過度の荷重がかからないようにご注意ください。破損、床のキズなどの原因になります。移動するときは2人以上で持ち上げて移動してください。
- ❷ 各パーツがしっかり固定されているか必ず確認してください。
- ❸ ご使用後、一週間程経過しましたら脚をしっかり締め直してください。ゆるんだまま使用すると、商品が破損し、ケガをするおそれがあります。





5

カバー（別売り）を付属の取扱説明書に従って装着してください。

6

- ① ⑤座クッションを下図のように、側生地のファスナーが付いている方を下面、タグが付いている方を後ろ上面にし、設置してください。
- ② ⑥背クッションを下図のように、側生地のファスナーが付いている方を下面にし、タグが付いている方を後ろ側にし、設置をしてください。



※分解する際は、組立方法と逆の手順で行ってください。

お手入れ方法

汚れについて

【本体の側生地のお手入れ】

- 通常のお手入れはやわらかい布で乾ぶきしてください。ほこりなどはブラシや掃除機（弱設定）などを使って取り除いてください。
- コーヒーなどの汚れがひどいときは、ぬるま湯を使って3～5%程度に薄めた中性洗剤にやわらかい布を浸し、よく絞って表面をたたくようにふき取ってください。その後、水を浸した布で洗剤をよくふき取り、自然乾燥してください。
- カバー（別売り）の洗濯方法については、カバーの品質表示ラベルに従い、正しくお取り扱いください。

ご使用に際して

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

シックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長期間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

●お部屋の換気について



注意

- ❗ 家具を設置の際は、室内の換気を十分にしてください。
化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をするようにご注意ください。換気効率をあげるため複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

●化学物質に敏感な体質のお客さまへ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましても、ホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

●ホルムアルデヒド吸着・分解シートについて

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、無印良品の家具には、ホルムアルデヒド吸着・分解シートを同梱しています。

※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

保守点検

- 脚や背もたれ、アームにゆるみやグラつきがないか定期的に点検し、ゆるみはじめたらしっかり締めなおしてください。ケガや破損、床面へのキズの防止となります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

ご使用に際して（つづき）

移動について



⓪ 1人では移動を行わないでください。ケガや破損、床面へのキズの原因になります。

- 移動させる際は、クッションなど取り外しできるものははずして運んでください。必ず座部の下に両手をかけて、大人2人以上で、床面をひきずらないように持ち上げて運んでください。
- 引越しなどで移動する際は、組み立て前の状態に戻してから運んでください。④蝶ネジにゆるみが生じ商品が破損しケガをするおそれがあります。

廃棄について

廃棄の際は、住居地域自治体のルールに従い、処分してください。

製品仕様

品 名	ソファ本体・3シーター・ウレタン・ポケットコイル		
J A N	4550182846263		
製品寸法	幅	2270 mm	
	奥行き	905 mm	
	高さ	700 mm (脚を除く) ※	
	座面の高さ	305 mm (脚を除く) ※	
	※木製脚/スチール脚 (別売り) を取り付けたときの高さ		
	「5cmの脚」をつけた場合	高さ750 mm	座面の高さ355 mm
	「10cmの脚」をつけた場合	高さ800 mm	座面の高さ405 mm
	「12cmの脚」をつけた場合	高さ820 mm	座面の高さ425 mm
製品重量	約59 kg		
用 途	ソファ・2～3人用		
材 質	構 造 部 材	本 体：	金属 (鋼)、合板 プラスチックボード (ポリプロピレン)
	側 生 地	本 体：	ポリエステル
	クッション	クッション：	ポリエステル・綿
	クッション材	本 体：	ウレタンフォーム 鋼製ばね (Sばね) スチールワイヤー
		背クッション：	ウレタンフォーム
		座クッション：	ウレタンフォーム 鋼製ばね (コイルスプリング)
原 産 国	中 国		

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ

 0120-14-6404

SOFA / URETHANE / POCKET COIL / 3S

User Guide

Thank you for your purchase.
Read this User Guide before use to ensure correct use and assembly of the product.
Please store this guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	11 - 13
Parts	14
Part Names	14
Assembly Instructions	15 - 16
Care Instructions	17
Usage	17 - 18
Specifications	18
Contact Information	18

Important Information (Safety Advice)

These instructions
must be followed.

This User Guide contains important information for safe use of this product in order to prevent harm to the user and others as well as damage to property.

Please note the following contents (indications and graphic symbols) before reading the main contents of this guide and follow the instructions given.

• Explanations of Indications

The extent of injury and damage that may arise when the product is used incorrectly is classified and explained with the following symbols.

 WARNING	Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury ^{*1} to the user.	 CAUTION	Indicates a hazard with a level of risk which, if not avoided, could result in injury ^{*2} to the user or property damage ^{*3} .
--	---	--	--

• Explanations of Graphic Symbols

Instructions are given in the form of the following graphic symbols.
(Examples of graphic symbols are as follows.)

 DON'Ts: Actions that are prohibited.	 DOs: Actions that must be taken.
--	--

*1 "Serious injury" indicates blindness, injuries, burns, bone fractures, poisoning, or electric shocks which have long term effects and require hospitalisation and/or long-term hospital visits for treatment.

*2 "Injury" indicates injuries or burns which do not require hospitalisation or long-term hospital visits for treatment.

*3 "Property damage" indicates extended damage that involves the house or household property.

Assembly and Disassembly Precautions

 WARNING	
 DON'Ts	• Do not keep unnecessary packing materials within reach of children. Discard them immediately after unpacking. Small children may accidentally pull them over their heads and cover their mouth and/or nose, causing suffocation.

 CAUTION	
 DOs	• The product must be assembled by two or more people as it is heavy. Forcibly lifting a heavy or long object, or installing such object in an awkward position may cause product damage and/or injury. • Stop the assembly if any part is missing or broken. Not doing so may cause parts to come off, resulting in injury. • Wear gloves or use a piece of cloth when tightening hanger bolts to protect your fingers and hands from injury. • Check if wing nuts are loose approximately one week after assembly and retighten them if necessary. Continued use with loose bolts may cause damage to the product, resulting in injury. • When relocating the product for moving, etc., disassemble the product beforehand. Not doing so may cause wing nuts to become loose, leading to damage of the product, resulting in injury.

Note (Other Caution)	
	• Secure enough space for assembly and place an underlay to protect the floor and other furniture from scratches.

Precautions for Installation Environment

 WARNING	
 DON'Ts	• Do not place near a heat source such as a room heater. Doing so may cause a fire. • Do not place a leg of the product on the power cord of an electrical appliance. Doing so may damage the cord, resulting in an electric shock or a fire.

Important Information (Safety Advice)

These instructions must be followed. (Continued)

Precautions on Installation Environment (Continued)

CAUTION



DON'Ts

- Do not place the product in a humid place (approx. humidity of 70% or higher and room temperature of 20°C or higher) for a long time. Doing so may cause mould and mites to grow, resulting in health hazards.
- Do not install without any space between the product and the wall. (Approx. 10 cm) Doing so may cause mould growth due to air stagnation from poor ventilation or condensation on the wall owing to outdoor air conditions, resulting in health hazards. In addition, direct contact to the wall may cause discolouration of wallpaper.

Note (Other Caution)

- Do not expose to direct sunlight and lighting, or heat or air from heating/cooling appliances such as heater and air conditioner. Doing so may cause warping, deformation, cracks, or discolouration.
- Install on top of a rug or other underlay, or attach felt pads on the bottom of the legs. It prevents chemical reactions between the coating on the legs and floor causing marks. Also using the product installed in the same location for a long period of time may result in dents or other damage of the floor surface.
- Install on a flat and stable surface. Using on an unstable surface may cause distortion of or damage to the product.

Precautions for Use

WARNING



DON'Ts

- Do not lay small children on the product. Doing so may cause them to fall on the floor or to suffocate.
- Do not let children use the product without supervision.
- Do not drop lit cigarettes, etc. onto the product. Doing so may cause a fire.
- Do not use for other than its intended use of sitting. Doing so may cause unexpected injury.
- Do not use the sofa in unstable conditions such as tilting it while sitting on it. Doing so may result in unexpected injury from falling, or damage of the product.
- Do not stand or jump on the product or use it as a stepladder. Doing so may result in injury from tipping over or damage of the product.
- Do not use if the product is damaged or deformed. Doing so may cause unexpected injury.
- Do not attempt to repair or modify. Doing so may reduce the structural strength of the product, resulting in injury.
- Do not sit near the edge of the seat. Doing so may cause the product to tip over, resulting in injury.
- Do not sit on the arms or backrest. Doing so may result in unexpected injury.

CAUTION



DON'Ts

- Do not place an object near or on this product. It may fall, causing injury.
- Do not attach legs longer than 12 cm or any legs other than MUJI's wooden/steel legs (sold separately). Doing so may result in the product tipping over, being damaged, or injury.



DOs

- The product must be moved by two or more adults. Moving the product by only one person may cause injury, product damage, or damage to the floor.
- Ventilate the room well during the early stage of use.
Formaldehyde contained in the adhesives may still remain, and those who have high sensitivity to chemicals or small children may experience allergic reactions.
- Make sure to attach MUJI's wooden/steel legs (sold separately) when using this product.

Important Information (Safety Advice)

These instructions must
be followed. (Continued)










Precautions for Use (Continued)

Note (Other Caution)


- Do not use organic solvents such as paint thinner or bleach for cleaning. Doing so may cause deformation or discolouration.
- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.
- Do not use on an uneven floor when felt pads are attached to the product. Doing so may cause the felt pads to come off, resulting in dirt or scratches on the floor surface.
- Wear gloves during assembly of the product. This is to prevent unexpected injury.

Parts

Ⓐ Base × 1 	Ⓑ Backrest × 1 	Ⓒ Arm (right) × 1 
Ⓓ Arm (left) × 1 	Ⓔ Back Cushion × 2  Tag: HB3	Ⓕ Seat Cushion × 2  Tag: HZ3

Fitting Parts			
Ⓐ Hanger Bolt × 6 (M8 × 70 mm) 	Ⓑ Washer × 6 (external diameter 18 mm) 	Ⓒ Spring Washer × 6 (external diameter 15 mm) 	Ⓓ Wing Nut × 6 (M8) 

Part Names



- * Always use with a cover (sold separately).
- * For instructions on how to attach the cover, refer to the User Guide enclosed with the cover (sold separately).
- * Legs are sold separately. Use MUJI's wooden/steel legs designed for the product.

Assembly Instructions

Note (Other Cautions)


Read these instructions carefully before assembling the product.

- Secure enough space for assembly and place an underlay to protect the floor and other furniture from scratches.
- The product must be assembled by two or more people.


1

Place ⑥ backrest with tag side facing back.

Hook the joints of ③ arm (right) and ④ arm (left) to the joints on ⑥ backrest from above as shown in the illustration below.




❗ The front and back of ⑥ backrest are different. Place it with the tag side facing back.



2

Attach ① hanger bolts to ⑥ backrest, ③ arm (right), and ④ arm (left).



❗ Wear gloves or use a piece of cloth when tightening ① hanger bolts to protect your fingers and hands from injury.


3

① Open the fasteners on ① base.

② Put ① hanger bolts into holes through the openings of ① base and fasten them with ② washers, ③ spring washers and ④ wing nuts.

* If ① hanger bolts are hard to fit into the holes, insert them not forcibly but gently while adjusting the overall positions.

③ Close the fasteners on ① base and put the sliders into the pockets.




❗ Check if ④ wing nuts are loose approximately one week after assembly and retighten them if necessary. Continued use with loose bolts may cause damage to the product, resulting in injury.

Assembly Instructions (Continued)


4

Attach wooden/steel legs (sold separately) into the holes on (A) base then securely tighten them. Turn the sofa over.



CAUTION

- ❗ When turning the sofa over, be careful not to apply excessive load on one side of the legs. Doing so may cause damage or scratches on the floor. The product must be lifted and moved by two or more people.
- ❗ Make sure all parts are securely tightened.
- ❗ Approximately one week after the assembly, securely retighten the bolts on the legs. Continued use with loose bolts may cause damage to the product, resulting in injury.





5

Put the cover (sold separately) on referring to the supplied user guide.

6

- ① Place (E) seat cushions with the fastener side facing down and the tag side facing upper back as shown in the illustration below.
- ② Place (E) back cushions with the fastener side facing down and the tag side facing back as shown in the illustration below.



Completed

* To disassemble the product, follow the process in reverse order.

Care Instructions

Dirt and Stains

[Care instructions for the outer shell of the body]

- For usual care, wipe with a soft, dry cloth. Remove dust by using a brush or a vacuum cleaner (low setting).
- If the product is particularly soiled with stains such as coffee, soak a soft cloth in a warm 3 to 5% solution of a neutral detergent, wring out the cloth thoroughly and pat the cloth on the surface to remove the stain. Then, wipe off any detergent residue with a damp cloth and leave it to dry naturally.
- When washing the cover (sold separately), follow the washing instructions on the cover and handle properly.

Usage

Formaldehyde Countermeasures

- What is Formaldehyde?

Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent-smelling compound that vaporises at room temperature, and is found in items such as furniture, building materials, and wallpaper adhesives. It is released gradually, and people in a room where formaldehyde has accumulated for a long time may experience symptoms such as eye irritations or a sore throat. A high concentration of formaldehyde may cause breathing difficulties.

- Ventilate the room



ⓘ Ventilate the room well when installing the furniture. Persons who have high sensitivity to chemicals or small children may experience allergic reactions.

Formaldehyde is easily dispersed in the air. Therefore, be sure to ventilate the room regularly. When multiple pieces of furniture are installed at the same time, open the windows widely for sufficient ventilation. More formaldehyde is released when the room temperature increases. Therefore, be careful if the room is closed for a long time during summer, and ventilate the room thoroughly. In order to increase ventilation efficiency, it is recommended that you open multiple windows, or use a ventilation fan or air circulator.

- For persons who have high sensitivity to chemicals

There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even when the actual value in the room is lower than the indoor concentration guideline value (indoor concentration of formaldehyde that is tolerable for health), some people react to formaldehyde. At present, MUJI furniture products are made with materials that emit as little formaldehyde as possible, but this does not guarantee that no formaldehyde is emitted at all. If any allergy symptom appears, it is recommended that you see a physician.

- Formaldehyde absorption/decomposition sheets

When used in confined spaces, formaldehyde may be reabsorbed by the material if there is nowhere for it to dissipate. Formaldehyde absorption/decomposition sheets are used to reduce the concentration of formaldehyde as much as possible before the product reaches the customer.

* Effectiveness of the "formaldehyde absorption/decomposition sheet" in the packaging has been expended by the time the package reaches the customer. Dispose of the sheet as burnable waste after unpacking.

Maintenance and Inspection

- Periodically check for any looseness or wobbling in the legs, arms and backrest, and retighten them if any looseness is found. Doing so will prevent injury, damage or scratches to the floor.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Usage (Continued)

Moving the Product



⊘ Do not attempt to move the product alone. Doing so may cause injury, damage to the product, or scratches on the floor.

- When moving the product, remove all removable parts such as cushions beforehand and hold the underside of the seat with both hands. The product must be moved by at least two adults. Do not drag the product on the floor.
- When relocating the product for moving, etc., disassemble it beforehand. Wing nuts may become loose, causing the product to become damaged, resulting in injury.

Disposal

To dispose of the product, follow the rules implemented by your local government.

Specifications

Product Name	SOFA / URETHANE / POCKET COIL / 3S		
JAN	4550182846263		
Product Dimensions	Width	2270 mm	
	Depth	905 mm	
	Height	700 mm (excluding legs)*	
	Seat Height	305 mm (excluding legs)*	
	*The height when wooden/steel legs (separately sold) are attached.		
	When 5-cm-long legs are attached	Height: 750 mm	Seat Height: 355 mm
	When 10-cm-long legs are attached	Height: 800 mm	Seat Height: 405 mm
	When 12-cm-long legs are attached	Height: 820 mm	Seat Height: 425 mm
Product Weight	Approx. 59 kg		
Usage	Sofa for 2 to 3 People		
Materials	Structural Elements	Body:	Metal (steel), Plywood Plastic Board (polypropylene)
	Outer Shell	Body:	Polyester
		Cushions:	Polyester / Cotton
	Filling	Body:	Urethane Foam Steel Springs (S-spring) Steel Wire
		Back Cushion:	Urethan Foam
		Seat Cushion:	Urethan Foam Steel Springs (coil spring)
Country of Origin	China		

Contact Information

For inquiries regarding the product, please contact the store of purchase.