

# MUJI 無印良品

保存用

## 製品仕様

### ステンレスユニットシェルフ ステンレス追加棚 木製追加棚

### 組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。また、本書はいつでも確認できるように大切に保管してください。

2024年9月26日

#### ステンレス追加棚

品名		ステンレスユニットシェルフ 追加棚		ウォールナット材		ステンレスユニットシェルフ ステンレス追加棚		タモ材	
規格	幅84cmタイプ用	幅56cmタイプ用	幅42cmタイプ用	幅84cmタイプ用	幅56cmタイプ用	幅42cmタイプ用	幅84cmタイプ用	幅56cmタイプ用	幅42cmタイプ用
JAN	4550583922443	4550583922429	4550583922436	4550583922481	4550583922498	4550583922504	4550584339455	4550584339462	4550584339479
製品寸法	約幅1090 ×奥行400 ×高さ25 mm	約幅810 ×奥行400 ×高さ25 mm	約幅395 ×奥行400 ×高さ25 mm	約幅805 ×奥行400 ×高さ25 mm	約幅530 ×奥行400 ×高さ25 mm	約幅395 ×奥行400 ×高さ25 mm	約幅805 ×奥行400 ×高さ25 mm	約幅530 ×奥行400 ×高さ25 mm	約幅395 ×奥行400 ×高さ25 mm
製品重量	約4.5 kg	約3 kg	約2.3 kg	約4.5 kg	約3 kg	約2.3 kg	約4.5 kg	約3 kg	約2.3 kg
用途	ステンレスユニットシェルフ用棚板								
耐荷重	棚板1枚あたり 約30 kg ※棚全体で均等に荷重を掛けた場合								
材質	棚板: MDF(オーク材突板)、フック: ステンレス鋼			棚板: MDF(ウォールナット材突板)、フック: ステンレス鋼			棚板: MDF(タモ材突板)、フック: ステンレス鋼		
表面加工	棚板: アクリルUV塗装、フック: 電解研磨								
原産国	中国								

### ご使用方法

#### 移動について

●引越など移動をする際は、組み立て前の状態に戻してから運んでください。ケガや製品の破損、床面がキズがつくおそれがあります。

#### 廃棄について

●廃棄の際は、居住地域の自治体のルールに従い、処分してください。

### お手入れ方法

#### 保守・点検

●破損、変形した状態では使用しないでください。  
●各部にゆるみやグラつきがないか定期的に点検し、ゆるんでいたらしっかり締め直してください。ケガや製品の破損、床面へのキズ防止になります。

#### 木部のお手入れ

●長時間、化学雑巾を接触させたまにしないでください。変色や表面がはがれる原因となります。

#### 木部・金属部のお手入れ

●通常のお手入れはやわらかい布で乾拭きしてください。  
●汚れがひどい時は、3～5%程度に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤をよくふき取ってください。次に乾いたやわらかい布で軽くふいた後で自然乾燥してください。

### 重要なお知らせ(安全上のご注意)

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

してはいけない「禁止」の内容です。

実行しなければならない内容です。

#### 警告 死亡や重傷などに結びつくおそれがあるもの

●不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。  
●フィッティングパーツは幼児の手の届くところには置かないでください。また、なくさないでください。これらは小さく、誤飲してしまうと窒息などのおそれがあります。

●棚セット(※)もしくは追加用帆立(単品)に付属の組立・取扱説明書をよく読み、正しくお使いください。組み立てた製品に対し、お使いになる上での注意が記載されており、ケガを防ぎ、安全にお使いいただく為に重要です。

※棚セットとはステンレスユニットシェルフシリーズ、スチールユニットシェルフシリーズの帆立、棚板、クロスバーがセットになった製品のことで

#### 注意 傷害を負う可能性や物的損害が生じるおそれがあるもの

●奥行寸法の異なる帆立に棚板を取り付けしないでください。固定できず、棚板の落下によりケガをするおそれがあります。  
●耐荷重を超えて物をのせたり、耐荷重内でも一部に片寄ってのせたりしないでください。変形や破損の原因となり、ケガをするおそれがあります。  
●修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。  
●屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。

#### お願い(その他 注意)

●木製追加棚は、使い始めは室内の換気を十分に行ってください。製品に微量にホルムアルデヒドが含まれることがあります。敏感な方や乳児などはアレルギー症状を起こすおそれがあります。  
●木製追加棚は、直射日光を避け、冷暖房具の熱や風に当たらないようにしてください。反り、割れ、変色の原因になります。  
●シンナーなどの有機溶剤や漂白剤などの薬剤で手入れしないでください。変色や変形の原因となります。  
●組み立ての際は、手袋などをつけて作業してください。思わぬケガの防止になります。

### パーツリスト・各部の名称

各サイズ共通です


#### ①棚板×1

ステンレス追加棚

追加棚 オーク材  
追加棚 ウォールナット材  
追加棚 タモ材



追加棚 オーク材  
追加棚 ウォールナット材  
追加棚 タモ材



※イラストには、幅84cmを使用しています。

※本製品はフックを締めるための六角レンチは同梱されていません。棚セットや追加用クロスバー(単品)に付属している六角レンチもしくは市販品(4 mm)をご使用ください。


### 組立方法

※イラストには、幅84cmを使用しています。 各サイズ 共通

- ユニットシェルフ全体の組み立てについては、棚セットもしくは追加用帆立(単品) 付属の組立・取扱説明書をよく読み正しく組み立ててください。
- 棚セットの組立・取扱説明書の【ユニットシェルフ・パーツ必要数確認表】をご確認の上、必ず、必要数のクロスバーを取り付けてください。


1 初めに、床面保護の為、敷物を敷いてください。組み立て後の移動を避けるため、なるべく設置位置の近くで組み立ててください。

①棚板の四隅に固定されているフック用ボルトをお手持ちの六角レンチ(4 mm)を使って、フックが自由に動く状態までゆるめてください。




※お手持ちのマイナスドライバーなどで垂直に押し下げて、はずしてください。

2 棚板を取り付けます。



②フック用ボルトをお手持ちの六角レンチ(4 mm)で軽く締めます。(きつい状態から半回転程度ゆるめたくらいにしておきます)




③帆立、クロスバー、棚板が全てゆるめに取り付けられたら、ボルト類を締め込んでいきます。棚板のフック用ボルトは前面、背面と交互に少しずつ閉めるようにしてください。一か所のみをきつく締めてしまうと、棚がゆがんで装着されて締めにくなります。(詳細はセット本体の組立・取扱説明書をご参照ください。)

①棚板の全てのフックのボルトが図のような状態になるまでゆるめ、フックはハの字になるようにしてください。

#### 木製追加棚の場合


##### お願い(その他 注意)

フック用ボルトは裏側のメネジがはずれるほど、ゆるめないでください。




- ①追加棚の表面を上にし、ポイント①先に背面側(フック2箇所)を帆立の帆立柱に引っ掛けてから
- ポイント②前側のフックを指で手前に引きながら
- ポイント③前側の帆立柱に引っ掛け、押し込みます。

ポイント①  
引っ掛ける



ポイント②  
手前に引く



ポイント③  
押し込む



#### 注意

①取り付ける際、指をはさまないようにしてください。ケガをするおそれがあります。

#### 棚板のはめ込み

棚板がはまりにくい状態の時は、棚板上部を軽くたたいて棚板をはめ込んでください。はまらない場合は、全体的にフックを少しゆるめるようにすると、はまりやすくなります。

#### お願い(その他 注意)

●フック用ボルトを締める際は、1箇所ごときつく締めず、徐々に締め込みながら4か所を締めてください。先に1箇所をきつく締めてしまうと、次が締めにくくなる場合があります。

**Directions for Use**

**Stainless steel unit shelf**  
**Additional shelf Stainless steel**  
**Additional shelf Wooden**

**Moving the Product**

- When transporting the product for a home move, etc., disassemble it beforehand. Not doing so may cause injury, damage to the product or scratches on the floor.

**Disposal**

- To dispose of the product, follow the rules implemented by your local government.

**Care Instructions**

**Maintenance and Inspection**

- Do not use if damaged or deformed.
- Regularly check for any looseness or wobbling in the product, and retighten them if any looseness is found. This is to prevent injury, product damage and floor scratches.

**Care Instructions (Continued)**

**Maintenance for Wooden Parts**

- Do not leave a chemically treated cloth in contact with the product for a long time. Doing so may cause discolouration or peeling of the surface material.

**Maintenance for Wooden/Metal Parts**

- For regular cleaning, wipe with a soft, dry cloth.
- If the product is heavily soiled, clean it with a cloth soaked in a 3% to 5% neutral detergent solution and wipe off any detergent residue with a damp cloth. Then gently wipe with a soft, dry cloth and let the product dry naturally.

**Contact Information**

For enquiries regarding the product, please contact the store of purchase.

**User Guide**

Thank you for your purchase.  
 Read this User Guide before use to ensure correct assembly and use of the product. Store this guide in an easily accessible place for future reference.

26 September 2024

**Specifications**

**Stainless Steel Additional Shelf Board**

Product Name	Stainless steel unit shelf Additional shelf Stainless steel			
Specification	For W112 cm type	For W84 cm type	For W56 cm type	For W42 cm type
JAN	4550583922443	4550583922450	4550583922467	4550583922474
Product Dimensions	Approx. W1090 × D400 × H25 mm	Approx. W810 × D400 × H25 mm	Approx. W530 × D400 × H25 mm	Approx. W395 × D400 × H25 mm
Product Weight	Approx. 4.5 kg	Approx. 3 kg	Approx. 1.6 kg	Approx. 1.4 kg
Usage	Shelf Board for Stainless Steel Unit Shelf			
Withstand Load	Approx. 30 kg per shelf board			
Material	Metal (Stainless Steel)			
Surface Finish	Hairline Finish, Hook: Electropolishing			
Place of Origin	CHINA			

**Wooden Additional Shelf Board**

Product Name	Stainless steel unit shelf Additional shelf Oak			Stainless steel unit shelf Additional shelf Walnut			Stainless steel unit shelf SS additional shelf Ash		
Specification	For W84 cm type	For W56 cm type	For W42 cm type	For W84 cm type	For W56 cm type	For W42 cm type	For W84 cm type	For W56 cm type	For W42 cm type
JAN	4550583922412	4550583922429	4550583922436	4550583922481	4550583922498	4550583922504	4550584339455	4550584339462	4550584339479
Product Dimensions	Approx. W805 × D400 × H25 mm	Approx. W530 × D400 × H25 mm	Approx. W395 × D400 × H25 mm	Approx. W805 × D400 × H25 mm	Approx. W530 × D400 × H25 mm	Approx. W395 × D400 × H25 mm	Approx. W805 × D400 × H25 mm	Approx. W530 × D400 × H25 mm	Approx. W395 × D400 × H25 mm
Product Weight	Approx. 4.5 kg	Approx. 3 kg	Approx. 2.3 kg	Approx. 4.5 kg	Approx. 3 kg	Approx. 2.3 kg	Approx. 4.5 kg	Approx. 3 kg	Approx. 2.3 kg
Usage	Shelf Board for Stainless Steel Unit Shelf								
Withstand Load	Approx. 30 kg per shelf board * When the load is spread evenly across the shelf								
Materials	Shelf Board: MDF (Oak Veneer), Hook: Stainless Steel			Shelf Board: MDF (Walnut Veneer), Hook: Stainless Steel			Shelf Board: MDF (Ash Veneer), Hook: Stainless Steel		
Surface Finish	Shelf Board: Acrylic UV Coating, Hook: Electropolishing								
Place of Origin	CHINA								

**Important Information (Safety Advice)** The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.

⊘ Actions that are prohibited.    ⚠ Actions that must be taken.

**⚠ WARNING Hazards that may lead to death or serious injury**

- ⊘ **DON'Ts**
  - Do not leave unnecessary packaging materials within reach of small children. They may accidentally pull them over their head, cover their mouth and/or nose and suffocate.
  - Do not keep the fitting parts within reach of small children, and do not lose them. They may accidentally swallow small parts and choke.

- ⚠ **DOs**
  - Carefully read the User Guide provided with the shelf set\* or Additional Frame (sold separately) to ensure correct use. It contains important safety precautions for assembly and use of the product to prevent injury.

\* Shelf set is a set with frames, shelf boards and cross bars of Stainless Steel Unit Shelf series or Steel Unit Shelf series included.

**⚠ CAUTION Hazards that may result in injury or damage to the property**

- ⊘ **DON'Ts**
  - Do not install the shelf board onto the shelf of different depth. Doing so may cause the shelf board to fall, resulting in injury as it cannot be securely fixed.
  - Do not attempt to repair or modify. Doing so reduces the strength of the product and may lead to injury.

**⚠ CAUTION (Continued) Hazards that may result in injury or damage to the property**


- ⊘ **DON'Ts**
  - Do not place anything exceeding the withstand load or anything only on one side even if it is within the withstand load. Doing so may cause deformation or damage, leading to injury.
  - Do not use outdoors. Doing so may cause deformation or severe degradation, resulting in injury.

**Note (Other Caution)**

- When the wooden additional shelf board is installed, ventilate the room well at the early stage of use. The shelf board may contain a small amount of Formaldehyde, and those with chemical sensitivity or small children may experience allergic reactions.
- When the wooden additional shelf board is installed, avoid exposure to direct sunlight and heat or air from heating and cooling appliances such as an air conditioner and a heater. Not doing so may cause warping, cracking and discolouration.
- Do not use bleach or organic solvents, such as thinner, for cleaning. Doing so may cause discolouration or deformation.
- Wear gloves during assembly of the product. Doing so prevents unexpected injury.

**Parts / Part Names**

Apply to all sizes



\* [W 84 cm type] is used in the illustrations.


\* Hexagonal wrench required for tightening the hooks is not included in this product. Use a commercially available hexagonal wrench (4 mm) or the one included in the shelf set or Additional Cross Bar (sold separately).

**Assembly Instructions**

\* [W84 cm type] is used in the illustrations. Apply to all sizes


- For details on how to assemble the Unit Shelf, read the User Guide provided with the shelf set or Additional Frame (sold separately).
- Check the [Unit Shelf Part Quantity Checklist] in the User Guide of the shelf set, and make sure to attach the required number of cross bars.

**1** First, place an underlay to protect the floor. Assemble as close to the installation location as possible to reduce the need to move it afterwards. Loosen the hook bolts fixed to the four corners of (A) shelf board using your own hexagonal wrench (4 mm) until the hooks can move freely.



\* Remove it by pushing it down vertically with your own flathead screwdriver, etc.


Loosen all the hook bolts on (A) shelf board as shown in the illustrations, and let the hooks stay loose and diagonal.




**When Installing Wooden Additional Shelf Board**

**Note (Other Caution)**

Be careful not to loosen the hook bolts so much that the barrel nuts on the reverse side come off.




**2** Install the shelf board.



① Position the additional shelf board with its top side facing up.

- Point ① First, fit the frame poles into the 2 hooks on the back of the shelf board.
- Point ② While pulling the hook on the front of the shelf board towards you with your fingers,
- Point ③ fit the frame pole on the front of the unit shelf into the hook and push it down.




**⚠ CAUTION** Be careful not to get your fingers caught when installing the shelf board. Otherwise it may cause injury.

**Fitting the Shelf Board**

If it is difficult to fit the shelf board, gently tap the top side of the shelf board to fit it in place. If it still does not fit, slightly loosen all the hooks to make it fit easily.

② Lightly tighten the hook bolts with your hexagonal wrench (4 mm). (Leave them loose approximately by half a turn from the tightest state.)



**Note (Other Caution)** Do not fully tighten one hook bolt at a time but little by little on all four places in turn. If you tighten one hook bolt too much first, it will become difficult to tighten the remaining bolts.

③ After loosely attaching the cross bars and shelf board to the frames, tighten the bolts.  
 • Tighten the hook bolts on all corners (at the front and back) alternately and gradually. Fully tightening the hook bolts only on one side first may cause the shelf board to be attached aslant, making it difficult to tighten the remaining bolts. (Refer to the User Guide of the shelf set for the details.)"