

保存用

Retain for future reference

保存用

MUJI 無印良品

ステンレスユニットシェルフ オーク材棚セット・大
ステンレスユニットシェルフ オーク材棚セット・ワイド・大
ステンレスユニットシェルフ ウォールナット材棚セット・大
ステンレスユニットシェルフ ウォールナット材棚セット・ワイド・大

STAINLESS STEEL UNIT SHELF / OAK SHELF SET / L

STAINLESS STEEL UNIT SHELF / WIDE TYPE / OAK SHELF SET / L

STAINLESS STEEL UNIT SHELF / WALNUT SHELF SET / L

STAINLESS STEEL UNIT SHELF / WIDE TYPE / WALNUT SHELF SET / L

不锈钢组合架/白橡木搁板套装/大

不锈钢组合架/白橡木搁板套装/宽型/大

不锈钢组合架/胡桃木搁板套装/大

不锈钢组合架/胡桃木搁板套装/宽型/大

組立・取扱説明書

User Guide

组装 / 使用说明书

日本語

この度は本商品をお買い上げいただき、誠にありがとうございます。

1ページからお読みください。

English

Thank you for your purchase.

Read these instructions from Page 13.

中 文

本次承蒙惠购本产品，在此深表感谢。

请从第二十五页开始阅读。

使用说明书发行日期：2018年1月18日

333666171-001-004

MUJI 無印良品

保存用

ステンレスユニットシェルフ オーク材棚セット・大

ステンレスユニットシェルフ オーク材棚セット・ワイド・大

ステンレスユニットシェルフ ウォールナット材棚セット・大

ステンレスユニットシェルフ ウォールナット材棚セット・ワイド・大

組立・取扱説明書

この度は本商品をお買い上げいただき、誠にありがとうございます。

ご使用前に本書をよくお読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。

また、本書はいつでも確認できるように大切に保管してください。

もくじ

ページ

重要なお知らせ（安全上のご注意）	2～3
パーツリスト	4
各部の名称	4
組立方法	5～8
ご使用方法	9～10
お手入れ方法	10
ご使用に際して	11
製品仕様	12
お問い合わせ先	12

2018年1月18日

重要なお知らせ（安全上のご注意）

必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。

次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明

誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。



警告

使用者が死亡または重傷（※1）を負うことが想定される内容です。



注意

使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明

お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）



してはいけない「禁止」の内容です。



実行しなければならない内容です。

※1 重傷とは、失明やけが、やけど、骨折、中毒、感電などで後遺症が残るもの及び、治療に入院、長期の通院をするものをさします。

※2 傷害とは治療や入院や長期の通院を要しない、けが、やけどをさします。

※3 物的損害とは、家屋、家財にかかる拡大損害をさします。



警告



禁止

- お子さまが商品にぶら下がったり、登ったりさせないでください。商品の転倒や破損によりケガをするおそれがあります。
- 商品の上に立ったり、腰かけたり、踏み台代わりに使用したりしないでください。商品の転倒や破損によりケガや破損の原因になります。
- 上部のみに片寄って収納しないでください。バランスを崩し不安定になりやすく、商品が転倒してケガをするおそれがあります。
- 上部に重たいものは置かないでください。地震などで物が落ちたり、本体ごと倒れたりして、ケガをすることがあります。
- 商品の近くでストーブなどの暖房器具を使用しないでください。引火して火災の原因となります。
- 商品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因になります。
- 本体が破損した場合、直ちに使用を中止してください。破損したまま使用しますと、ケガをするおそれがあります。
- 梱包材は幼児の手の届くところに置かないでください。頭からかぶるなどしたときに口や鼻をふさぎ窒息するおそれがあります。



行う

- A V機器を置く場合は、そのA V機器の取扱説明書をよく読み正しく設置してください。また、十分に隙間をあけて通気性をよくしてご使用ください。電気製品の故障や火災の原因となります。
- 建物の壁や床、天井等に固定用金具（専用もしくは市販）や固定部材でしっかりと帆立を固定してください。地震などで商品が倒れ、ケガをすることがあります。

重要なお知らせ（安全上のご注意）

必ずお守りください。（つづき）

⚠ 注意

禁止	<ul style="list-style-type: none">●商品を連結した状態で持ち上げないでください。落下によるケガの原因になることがあります。●棚板を持って、持ち上げないでください。棚がはずれてケガや器物破損の原因になることがあります。●組み立てが不完全なまま使用しないでください。固定部分が外れてケガの原因になることがあります。●移動する際は、引きずらないでください。商品の破損、床面へのキズの原因となります。●本来の用途以外では使用しないでください。思わぬ事故やケガの原因となります。●耐荷重以上のものをのせたり、耐荷重内でも一部に片寄ってのせたりしないでください。変形や破損によりケガをするおそれがあります。●修理および改造はしないでください。製品の強度が弱くなりケガをするおそれがあります。
	<ul style="list-style-type: none">●使い始めるときは、室内の換気を十分にしてください。ホルムアルデヒド放散量の少ない木材を使用しておりますが、ホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。●組み立ては必ず2人以上で行ってください。1人では商品破損や商品落下などによりケガをする原因となります。●移動する際は収納物を取り除いてから、2人以上で移動させてください。1人で引きずったりするなど無理に移動させるとケガや商品が破損する原因となります。●引越しや部屋や階をまたぐような移動をする際は、組み立て前の状態に戻してから運んでください。パーツが外れて、ケガや商品が破損する原因となります。●強度を保つために必要なパーツ（P9 ユニットシェルフ・パーツ必要数確認表参照）は取り付けた状態で使用してください。強度パーツが不足していると強度が低下し、搖れや破損によりケガをする原因となります。

お願い（その他 注意）




禁止	<ul style="list-style-type: none">●高温（目安：35℃以上）や乾燥した場所（目安：湿度30%以下）で長期間設置はしないでください。製品の反りやゆがみ、割れなどが生じる原因になります。●棚板に直接熱いものや濡れたものを置かないでください。反りやゆがみ、割れ、変色などの原因になります。●直射日光や照明、ストーブやエアコンなどの冷暖房器具の熱や温風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になります。●本来の用途以外では使用しないでください。思わぬ事故やケガの原因となります。●棚板の上にビニール製品を長時間置かないでください。変色したり塗装がはげる原因となります。●梱包材は、開封後は自治体の指示に基づき、正しく破棄してください。●お手入れの際は、シンナーなどの有機溶剤を含んだ布で拭かないでください。変色や変形の原因となります。
	<ul style="list-style-type: none">●平坦で安定した場所に設置してください。不安定な場所での使用は、製品がゆがんだり、破損の原因になることがあります。●暖房器具を使用する場合は室内温湿度は適正に保つようにしてください。冬場などの暖房器具による室内の極端な乾燥は天然木材の割れや反りの原因となります。

パーツリスト


オーク材棚セット ウォールナット材棚セット 共通 / 大 ワイド・大 共通

※各リストはオーク材棚セット、ウォールナット材棚セットとともに共通です。

※各リストは 大 ワイド・大 サイズ共通ですが、イラストには ワイド・大 タイプを使用しています。

<p>Ⓐ帆立</p>  <p>× 2</p>	<p>Ⓑ棚板</p>  <p><表面></p> <p><裏面></p> <p>メネジ</p> <p>× 5</p>	
<p>Ⓒクロスバー</p>  <p>× 4</p>	<p>Ⓓアジャスター</p>  <p>× 4</p>	
<p>フィッティングパーツ</p>		
<p>ⓐボルト（クロスバー中心部）</p>  <p>× 2</p>	<p>ⓑ袋ナット（クロスバー中心部）</p>  <p>× 2</p>	
<p>ⓒボルト</p>  <p>× 8</p>	<p>ⓓ座金</p>  <p>× 8</p>	<p>ⓔ六角レンチ</p>  <p>× 1</p>

各部の名称



※組み立て方法は、オーク材棚セット、ウォールナット材棚セットともに共通です。

※各サイズの組み立て方法も共通ですが、イラストには **ワイド・大** タイプを使用しています。


！注意

- 組み立ては、必ず2人以上で行ってください。
1人では商品破損や商品落下などによりケガをする原因となります。
- 組み立てには電動工具は使用しないでください。
無理に負荷がかかると、商品破損によりケガをすることがあります。
- 組み立て後、一週間程度経過しましたら、ボルトを締め直してください。
使い始めはゆるんでいる場合があり、そのまま使用すると破損、ケガの原因となります。
- 組み立て、設置の際は、床や既存の家具がキズつかないようご注意ください。

組み立ての前にお読みください

※棚板のフックに取り付けてある白いプラスチックは輸送中のつぶれ防止パーツです。

組み立てる際に取りはずしてください。




※マイナスドライバーなどで垂直に押し下げて、はずしてください。

1

はじめに、組み立てる場所に敷物を敷いて床面を保護してください。

(組み立て後の移動を避けるため、なるべく設置位置の近くで行ってください。)

④アジャスターを③帆立に取り付けてください。





組立方法（つづき）

※イラストにはワイド・大タイプを使用しています。

2


⑧棚板の四隅に固定されているフック用ボルトをそれぞれ⑨六角レンチでフックが自由に動く状態までゆるめてください。

※棚の全てのフックのボルトが図のような状態になるまで
ゆるめ、フックはハの字になるようにしてください。



お願い（その他 注意）

フック用ボルトはゆるめすぎない
でください。裏側から
メネジがはずれます。



3

最下段の棚板を取り付けます。


①⑧棚板の表を上にして斜めにし、背面側のフック2箇所をまず⑩帆立の帆立柱に引っ掛け、

ポイント① 前面のフックを指で手前に押さえながら ポイント② 帆立柱に引っ掛けて押し込みます。ポイント③

②フック用ボルトを⑨六角レンチで軽く締めます。（きつい状態から半回転程度ゆるめたぐらいにしておきます）


①

ポイント② 押さえる → ポイント③ 押し込む




①

ポイント① 引っかける



② 軽く締める



取り付ける際、指をはさまないよう
ご注意ください。ケガをする
おそれがあります。

棚板のはめ込み

棚板がはまりにくい状態の時は、棚板上部を軽くたたいて棚板をはめ込んでください。それでもはまらない場合は、全体的に少しフックをゆるめるようにすると、はまりやすくなります。

お願い (その他 注意)


フック用ボルトを軽く締める
際は締めすぎないでください。
残りの棚板がはまりにくくなる
場合があります。

組立方法（つづき）

※イラストにはワイド・大タイプを使用しています。

4

次に最上段の④棚板を手順③と同じ要領で取り付けます。




軽く締めておく

5

手順③と同じ要領で残りすべての④棚板を取り付けてください。


※収納するものの高さに応じて、取り付け位置を決めてください。




軽く締めておく

6

④クロスバーの中心を重ねて
⑤袋ナット（クロスバー中心用）と
⑥ボルト（クロスバー中心用）を
軽く締めてください。



クロスバーの重ね方



※それぞれのクロスバーの向きを上図のように重ねてください。平らなほうからボルトを通して、へこんでいるほうを袋ナットで軽く締めます。なお、クロスバーには上下の区別はありません。


組立方法（つづき）

※イラストには「ワイド・大」タイプを使用しています。

7

組み立てたクロスバーを、背面から④座金と⑤ボルトで⑥帆立に固定します。
その際、クロスバーは⑦袋ナットが外向きになるように取り付けます。


お願い (その他 注意)	●クロスバーのボルト穴の位置が合わない場合は、本体がゆがんでいる場合がありますので、棚板のフック用ボルトを少しゆるめてください。 ●クロスバーの④ボルトを締める際は全体を少しずつ締めてください。一箇所をきつく締めてしまうと、次が締めにくくなる場合があります。
-----------------	--



8


最後に、組立手順③～⑤で軽く締めた⑥棚板のフック用ボルトと、組立手順⑥～⑦で軽く締めたクロスバーの⑧⑨ボルトを、⑩六角レンチできつくなるまで締めてしっかり固定します。(全部で30箇所)

お願い (その他 注意)	棚板のフック用ボルトは、前面、背面と交互に少しずつ締めるようにしてください。1箇所をきつく締めてしまうと棚がゆがんで装着され、最後のフックが締めにくくなります。
-----------------	--



9

商品設置後に商品がガタつかないよう、⑪アジャスターで調整してください。



ご使用方法

[ユニットシェルフ・パーツ必要数確認表]

帆立サイズ		特大	大	中	小	ミニ
幅112cm	パーツ名	4	3	3	2	3
幅84cm	棚板	2	2	1	1	0
	クロスバー	4	3	3	2	3
幅56cm	棚板または帆立補強パーツ	2	2	1	1	0
	クロスバー	4	3	3	2	3
幅42cm	棚板	2	2	1	1	0
	クロスバー	4	3	3	2	3

※ **ワイド・大** をお持ちの方は  を確認してください。

※ **大** をお持ちの方は  を確認してください。


※組み立て位置によっても強度は異なります。必要数量以上でも一部に片寄っていると強度に影響する場合があります。

特に上下を空けたり、長い間隔で空けると揺れの原因にもなりますので、設置の際は均等になるようにご注意ください。

[移動について]


<組み立てた状態で動かす場合>

- 棚板を持って、持ち上げないでください。
棚がはずれて物が落ち、思わぬケガや器物破損の原因になることがあります
組立後の移動は必ず収納物を取り除いてから
2人以上で左右から帆立部分をしっかり持って
移動してください。
- 床面を引きずったり、押したりしないでください。
床面のキズや破損の原因になります。



<引越しなどで運ぶ場合>

- 引越しや部屋や階をまたぐような移動をする際は、組み立て前の状態に戻してから運んでください。
(パーツがはずれてケガや商品が破損する原因となります)




ご使用方法（つづき）

⚠ 収納する際のご注意

- 上部のみに片寄って収納しないでください。バランスを崩し不安定になりやすく、商品が転倒してケガをすることがあります。
- 上部に重たいものは置かないでください。地震などで物が落ちたり、本体ごと倒れたりして、ケガをすることがあります。

🚫 不安定になりやすい使い方 (例)



[廃棄について]

- 廃棄の際は、居住地域自治体の指示に従い、処分してください。

お手入れ方法

保守・点検

- 破損、変形した状態では使用しないでください。
- 脚、ボルト類は、ゆるみやぐらつきがないか時々点検し、ゆるみはじめたらしっかりと締め直してください。ケガや破損、床面のキズの防止になります。また、がたつきやきしみ音の原因となります。
- 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

汚れについて

[木部]

- 塗装面のホコリは、やわらかい布または、ハタキなどで軽く払ってください。硬い布やほこりなどが付着した状態でこすると細かいキズの原因となります。
- 汚れがひどい時は、3-5%程度に薄めた中性洗剤を浸した布で汚れを落とし、その後水で浸した布で洗剤をよくふき取ってください。次に乾いたやわらかい布で軽く拭いた後で自然乾燥してください。
- 化学雑巾を長時間接触させないでください。表面がはがれたり変色したりするおそれがあります。
- 直接熱いものや濡れたものを置かないでください。反りやゆがみ、割れ、変色などの原因になります。濡れる可能性のあるものを置く場合は敷物を敷くなどしてください。
- 底のざらついたものを直接置かないでください。引きずったりするとキズがつくおそれがあります。

[金属部]

- 毎日のお手入れはやわらかい布で乾拭きしてください。
- 汚れがひどい時は、3-5%程度に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤をよくふき取ってください。次に乾いたやわらかい布で軽く拭いた後で自然乾燥してください。
- 金属部分には、潤滑油を薄く塗り、やわらかい布で軽く拭きとってください。

ご使用に際して

天然木製品についてのおことわり

- 本商品は天然木を使用しているため、木目や色合い等、天然木材特有の個体差があります。
そのため、商品として木目や色調に差がありますが、あらかじめご了承ください。
- 天然木（突板）は下記の条件により、割れや反りなどが発生することがありますので、ご注意ください。
 - ①直射日光のある場所でのご使用は出来る限りお避けください。
どうしても直射日光が当たる場合は、カーテンなどで出来る限り避けてご使用ください。
 - ②冷暖房器具の近くでのご使用は出来る限りお避けください。必ず冷暖房風が直接当たらないようにしてご使用ください。
 - ③特に冬の暖房による室内の極端な乾燥は、天然木の割れ、反りを発生させる原因になります。

ホルムアルデヒドの対策について

- ホルムアルデヒドは

ホルムアルデヒドとは、シックハウス症候群の原因物質の一つと言われています。常温で気化する無色で刺激臭のある化学物質で、家具はもとより建築資材、壁紙を貼る接着剤などに含まれています。少しづつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

- お部屋の換気をしてください



注意

家具を設置の際は、室内の換気を十分にしてください。化学物質に敏感な体质の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。複数の家具を同時に設置した場合は特に窓をできるだけ広く開け、十分な換気を行ってください。室内的温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は特に換気をするようご注意ください。換気効率を上げるため、複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

- 化学物質に敏感な体质のお客様へ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質は許容量に個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体质の方もいらっしゃいます。現段階の無印良品の家具におきましても少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。
アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

- 無印良品の家具は、梱包材にホルムアルデヒド吸着・分解シート※を入れて出荷しています。

(※ホルムアルデヒド吸着・分解シート：アイシン精機(株)との共同開発)

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お手元に届くまでに少しでもホルムアルデヒド濃度を低下させるために、ホルムアルデヒド吸着・分解シートを入れています。

※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

製品仕様

品 名	ステンレスユニットシェルフ オーク材棚セット・大	ステンレスユニットシェルフ オーク材棚セット・ワイド・大	ステンレスユニットシェルフ ウォールナット材棚セット・大	ステンレスユニットシェルフ ウォールナット材棚セット・ワイド・大
製 品 寸 法	幅 580 × 奥行410 × 高さ 1755 (mm)	幅 860 × 奥行410 × 高さ 1755 (mm)	幅 580 × 奥行410 × 高さ 1755 (mm)	幅 860 × 奥行410 × 高さ 1755 (mm)
製 品 質 量	約 25.1 kg	約 33.0 kg	約 25.1 kg	約 33.0 kg
用 途	収納家具			
耐 荷 重 棚板1枚あたり	約 30 kg (※棚全体での均等に荷重をかけた場合)			
全 耐 荷 重	約 100 kg			
材 質 (オーク材棚セット)	帆立 : ステンレス鋼 棚板 : MDF (オーク材突板) 表面加工 : 棚板 アクリルUV塗装 : フレーム 電解研磨			
材 質 (ウォールナット材棚セット)	帆立 : ステンレス鋼 棚板 : MDF (ウォールナット材突板) 表面加工 : 棚板 アクリルUV塗装 : フレーム 電解研磨			

Made in Taiwan

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様室までご連絡ください。

株式会社 良品計画

〒170-8424

東京都豊島区東池袋 4-26-3

お客様室でんわ

 0120-14-6404

受付時間 ■平日 10:00 ~ 21:00
■土・日・祝 10:00 ~ 18:00



Retain for future reference

STAINLESS STEEL UNIT SHELF / OAK SHELF SET / L

STAINLESS STEEL UNIT SHELF / WIDE TYPE / OAK SHELF SET / L

STAINLESS STEEL UNIT SHELF / WALNUT SHELF SET / L

STAINLESS STEEL UNIT SHELF / WIDE TYPE / WALNUT SHELF SET / L

User Guide

Thank you for your purchase.

Please read the instructions before use to ensure correct use and assembly of this product.

Please store this user guide in an easily accessible place for future reference.

Table of Contents	Pages
Important Information (Safety Advice)	14 – 15
Parts List	16
Part Names	16
Assembly Instructions	17 – 20
Directions for use	21 – 22
Care Instructions	22
Tips for using the product	23
Specifications	24
Contact Information	24

2018. 1. 18

Important Information (Safety Advice) These instructions must be followed.

This manual contains important information for safe use in order to prevent harm to the user and others as well as damage to property.

Please note the following contents (indications and graphic symbols) before reading the main contents of this manual, and follow the instructions given.

• Explanations on Indications

If the product is used incorrectly, the degree of injury or damage that may arise is classified and explained with the following symbols.

 Warning	Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury*1 to the user.	 CAUTION	Indicates a hazard with a level of risk which, if not avoided, could result in injury*2 to the user or property damage*3.
--	---	--	---

• Explanations on Graphic Symbols

Instructions are given in the forms of the following graphic symbols. (Examples of graphic symbols are as follows.)

 PROHIBITED: Actions that are prohibited.	 COMPULSORY: Actions that must be taken.
--	---

*1 "Serious injury" indicates blindness, injuries, burns, bone fractures, poisoning, or electric shocks which have long term effects and require hospitalisation and/or long-term hospital visits for treatment.

*2 "Injury" indicates injuries or burns which do not require hospitalisation or long-term hospital visits for treatment.

*3 "Property damage" indicates expanded damage involving house and household property.

 Warning	
 PROHIBITED	<ul style="list-style-type: none">Do not allow children to hang from or climb on the product. Doing so may cause the product to tip over or become damaged, resulting in injury.Do not stand on or lean against this product or use it as a stepladder. Doing so may cause the product to tip over or become damaged, resulting in injury or damage to property.Do not store items only in the top section. Doing so may cause the product to become unbalanced and tip over, resulting in injury.Do not place heavy items on top of the product. In the event of an earthquake, such objects may fall off or cause the product to tip over, resulting in injury.Do not use near a heating appliance such as a heater. Doing so may cause the product to catch fire.Do not place the product on the power cord of an electric appliance. Doing so may damage the cord, resulting in electric shock or fire.Stop using this product immediately if it is damaged. Continuing to use this product when damaged may result in injury.Keep all packaging materials out of reach of small children. A child may suffocate if they pull packaging materials over the head covering the mouth or nose.
 Do's	<ul style="list-style-type: none">When placing AV equipment on this product, be sure to thoroughly read the instruction manual of the AV equipment and use it correctly. Also, ensure there is sufficient space for ventilation. Failure to do so may cause damage or fire in the electric product.Fix the frame securely to the walls, floor or ceiling of the building using the fixtures (specialised or commercially available) or fixing materials. In the event of an earthquake, this product may tip over resulting in injury.

Important Information (Safety Advice)

These instructions must be followed.
Continuance of the previous page.

! CAUTION

 PROHIBITED	<ul style="list-style-type: none">Do not lift products that are joined together. The product(s) may fall, causing injury.Do not hold the shelves when lifting the shelving unit. The shelf may detach from the product, causing injury or damage.Do not use the product if it is not fully assembled. Fixed parts may come off, causing injury.Do not drag the product when moving it. Doing so may cause injury, damage or scratches to the floor.Use this product only for its intended purpose. Failure to do so may result in an unexpected accident or damage to the product.Do not exceed the withstand load, or place items that are within the withstand load on only one part of the product. Doing so may cause the product to become deformed or damaged, resulting in injury.Do not attempt to repair or modify the product. This weakens the product, and may cause injury.
 Do's	<ul style="list-style-type: none">Ventilate the room well before use. Wooden materials that only contain a small amount of formaldehyde are used. However, formaldehyde contained in the adhesive for wooden parts may still remain, and those with chemical sensitivity and infants may experience an allergic reaction.Assemble the product with two or more people. Assembling alone may result in damage to the product or injury due to the product falling.When moving the product, remove the items stored in the product and move it by two or more people. Dragging the product or attempting to move it alone may result in injury or damage to the bed.When moving the product between rooms or floors such as when moving house, disassemble it before moving. Parts may come off, resulting in injury or damage to the product.Be sure to use with all parts required for maintaining strength (see [Unit Shelf - Required Parts Quantity Check List] on P.21) attached correctly to the product. Strength of the product is reduced if used without the necessary strengthening parts, which may cause shaking or damage that results in injury.

Note (Other Cautions)


 PROHIBITED	<ul style="list-style-type: none">Do not leave the product in a hot (approx. 35°C or higher) or dry (30% humidity or less) environment for a long period. Doing so may cause warping, distortion or cracks.Do not place hot or wet items directly on the shelves. Doing so may cause warping, distortion, cracks or discolouration.Do not expose the product to direct sunlight or lighting, or hot or cold air from a heating or cooling equipment such as a heater or air conditioner. Doing so may cause warping, distortion, cracks or discolouration.Use this product only for its intended purpose. Failure to do so may result in an unexpected accident or damage to the product.Do not leave vinyl products on the shelves for long periods. Doing so may result in discolouration or peeling of the coating.Please dispose of the packing materials in accordance with the regulations of your local government after unpacking the product.Do not wipe using a cloth that contains organic solvent such as thinner. It may cause deformation or discolouration.
 Do's	<ul style="list-style-type: none">Use in a flat and stable place. Using the product in an unstable place may cause warping or damage to the product.When using a heating appliance, make sure the indoor temperature and humidity is maintained at an optimum level. The use of heating appliances in the winter may cause the room to become dry, resulting in cracking or warping of natural wooden materials.

Parts List


* Each list applies to both oak shelf set and walnut shelf set models.

* Each list applies to both L and WIDE TYPE / L models, but illustrations are of the WIDE TYPE / L model.

Parts

AFrame

× 2

BShelf Board

× 5

CCross Bar

× 4

DAdjuster

× 4

Fitting Parts

aBolt (cross bar centre section)

× 2

bCap nut (cross bar centre section)


× 2

cBolt

× 8


dWasher

× 8


eHexagonal wrench

× 1

Part Names



L

(Completion Diagram)

WIDE TYPE / L

Assembly Instructions

* The assembly method applies to both oak shelf set and walnut shelf set models.

* The assembly method also applies to both sizes, but illustrations are of the **WIDE TYPE / L** model.




CAUTION

- Assemble the product with two or more people.
Assembling alone may result in damage to the product or injury due to the product falling.
- Do not use power tools to assemble the product.
Placing unnecessary strain on the product may result in damage or injury.
- Re-tighten all bolts approximately one week after assembly.
Bolts may be loose at the start of use, but continued use in this state may result in damage or injury.
- Be careful not to damage the floor and existing furniture when assembling and installing the product.

Be sure to read these instructions carefully before assembling the product.

* White plastic parts attached to shelf board hooks are attached to prevent damage during transportation.
Remove them before assembly.




* Push the part down using a flat-blade screw driver.

1

First, lay a rug or sheet where you intend to assemble the product in order to protect the floor surface.
(In order to avoid the need to move the product after assembly, assemble it near to where it will be used.)

Attach ④ adjuster to ① frame.




Assembly Instructions (Continued)

* Illustrations are of the
WIDE TYPE / L model.


- 2** Loosen the hook bolts fixed on the four corners of **B** shelf board using **e** hexagonal wrench until they are freely movable.

* Loosen the bolts on all hooks on the shelf until they form inverted v shape as depicted below.



Note (Other Cautions)


Do not over-loosen the hook bolts. The female screw can be unscrewed from the reverse.



- 3** Install the bottom shelf board.

① Point ① Slant **B** shelf board with the top facing upwards, and hook the two hooks on the back onto the **A** frame pillar. Point ② Hold the front hook with your finger Point ③ while hooking onto the frame pillar.

② Lightly tighten the hook bolts using **e** hexagonal wrench. (If tight, loosen by half a turn)



Be careful not to pinch your fingers when attaching. Doing so may cause injury.

Insertion of Shelf Board

Lightly tap the upper part of the shelf board if it is difficult to insert. If it still cannot be inserted, loosen all of the hooks to make it easier to insert.

Note (Other Cautions)


Do not over-tighten the hook bolts when tightening them lightly. Other shelf boards may not be easy to insert.

Assembly Instructions (Continued)

* Illustrations are of the
WIDE TYPE / L model.

4

Next, attach the top **(B)** shelf board as described in step **3**.




Lightly tighten

5

Install all remaining **(B)** shelf boards as described in step **3**.


* Adjust the installation position based on the height of items to be stored.




Lightly tighten

6

Lay the centres of **(C)** cross bars each other, and loosely tighten them using the **(b)** cap nut (for cross bar centre) and **(a)** bolt (for cross bar centre).



Laying cross bars with each other




* Lay cross bars with each other in the direction depicted above. Insert the bolt from the flat side, and loosely tighten cap nut at the indented side. There is no difference between top and bottom sides of the cross bar.

Assembly Instructions (Continued)

* Illustrations are of the
WIDE TYPE / L model.


- 7** Fix the assembled cross bar to **(A)** frame from behind using **(d)** washer and **(c)** bolt.
At this time, attach the cross bar with **(b)** cap nut facing outwards.

Note (Other Cautions)	<ul style="list-style-type: none"> The main unit may be slightly crooked if the positions of the cross bar bolt holes do not align. In this case, slightly loosen the shelf hook bolts. Gradually tighten all bolts when tightening the cross bar (c) bolts. Fully tightening one bolt may make the other bolts difficult to tighten.
---------------------------------	--




- 8** Lastly, use **(e)** hexagonal wrench to fully tighten the hook bolts for **(B)** shelf boards loosely tightened in steps **3** to **5** and crossbar **(a)** **(c)** bolts loosely tightened in steps **6** and **7**. (Total 30 parts)

Note (Other Cautions)	Alternately tighten the shelf board hook bolts on the front and back until they are fully tightened. If only one section is securely tightened, the shelf will be crooked and the last hook will be difficult to tighten.
---------------------------------	---



- 9** Adjust the **(D)** adjusters so that the product is not shaky after installation.



Directions for use

[Unit Shelf - Required Parts Quantity Check List]

Frame Size		XL	L	M	S	MINI
Part Name						
Width: 112cm	Shelf	4	3	3	2	3
	Cross Bar	2	2	1	1	0
Width: 84cm	Shelf or frame reinforcement parts	4	3	3	2	3
	Cross Bar	2	2	1	1	0
Width: 56cm	Shelf or frame reinforcement parts	4	3	3	2	3
	Cross Bar	2	2	1	1	0
Width: 42cm	Shelf	4	3	3	2	3
	Cross Bar	2	2	1	1	0

* Check  for the **WIDE TYPE / L** product.

* Check  for the **L** product.


* Strength differs depending on the installation position. Attaching more than the required amount to one section may also affect the strength.

Be careful to install the shelves equally as leaving the space between the shelves too high may cause the product to sway.

[Moving the Product]


<Moving the assembled product>

- Do not lift the shelving unit by holding a shelf. The shelf may come off and the things on it may fall to cause injury or damage to property. When moving the product after assembly, remove the things on the shelf, and firmly and carefully hold the frames from both sides with two or more people.
- Do not drag or push this product to move it. It may cause damage or scratches on the floor.




<Carrying when Moving House or etc.>

- When moving the product between rooms or floors such as when moving house, disassemble it before moving. (Parts may come off, resulting in injury or damage to the product)





Holding Correctly



How to Use (Continued)

Precautions for Storing Items

- Do not store items only on the upper section. Doing so may cause the product to become unbalanced and unstable, and tip over, resulting in injury.
- Do not place heavy items on the upper shelves of the product. In the event of an earthquake, such objects may fall off or cause the product to tip over, resulting in injury.



[Disposal]

- Please dispose of this product in accordance with the regulations of your local government.

Care Instructions

Maintenance and Inspection.

- Do not use this product if it is damaged or deformed.
- Periodically check for any looseness in the shelves and bolts, and re-tighten them if necessary.
Doing so will prevent injury, damage or scratches to the floor. Looseness also causes wobbling and creaking.
- If any insect damage is found, take measures to exterminate the insects immediately. If left untreated, insect damage may grow.

Stains

[Wooden Parts]

- Lightly wipe off dust from the coated surface with soft cloth or duster. Rubbing the surface when dusty or with a stiff cloth causes small scratches.
- If the product is particularly dirty, remove the dirt with a cloth soaked into neutral detergent diluted to 3 to 5%. Then wipe off the residual detergent with a wet cloth. Next, gently wipe off with soft, dry cloth and let the product dry naturally.
- Do not leave a chemical wipe on the product for a long time. It may cause discolouration or peeling of the surface.
- Do not place hot or wet items directly on the product. Doing so may cause warping, distortion, cracks or discolouration.
Place a mat underneath an item that may be wet.
- Do not place an item that has a rough surface on the base directly onto the product. Dragging such items may cause scratches.

[Metallic Parts]

- For daily care, wipe them with a soft, dry cloth.
- If the product is particularly dirty, remove the dirt with a cloth soaked into neutral detergent diluted to 3 to 5%. Then wipe off the residual detergent with a wet cloth. Next, gently wipe off with soft, dry cloth and let the product dry naturally.
- Apply a thin coating of lubricant to metallic parts, and wipe off with soft cloth.

Tips for using the product

Caution for Natural Wood Products

- Variations in wood grain and colour may occur because the product is made with natural wood. Therefore, please note that your product may look different to the store display model.
- Please note that cracks and warping may occur in natural wood (sliced veneer) in the following conditions.
 - ① Avoid use in a place with high temperatures or humidity or in direct sunlight wherever possible. If use in direct sunlight is unavoidable, reduce the amount of sunlight wherever possible using curtains, etc.
 - ② Avoid use near heaters or air conditioners wherever possible. Be sure that the air from heaters or air conditioners does not come into direct contact with the product.
 - ③ In particular, air from heaters in the winter season is particularly dry and can easily cause cracks and warping in natural wood.

Measure Against Formaldehyde

- What is Formaldehyde?

Formaldehyde is said to be one of the causes of sick house syndrome. It is a colourless, pungent smelling compound that vaporizes at room temperature, and is found in such items as furniture, building materials and wallpaper adhesives. Since it is eventually diffused, staying in a room contaminated with formaldehyde for a long time may cause eye and throat irritation. A high concentration of formaldehyde may cause breathing difficulties.

- Ventilate the room.



CAUTION

Ventilate the room well when installing furniture. Small children and those who are sensitive to chemicals may have an allergic reaction.

Formaldehyde is easily dispersed in the air. Therefore, be sure to ventilate the room regularly.

In particular, be sure to open the window as wide as possible and thoroughly ventilate the room when assembling a number of furniture items at the same time. When the room temperature gets high, more formaldehyde is likely to be released. If the room is closed for a long period of time in summer, be sure to ventilate the room. We recommend opening more than one window, or using a device such as a ventilator fan, electrical fan or circulator to increase ventilation efficiency.

- For Persons Who are Sensitive to Chemicals

There are individual differences in resistance to chemicals related to sick house syndrome, not just formaldehyde.

Therefore, some people may have a reaction to chemicals even if the concentration is below the indoor concentration guideline value (indoor concentration value of formaldehyde considered acceptable for a healthy environment). At present, MUJI furniture products are made with materials that contain as little formaldehyde as possible, but this does not guarantee that no formaldehyde is emitted at all.

We recommend consulting a physician if you experience any allergic symptoms.

- MUJI furniture is shipped with a formaldehyde absorbing/decomposing sheet * included in the packaging material.

* Formaldehyde absorbing/decomposing sheet: Jointly developed with Aisin Seiki Co., Ltd.

When used in small spaces, formaldehyde may be re-absorbed by the material if there is nowhere for it to dissipate. Formaldehyde absorbing/decomposing sheets are used to reduce the concentration of formaldehyde as much as possible before the product reaches you.

* Effectiveness of the "formaldehyde absorbing/decomposing sheet" in the packaging will have reduced, and it can be disposed of as burnable rubbish.

Specifications

Product name	STAINLESS STEEL UNIT SHELF / OAK SHELF SET / L	STAINLESS STEEL UNIT SHELF / WIDE TYPE / OAK SHELF SET / L	STAINLESS STEEL UNIT SHELF / WALNUT SHELF SET / L	STAINLESS STEEL UNIT SHELF / WIDE TYPE / WALNUT SHELF SET / L
Product dimensions	W580 x D410 x H1755(mm)	W860 x D410 x H1755(mm)	W580 x D410 x H1755(mm)	W860 x D410 x H1755(mm)
Product weight	Approx. 25.1kg	Approx. 33.0kg	Approx. 25.1kg	Approx. 33.0kg
Usage	Storage Furniture			
Withstand load Per shelf	Approx. 30kg (*When evenly loaded)			
Total withstand load	Approx. 100kg			
Materials (OAK SHELF SET)	Frame : Stainless steel Shelf : MDF (Oak veneer) Surface finish : Shelf: Acrylic UV coating : Frame: Electrolytic polishing			
Materials (WALNUT SHELF SET)	Frame : Stainless steel Shelf : MDF (Walnut veneer) Surface finish : Shelf: Acrylic UV coating : Frame: Electrolytic polishing			

Made in Taiwan

Contact Information

For your inquiry about the product, please contact the store where you bought it.

- 不锈钢组合架/白橡木搁板套装/大
- 不锈钢组合架/白橡木搁板套装/宽型/大
- 不锈钢组合架/胡桃木搁板套装/大
- 不锈钢组合架/胡桃木搁板套装/宽型/大

组装 / 使用说明书

本次承蒙惠购本商品，在此深表感谢。

使用前请务必仔细阅读本文，并在对内容充分理解的基础上再正确组装和使用。

此外，请务必妥善保管本文，以备随时进行确认。

目录

页

重要通知 (安全注意事项)	26 ~ 27
配件清单	28
各部位名称	28
组装步骤	29 ~ 32
使用方法	33 ~ 34
保养方法	34
使用注意事项	35
产品规格	36
联系方式	36

2018年1月18日

重要通知(安全注意事项)

请务必遵守。

为了防止使用者或他人遭受危害和经济损失, 本文中记述了确保安全且正确使用的重要内容。

请在充分理解下述内容(标示/图形符号)的基础上仔细阅读本文, 并严格遵守所述事项。

●标示说明

按错误使用所造成的危害或损失程度进行分类说明。



警告

可能会导致使用者死亡或重伤(※1)的内容。



注意

可能会导致使用者遭受伤害(※2)或物质损失(※3)的内容。

●图形符号说明

通过以下图形符号对应严守的内容进行说明。(以下为图形符号范例。)



不得执行的“禁止”内容。



必须执行的“强制”内容。

※1 所谓重伤, 是指因失明或受伤、烫烧伤、骨折、中毒、触电等原因而留下后遗症以及需住院治疗、长期就医的伤势。

※2 所谓伤害, 是指无需治疗或住院、长期就医的受伤、烫烧伤。

※3 所谓物质损失, 是指住房、家具财产相关的连带损失。

<h3>⚠ 警告</h3>	
禁止	<ul style="list-style-type: none">●请勿让儿童在商品上悬吊或攀爬。否则可能导致商品倾倒或损坏而发生受伤的危险。●请勿在商品上站立、凭靠、将其作为脚踏使用。否则可能因商品倾倒或损坏而导致受伤或损坏。●请避免仅在上方收纳物品。否则容易因失衡而不稳定, 导致商品倾倒而发生受伤的危险。●请勿在上部放置重物。地震等会导致重物落下或本体倾倒而造成受伤。●请勿在商品附近使用火炉等暖气设备。否则可能导致起火而发生火灾。●请注意产品不要压住家电产品的电源线。否则可能会因电源线断裂而导致触电、火灾。●主体破损时, 请立即停止使用。破损后如果持续使用, 可能会导致受伤。●包装材料请放置于幼儿无法触及的场所。否则可能因包装材料套住头部等阻碍嘴或鼻的呼吸而导致窒息的危险。
严守	<ul style="list-style-type: none">●放置录像机时, 须仔细阅读该录像机的说明书以正确设置。再者, 使用时要留充分的间隙以确保通风透气。否则可能引起电器故障或火灾。●请在建筑物的墙壁、地板和天花板等上面使用固定用的金属零件和固定构件将竖杆固定牢靠。地震等会导致商品倾倒而造成受伤。

重要通知(安全注意事项)

请务必遵守。(续)

⚠ 注意	
 禁止	<ul style="list-style-type: none">● 请勿在商品联结的状态将其抬起。否则可能因物品掉落而导致受伤。● 请勿抓住搁板抬起。有可能导致搁板脱落造成受伤或器具损坏。● 组装完成之前请勿使用。否则可能因固定部位脱落而导致受伤。● 移动时, 请勿在地板上拖动。否则可能导致商品损坏、地板受伤。● 请勿用于原本用途以外的其他用途。否则可能导致意外事故而受伤。● 请勿放置耐载荷以上的物品, 即使在耐载荷以内也请避免一侧偏重。否则可能导致变形或损坏而造成受伤。● 请勿擅自维修及改造。否则可能导致产品强度下降, 造成受伤。
 严守	<ul style="list-style-type: none">● 刚开始使用时, 请务必对室内进行充分换气。虽然使用了甲醛散发量少的木材, 但仍可能有甲醛残留物, 易导致化学物质过敏体质者及婴幼儿等出现过敏症状。● 组装时, 请务必确保两人以上共同作业。一人的话可能会因商品破损或掉落而造成受伤。● 移动时, 清理收纳物品后, 请确保两人以上共同作业。如果单人拖动等强行搬动, 则可能导致人体受伤或商品损坏。● 因搬家等原因而需跨越房间或楼梯进行移动时, 请将其恢复组装前状态后再搬动。零部件脱落可能会导致受伤或商品破损。● 请在安装好保持强度必需零件(请参阅P33组架·零件必要数确认表)的状态下使用。如果缺乏强度零件, 强度会下降, 导致摇动或破损而受伤。



请求(其他注意事项)	
 禁止	<ul style="list-style-type: none">● 请勿长期设置于高温场所(参考: 温度在35°C以上)或干燥的场所(参考: 湿度在30%以下)。否则可能导致产品弯曲、变形或开裂等。● 请勿直接在搁板上放置热的或湿的物品。否则可能导致弯曲或变形、开裂、变色等。● 请勿使商品直接受到阳光和照明直射、以及火炉和空调等冷暖气器具的热源及暖风直吹。否则可能导致弯曲或变形、开裂、变色等。● 请勿用于原本用途以外的其他用途。否则可能导致意外事故而受伤。● 请勿长期在搁板上放置塑料制品。否则可能导致变色或涂漆剥落。● 请按各地官方规定对开箱后的包装材料进行正确的废弃处理。● 清洁时, 请勿使用带稀释剂等有机溶剂的布擦拭。否则可能导致变色或变形。
 严守	<ul style="list-style-type: none">● 请设置于平坦、稳定的场所。如果在不稳定场所使用, 则可能导致产品变形、损坏。● 使用暖气器具时, 请保持适当的室内温湿度。冬季等如果使用暖气器具使室内极端干燥, 有可能导致天然木材开裂或弯曲。

配件清单


白橡木搁板套装 胡桃木搁板套装 通用/ 大 宽型/大 通用

※各清单中，白橡木搁板套装/胡桃木搁板套装皆共通。


※各列表均是 大 宽型/大 尺寸通用，解说图仅介绍 宽型/大 尺寸。

Ⓐ立杆		× 2	Ⓑ搁板		× 5 <表面> <背面> 螺母
Ⓒ交叉杆		× 4	Ⓓ调节旋钮		× 4

组装零件

ⓐ螺栓(交叉杆中心部分)		× 2	ⓑ盖形螺母(交叉杆中心部分)		× 2			
ⓒ螺栓		× 8	ⓓ垫片		× 8	ⓔ六角扳手		× 1

各部位名称



※组装方法上, 白橡木搁板套装/胡桃木搁板套装皆共通。

※各尺寸的组装方法也通用, 解说图仅介绍 **宽型/大** 尺寸。


注意

- 组装时, 请务必确保两人以上共同作业。
一人的话可能会因商品破损或掉落而造成受伤。
- 组装时请勿使用电动工具。
过度施压会造成商品破损而受伤。
- 请在组装一周后重新紧固螺栓等零部件。
刚开始使用可能会有松动的情况, 继续使用下去可能会造成破损而受伤。
- 组装、设置时请多加小心, 以防损伤地板或周围的家具。

组装前请仔细阅读

※搁板挂钩上安装的白色塑料物体是运输中防止挤压的配件。

请在组装时将其拆除。




※请使用一字形螺丝刀等垂直下压后取出。

1 首先, 在组装场所铺设铺垫物以保护地板。

(为了避免组装后再移动, 请尽量在设置位置附近进行组装。)

请将①调节旋钮安装在④立杆上。




组装步骤(续)

※解说图使用[宽型/大类型]进行介绍。

2

请使用④六角扳手将分别固定于⑧搁板四个转角的挂钩螺栓拧松至可自由转动状态。

※请将搁板所有挂钩螺栓拧松至图中所示状态、并使挂钩呈八字形。




3

安装最下层的搁板。

①使⑧搁板表面朝上呈倾斜状态,先将背面的2处挂钩挂至⑨立杆的立柱上 [要领①],然后用手指将前面的挂钩推挂 [要领②]、嵌入竖杆立柱中。[要领③]

②用④六角扳手将挂钩螺栓轻轻旋紧。(从牢牢旋紧的状态半回旋一下,使之稍微松动)




组装步骤(续)

※解说图使用[宽型/大型]进行介绍。

4


接下来以工序**3**相同的要领安装最上层的⑧搁板。



5


以工序**3**相同的要领安装剩下的全部⑧搁板。

※请按照收纳物品的高度决定安装的位置。




6

将⑨交叉杆的中心叠放后, 使用⑩盖形螺母(交叉杆中心专用)和⑪螺栓(交叉杆中心专用)将其轻轻旋紧。



交叉杆叠放方式



※请将各交叉杆的朝向如上图所示叠放。将螺栓从平坦面穿过, 使用盖形螺母将凹陷面轻轻旋紧。此外, 交叉杆无上下方向之分。

组装步骤(续)

※解说图使用**宽型/大类型**进行介绍。

- 7** 将组装好的交叉杆从背面用④垫圈和⑤螺栓固定在①立杆上。
安装时, 将交叉杆的⑥盖形螺母朝向外侧。

请求 (其他注意事项)	●如果交叉杆的螺栓孔位置合不上, 有可能是本体倾斜了, 请稍微松动一下搁板的挂钩螺栓。 ●在旋紧交叉杆的⑤螺栓时, 请整体性地将全体螺栓逐渐旋紧。如果先将一处牢牢旋紧, 有可能导致其他位置难以旋紧。
----------------	--




- 8** 最后, 用⑥六角扳手将工序**3~5**轻轻旋紧的⑦搁板的挂钩螺栓, 以及工序**6~7**轻轻旋紧的交叉杆的⑧⑨螺栓牢牢旋紧固定。(全部共30处)

请求 (其他注意事项)	请从前面、背面交替逐渐旋紧搁板的挂钩螺栓。如果先将1处牢牢旋紧, 则会导致安装的搁板歪斜, 使最后的挂钩难以旋紧。
----------------	---



- 9** 将商品设置好后, 请调整⑩调节旋钮, 使商品不松动。



使用方法

[组架/零件必要数确认表]

竖杆尺寸		特大	大	中	小	迷你
零件名						
长112cm	搁板	4	3	3	2	3
	交叉杆	2	2	1	1	0
长84cm	搁板或立杆加强配件	4	3	3	2	3
	交叉杆	2	2	1	1	0
长56cm	搁板或立杆加强配件	4	3	3	2	3
	交叉杆	2	2	1	1	0
长42cm	搁板	4	3	3	2	3
	交叉杆	2	2	1	1	0

※ 持有 **宽型/大** 者请确认 。

※ 持有 **大** 者请确认 。

※强度因组装位置而异。即使达到必需数量，一侧偏重也可能影响强度。

特别是上下腾空，或有较长间隔的腾空，则可能导致摇晃，设置时请注意均匀。

[关于移动]

<组装后需要搬动时>


●请勿抓住搁板抬起。

搁板一旦脱落，则会导致物品掉落、人体意外受伤或器具损坏。

组装后需移动时，请务必在清理收纳物品后、由2人以上人员从左右两侧抬起立杆部位移动。


●请不要在地面拖动或按压。

否则可能导致地板损伤或损坏。



<搬家等情况需要搬动时>

●因搬家等原因而需跨越房间或楼梯进行移动时，请将其恢复组装前状态后再搬动。
(零部件脱落可能会导致受伤或商品破损)




使用方法(续)

⚠ 收纳时的注意事项

- 请避免仅在上方收纳物品。否则容易因失衡而不稳定，导致商品倾倒而发生受伤的危险。
- 请勿在上部放置重物。地震等会导致重物落下或本体倾倒而造成受伤。

🚫 容易导致不稳定的使用方法 (例)



[关于报废]

- 报废时，请按各地官方规定的方式进行报废处理。

保养方法

保养・检查

- 请勿在损坏、变形的状态下使用。
- 请定期检查脚、螺栓有无松动或摇动，一旦发现松动，请立即将其紧固。
可以此防止人体受伤或家具损坏、地板损伤。否则有可能造成松动或出现异音。
- 发现虫害时，请立即使用杀虫或防虫剂进行清理。若置之不理则可能导致虫害范围扩大。

关于污垢

[木质部]

- 涂漆面的灰尘请用软布、或掸子等轻轻掸去。若用硬布或在附着灰尘等状态下直接擦拭，则会留下细小划伤。
- 污垢严重时，请用经过3~5%左右稀释的中性洗涤剂将软布浸透后擦除污垢，然后再用清水浸湿的软布将洗涤剂擦拭干净。最后用柔软的干布擦拭后使其自然风干。
- 请勿使产品长时间接触化学抹布。否则可能导致表面剥落、变色。
- 请勿直接在其上放置热的或湿的物品。否则可能导致弯曲或变形、开裂、变色等。
放置潮湿的物品时请在下面铺设铺垫物。
- 请勿将底部粗糙的物品直接放于其上。拖动时可能会造成损伤。

[金属部]

- 每天清洁时，请使用柔软的干布轻轻擦拭。
- 污垢严重时，请用经过3~5%左右稀释的中性洗涤剂将软布浸透后擦除污垢，然后再用清水浸湿的软布将洗涤剂擦拭干净。最后用柔软的干布擦拭后使其自然风干。
- 请在金属部薄薄地涂上一层润滑油，再用软布轻轻地擦拭干净。

使用注意事项

天然木产品禁止事项

●本商品采用天然木材制作，木纹及色调等均具有天然木材特有的个体差异。

因此，商品会在木纹及色调上存在差异，敬请谅解。

●天然木（刨切单板）根据以下条件，可能会出现破裂或弯曲等，敬请注意。

①请尽量避免在阳光直射的场所使用。

仍然会有阳光直射的话，请尽量使用窗帘等遮挡。

②请尽量避免在冷热设备附近使用。请务必不要在冷热设备风口处使用。

③尤其是冬季的暖气会使室内极度干燥，因而导致天然木发生破裂、弯曲。

关于甲醛对策

●何谓甲醛

据说，甲醛是导致病态建筑综合症的物质之一。在常温下是一种气化无色且具有刺激性气味的化学物质，除了家具以外，建筑材料、黏贴墙纸使用的接合剂等中也均含有这种物质。由于会逐渐扩散，所以如果长时间滞留于被甲醛污染的室内环境，将会刺激眼睛、导致咽喉产生不适的刺激感。如果浓度过高，还可能导致呼吸困难。

●请对房间进行换气



注意

设置家具后，请务必对室内进行充分换气。否则可能导致对化学物质敏感者及婴幼儿等出现过敏症状。

甲醛易在空气中扩散，故请在日常随时对室内进行充分换气。

同时设置多款家具时，请尽量开大窗户，对室内进行充分换气。室内温度一旦升高，甲醛可能出现加速扩散的倾向，所以在夏季长时间门窗紧闭时，请务必确保充分换气。为了提高换气效率，建议同时打开多扇窗户、开启换气扇、电风扇、空气循环风扇等。

●致对化学物质敏感的用户

除甲醛以外，其他导致病态建筑综合症的化学物质在容许量上也均因人而异。

因此，即使浓度在室内浓度标准值(不会影响健康的甲醛室内浓度值)以下，也会存在过敏反应体质的用户。我们在目前的无印良品家具上已尽力减少使用该些材料，但依然无法完全阻止扩散，故请多加注意。

一旦出现过敏症状，建议立即向医生咨询。

●无印良品的家具在出厂时均已于封装材料中放入了甲醛吸附/分解纸※。

（※甲醛吸附/分解纸：与爱信精机株式会社共同开发）

甲醛在狭窄的空间内无处可逃，可能再次被材料吸附。因此，为了尽量降低送达顾客手中的商品所附甲醛浓度，我们在封包中放入了甲醛吸附/分解纸。

※封包中的“甲醛吸附分解纸”性能将下降，故请作为可燃垃圾处理。

产品规格

产品名称	不锈钢组合架/ 白橡木搁板套装/大	不锈钢组合架/ 白橡木搁板套装/ 宽型/大	不锈钢组合架/ 胡桃木搁板套装/大	不锈钢组合架/ 胡桃木搁板套装/ 宽型/大
产品尺寸	长580x宽410x 高1755(mm)	长860x宽410x 高1755(mm)	长580x宽410x 高1755(mm)	长860x宽410x 高1755(mm)
产品重量	约25.1kg	约33.0kg	约25.1kg	约33.0kg
用途	收纳家具			
载重量 每1块搁板	约30kg (※均衡载重时)			
载重量	约100kg			
材质 (橡木搁板套装)	框架 : 不锈钢 搁板 : MDF (橡木刨切单板) 表面加工 : 搁板 丙烯酸UV涂装 : 框架 电解研磨			
材质 (胡桃木搁板套装)	框架 : 不锈钢 搁板 : MDF (胡桃木刨切单板) 表面加工 : 搁板 丙烯酸UV涂装 : 框架 电解研磨			
执行标准	GB/T 3325-2008			

Made in Taiwan

联系方式

有关商品的咨询, 请联系购买的代理商。

无印良品(上海)商业有限公司
注册地址: 上海市静安区南京西路1601号35楼
电话: 021-6375-6677
www.muji.com.cn