

MUJI 無印良品

保存用

ブナ材テーブル 丸脚

組立・取扱説明書

この度は本製品をお買い上げいただき、誠にありがとうございます。ご使用前に本書をよく読みいただき、内容を理解した上で、正しく組み立て、正しくお使いください。また、本書はいつでも確認できるように大切に保管してください。

2024 年 1 月 30 日

お手入れ方法

- 保守・点検
- 各部にゆるみがないか定期的に点検し、ゆるんでいたらしっかり締め直してください。ケガや製品の破損防止になります。
 - 害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。
- 木部のお手入れ
- 塗装面のほこりはやわらかい布または、はたきで軽く払ってください。
 - 汚れのひどい時は、3～5％に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤分をよくふき取ってください。次に乾いた布で軽くふいた後、自然乾燥させてください。
 - 長時間、化学雑巾を接触させたままにしないでください。変色や表面がはがれる原因となります。

重要なお知らせ (安全上のご注意)

ここに示した警告・注意事項はお使いになる方や他の人への危害や損害を未然に防ぐためのものです。必ずお守りください。

してはいけない「禁止」の内容です。

実行しなければならぬ内容です。

警告

死亡や重傷などに結びつくおそれがあるもの

禁止

- お子さまに製品に登る、ぶら下がるなどさせないでください。転倒や破損、ケガをするおそれがあります。
- 指定の用途以外で使用しないでください。破損してケガをするおそれがあります。
- 製品で電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因となります。
- 不要になった梱包材は、幼児の手の届くところに置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。

注意

傷害を負う可能性や物的損害が生じるおそれがあるもの

禁止

- 耐荷重を超えて物をのせたり、耐荷重内でも一部に片寄ってのせたりしないでください。変形や破損の原因となり、ケガをするおそれがあります。
- 組み立てが不完全なまま使用しないでください。固定部分がはずれてケガの原因になることがあります。
- 修理や改造はしないでください。製品の強度が弱くなり、ケガをするおそれがあります。
- 破損や変形した状態では使用しないでください。製品の強度が弱くなりケガをするおそれがあります。
- 高温多湿な場所に長期間設置しないでください。カビやダニが発生し、健康を害することがあります。
- 屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。

ご使用に際して

天然木について

- 本製品は天然木を使用しているため、製品ごとに天然木材特有の個体差（木目や色合いなど）がありますが、あらかじめご了承ください。
- 天然木は下記の条件により、割れや反りなどが発生することがありますので、ご注意ください。
 - ・直射日光の当たる場所でのご使用は出来る限りお避けください。どうしても直射日光が当たる場合は、カーテンなどで出来る限り避けてご使用ください。
 - ・冷暖房器具の近くでのご使用は出来る限り避け、必ず冷暖房の風が直接当たらないようにしてください。
 - ・特に冬の暖房による室内の極端な乾燥は、天然木の割れ、反りを発生させる原因となります。

ホルムアルデヒドの対策について

- ホルムアルデヒドとはシックハウス症候群の原因物質の一つといわれています。常温で気化する、無色で刺激臭のある化学物質で、家具はもとより建築資材・壁紙を貼る接着剤などに含まれています。少しずつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いと目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

製品仕様

品名	ブナ材テーブル 丸脚 幅150cm	ブナ材テーブル 丸脚 幅180cm
J A N	4550512892410	4550512892373
製品寸法	約幅1500×奥行800×高さ720 mm	約幅1800×奥行850×高さ720 mm
製品重量	約28 kg	約35.5 kg
用途	テーブル	
耐荷重	甲板：約40 kg	
材質	甲板の表面材：天然木（ブナ材） 脚部：天然木（ブナ材） 表面加工：ウレタン樹脂塗装	
原産国	日本	

ご使用方法

- 移動について
- 移動させる際は、大人2人以上で、必ず製品の下に両手を掛け、床面を引きずらないように持ち上げて運んでください。床や既存の家具のキズ防止になります。
- お問い合わせ先
- 製品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社 良品計画

お客様相談室でんわ

0120-14-6404

- 廃棄の際は、居住地域の自治体のルールに従い、処分してください。

注意 (つづき)

傷害を負う可能性や物的損害が生じるおそれがあるもの

行う

- 使用時は、脚底面にフェルトなどの保護材を貼ったり、敷物を敷いたりしてご使用ください。床へのキズ防止、また、クッションフロアーなどの場合は木部の塗料とクッションフロアーの反応による変色を防いでくれます。

お願い (その他 注意)

- 平らで安定した場所に設置してください。不安定な場所での使用は、製品のゆがみ、破損の原因になることがあります。
- 製品に直接熱い物や濡れた物を置かないでください。反りやゆがみ、割れ、変色、カビなどの原因となります。
- 天然木の上にビニール製品（塩化ビニル樹脂など）を直接、長期間置かないでください。変色や表面がはがれる原因となります。
- 飲食時は、ランチョンマットやコースターなどを敷いてお使いください。濡れた物、熱い物が置かれると、変形や変色の原因となります。
- テーブルの上で筆記などの作業を行う時は、必ずマットなどを敷いてください。天板に凹みやキズがつく原因となります。
- 製品の上で陶器など底のざらついた物を直接置いて引きずらないでください。天板がキズがついたり、凹む原因となります。
- シンナーなどの有機溶剤や漂白剤などの薬剤、アルコールを含む消毒剤でお手入れしないでください。変色や変形の原因となります。
- 組み立ての際は、手袋などをつけて作業してください。思わぬケガの防止になります。

- お部屋の換気について

注意

- ❶家具を設置の際は、室内の換気を十分にしてください。化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすことがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。特に複数の家具を同時に設置した場合は、窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は、特に換気をするようにご注意ください。換気効率をあげるため複数の窓を開けたり、換気扇、扇風機、サーキュレーターの利用をおすすめします。

- 化学物質に敏感な体質のお客さまへ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質の許容量には個人差があり、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具においても、ホルムアルデヒド放散量の少ない材料を極力使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。アレルギー症状が起きた際は、医師にご相談されることをおすすめします。

- ホルムアルデヒド吸着・分解シートについて狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性がありますので、お手元に届くまで少しでもホルムアルデヒド濃度を低下させるために、無印良品の家具には、ホルムアルデヒド吸着・分解シートを同梱しています。※同梱の「ホルムアルデヒド吸着・分解シート」は効力が落ちておりますので、燃えるゴミとして処分してください。

パーツリスト

④天板×1

幕板

隅木

(裏面)

⑧脚×4

ボルト

※イラストは ブナ材テーブル 丸脚 幅150cm です。

幅 150 cm

幅 180 cm

共通

組立方法


注意

- ❶組み立て時は、組み立てに必要なスペースを十分に確保し、敷物を敷いてください。床や既存の家具のキズ防止になります。
- ❷組み立ては、大人2人以上で行ってください。1人で作業すると、転倒や破損、ケガをしたり、床をキズつける原因となります。

1

④天板を敷物の上に裏面が見えるように置いてください。

※イラストは ブナ材テーブル 丸脚 幅150cm です。



- ⑧脚のボルトを④天板の隅木穴に通します。
- ④天板の内側から⑧のボルトに③、⑥、④を通し、④でまず、ゆるめに締め
- ③全部取り付けた後に、きつく締め込んでください。


ポイント

1

はじめに天板に近い側の脚ボルト部を固定します。その後、脚と天板の間に隙間がないように密着させて取り付けてください。

2

もう一方の脚ボルト部もしっかり固定させます。



- ④⑥を⑧脚の底面に貼ります。

注意

- ❶ご使用の前に、付属の⑥フェルトを脚底面にお貼りください。フローリング床などのキズつき防止、ガタつきの際の調整にご使用いただけます。

お願い (その他 注意)

貼る前に貼る面のほこりなどの付着物をふき取ってください。付着物があると粘着力が低下します。貼った後は全体をしっかり押さえて、ムラなく接着してください。

2

テーブルを静かに起こして完成です。

注意

- ❶テーブルを起こす際は、片方の脚に過度の荷重をかけたりしないでください。床から持ち上げるようにして起こし、ケガやテーブルの破損、床面がキズつかないようにしてください。
- ❷組み立て後、1週間程度経過しましたら、ボルトを締め直してください。使い始めはゆるんでいる場合があり、そのまま使用すると破損、ケガの原因となります。



(完成図)

Beech table Round legs

User Guide

Thank you for your purchase. Read this User Guide before use to ensure correct assembly and use of the product. Store this guide in an easily accessible place for future reference.

30 January 2024

Care Instructions

Maintenance and Inspection

- Regularly check for any looseness in all parts, and retighten them if looseness is found. This is to prevent injury and product damage.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, pest damage may worsen.

Contact Information

For enquiries regarding the product, please contact the store of purchase.

Specifications

Product Name	Beech table Round legs W150 cm	Beech table Round legs W180 cm
JAN	4550512892410	4550512892373
Product Dimension	Approx. W1500 × D800 × H720 mm	Approx. W1800 × D850 × H720 mm
Product Weight	Approx. 28 kg	Approx. 35.5 kg
Usage	Table	
Withstand Load	Tabletop: Approx. 40 kg	
Material	Tabletop Surface : Natural Wood (Beech) Leg : Natural Wood (Beech) Surface Finish : Urethane Resin Coating	
Place of Origin	JAPAN	

Directions for Use

Moving the Product


- When moving the assembled product, do not drag it on the floor. It must be lifted and carried by at least two adults holding the underside of the product with both hands. This prevents the floor and other furniture from scratches.

Disposal

- To dispose of the product, follow the rules implemented by your local government.


Parts

Ⓐ Tabletop × 1



Apron
(Underside)
Corner Block

Ⓑ Leg × 4








Bolt

Same for W150 cm and W180 cm types


* Beech Table Round Legs W150 cm is used in the illustrations.

Fitting Parts

Ⓐ Nut × 8	Ⓑ Spring Washer × 8	Ⓒ Washer × 8
		
Ⓓ Spanner × 1	Ⓔ Felt Pad × 4	
		
13 mm		

Assembly Instructions

Applies to W150 cm and W180 cm types

 **CAUTION**


⚠ Secure enough space and place an underlay when assembling the product. This prevents the floor and other furniture from scratches.


⚠ The product must be assembled by two or more adults. Assembling alone may cause injury, tip-over, damage and/or floor scratches.


- 1 Place Ⓐ tabletop on an underlay with the underside facing up.
- * Beech Table Round Legs W150 cm is used in the illustrations.


Important Information (Safety Advice)

The warnings and cautions indicated here are intended to prevent harm to the users and other individuals or damage to the property. The instructions must be followed.


 Actions that are prohibited.


 Actions that must be taken.

 **WARNING** Hazards that may lead to death or serious injury

 DON'Ts

- Do not let children climb on or hang from the product. Doing so may cause tip-over, damage and/or injury.
- Do not use for other than its intended purpose. Doing so may cause product damage and lead to injury.
- Do not place on the power cord of an electrical appliance. Doing so may damage the cord, leading to electric shock or a fire.
- Do not leave unnecessary packaging materials within reach of small children. Children may accidentally pull them over their head, cover their mouth and/or nose and suffocate.

 **CAUTION (Continued)** Hazards that may result in injury or damage to the property

 DOS

- Apply felt pads or any protective materials to the bottoms of the legs, or use an underlay. This is to protect the floor from scratches and discolouration due to chemical reaction between the coating on the wooden parts and the floor when the product is installed on a cushioned vinyl flooring.

Note (Other Caution)

- Use the product on a flat and stable surface. Otherwise it may cause product distortion or damage.
- Do not place hot or wet items directly on the product. Doing so may cause warping, distortion, cracking, discolouration or mould growth.
- Do not place plastic products (vinyl chloride resin, etc.) directly on natural wood for a long time. Doing so may cause discolouration or peeling of the surface material.
- Lay place mats and coasters on the product when eating. Placing wet or hot items directly on the product may cause deformation or discolouration.
- Be sure to use a mat, etc. when writing or drawing on the table. Not doing so may cause dents or scratches on the tabletop.
- Do not place and drag items with rough bottom surfaces, such as ceramics, directly on the product. Doing so may cause scratches and dents on the tabletop.
- Do not use bleach, organic solvents such as thinner, or alcohol-containing disinfectant for cleaning. Doing so may cause discolouration or deformation.
- Wear gloves during assembly of the product. This is to prevent unexpected injury.

General Notes

Care Tips for Natural Wood Products

- As this product is manufactured using natural wood, there are individual differences (grain, colour, etc.) unique to natural wood.
- Note that cracking and warping may occur in natural wood under the following conditions.
 - Avoid use in locations exposed to direct sunlight. If exposure to direct sunlight is unavoidable, use curtains, etc. to reduce the amount of sunlight.
 - Avoid use near heaters or air conditioners and make sure that the air from heater or air conditioner does not come into direct contact with the product.
 - In particular, use of heating appliances during winter causes the room to become extremely dry and may lead to cracking or warping of natural wood.

Formaldehyde Countermeasures

- What is Formaldehyde?

Formaldehyde is said to be a cause of sick house syndrome. It is a colourless, pungent-smelling chemical that vaporises at room temperature, often found in furniture, building materials, wallpaper adhesives, etc. As it is gradually released into the air, spending a long time in a room contaminated with formaldehyde can result in eye/throat irritation. Also, exposure to a high concentration of formaldehyde may cause breathing difficulties.
- Room Ventilation

Be sure to frequently ventilate the room on a regular basis as formaldehyde is released into the air. Especially when installing multiple pieces of furniture at the same time, open the windows wide enough to allow adequate ventilation. Formaldehyde release tends to increase with temperature rise of the room. Therefore, be sure to ventilate well after the room has been closed up for a long time during summer. It is recommended that you open multiple windows and use a ventilation fan or an air circulator to increase ventilation efficiency.


- For Individuals Sensitive to Chemicals


There are individual differences in resistance to chemicals that are related to sick house syndrome other than formaldehyde. Therefore, even if the actual concentration in the room is lower than the indoor concentration guideline value (acceptable safe level of formaldehyde indoors), some people may react to formaldehyde. MUJI furniture are made with materials that contain as little formaldehyde as possible, but note this does not guarantee that they are completely formaldehyde-free. It is recommended that you seek medical attention if you experience any allergic symptoms.
- Formaldehyde Adsorption/Decomposition Sheet


Formaldehyde is readsorbed onto materials when there is nowhere for it to dissipate in a confined space. Therefore, a formaldehyde adsorption/decomposition sheet is included in the packaging to reduce formaldehyde concentration as much as possible before the product reaches the customer.

* The effect of the sheet will be diminished by the time the product reaches the customer. Dispose of the sheet as burnable waste after unpackaging.

- 2 Finally, gently turn the table to the upright position.

 **CAUTION**

 Do not put excessive load only on one side (of the legs) when turning the table upright. Make sure to lift it off the floor when turning it to prevent injury, product damage or floor scratches.

 Retighten all the bolts approximately one week after assembly. They may be loose at the start of use, and continued use under this condition can lead to damage and/or injury.

- ① Put the bolts on Ⓑ leg through the holes on the corner block of Ⓐ tabletop.


② Put Ⓒ, Ⓑ and Ⓐ around the bolts from inner side of Ⓐ tabletop, and lightly tighten them with Ⓓ.

③ Firmly tighten them after all the parts are attached.


Points

1 Fix the leg bolt close to the tabletop. Then adjust the angle of the leg so that there is no gap between the leg and the tabletop.

2 Fix the other leg bolt.



- 4 Attach Ⓔ to the bottoms of Ⓑ legs.

 **CAUTION**

⚠ Attach the provided Ⓔ felt pads to the bottoms of the legs before start of use. This will help protect the wooden flooring, etc. from scratches and adjust the height of the legs to fix wobbling.

Note (Other Caution)

Remove any dust and other debris from the attachment surface before attaching Ⓔ felt pad. It may not adhere well if there is anything on the surface. Press the whole pad firmly so it adheres evenly.

