保存用

Retain for future reference

保存用

MUJI 無印良品

ハイバックリクライニングソファ・本体・1シーター
HIGH BACK RECLINING SOFA / 1S
高靠背斜倚沙发椅/主体/1人座

取扱説明書
User Guide
使用说明书

日本語

この度は本商品をお買い上げいただき、誠にありがとうございます。
1ページからお読みください。

English

Thank you for your purchase.
Read these instructions from Page 9.

中 文

本次承蒙惠购本产品，在此深表感谢。
请从第十七页开始阅读。

4550002405236　HIGH BACK RECLINING SOFA / 1S

使用说明书发行日期 : 2023 年 8 月 24 日

853395553-004-002

MUJI 無印良品

保存用

ハイバックリクライニングソファ・本体・1シーター

取扱説明書

この度は本商品をお買い上げいただき、誠にありがとうございます。
ご使用前に本書をよくお読みいただき、内容を理解した上で、正しくお使いください。
また、本書はいつでも確認できるように大切に保管してください。

もくじ　ページ

重要なお知らせ（安全上のご注意）	2～4
パーツリスト	5
各部の名称	5
ご使用方法	6
お手入れ方法	6
ご使用に際して	7～8
製品仕様	8
お問い合わせ先	8

2023年8月24日

重要なお知らせ（安全上のご注意）　必ずお守りください。

本書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。
次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

●表示の説明
誤った使い方をしたときに生じる危害や損害の程度を区分して説明しています。

⚠ 警告	使用者が死亡または重傷（※1）を負うことが想定される内容です。	⚠ 注意	使用者が傷害（※2）を負うことや物的損害（※3）が発生することが想定される内容です。

●図記号の説明
お守りいただく内容を次の図記号で説明しています。（次は図記号の例です。）

⃠	してはいけない「禁止」の内容です。	❗	実行しなければならない内容です。

※１ 重傷とは、失明やケガ、やけど、骨折、中毒、感電などで後遺症が残るもの及び治療に入院、長期の通院を要するものをさします。
※２ 傷害とは治療や入院や長期の通院を要しない、ケガ、やけどをさします。
※３ 物的損害とは、家屋、家財にかかわる拡大損害をさします。

⚠ 開梱時のご注意

⚠ 警告	
⃠ 禁止	●不要になった包装資材はすぐに処分するなど、お子さまの手の届く所に置かないでください。頭からかぶるなどしたときに、口や鼻をふさぎ、窒息するおそれがあります。

⚠ 設置環境についてのご注意

⚠ 警告	
⃠ 禁止	●ストーブなど引火するおそれのあるものを近くに置かないでください。火災の原因となります。 ●商品の脚などで電化製品の電源コードを踏まないでください。コードが破損し、感電や火災の原因になるおそれがあります。

⚠ 注意	
⃠ 禁止	●直射日光や照明、ストーブやエアコンなどの熱や温風を商品に直接あてないでください。反りやゆがみ、割れ、変色などの原因になり、ケガをするおそれがあります。 ●多湿な場所（目安：湿度７０％以上でかつ室温２０℃以上）で長期間設置はしないでください。カビやダニなどが発生し、健康を害するおそれがあります。
❗ 行う	●商品を長時間同じ場所に設置し使用されますと、床と脚の設置面が凹んだりして床をキズつける場合があります。必ずカーペット等敷物の上に商品を設置するか、商品の脚にフェルト等を貼って使用してください。また、クッションフロアなどの場合は、木部の塗料とクッションフロアの反応により変色することがあります。

お願い（その他 注意）	
	●平らで安定した場所に設置してください。不安定な場所での使用は、製品がゆがんだり、破損の原因になるおそれがあります。

⚠ 使用上のご注意

⚠ 警告

禁止

●乳幼児を寝かさないでください。床への落下や窒息の原因になるおそれがあります。

●保護者の目の届かないところで、お子さまだけでは使用させないでください。

●たばこの火などを商品に落とさないでください。火災の原因となります。

●座る以外には使わないでください。思わぬケガの原因になるおそれがあります。

●座った状態で商品を傾けるなど、不安定な状態では使用しないでください。転倒や商品の破損により、思わぬケガをする原因となります。

●商品の上に立ったり、飛びはねたり、踏み台代わりに使用したりしないでください。バランスを崩し転倒したり、商品の破損によりケガの原因になるおそれがあります。

●破損・変形した商品は使用しないでください。思わぬケガをするおそれがあります。

●修理や改造はしないでください。製品の強度が弱くなり、ケガをする原因となります。

●逆さにした状態で上に乗らないでください。ギアなど商品の破損により、思わぬケガをする原因となります。

●背もたれに腰掛けるなど背もたれの先端部分に過度に荷重をかけないでください。ギアの破損によりケガをする原因となります。

●後脚に乗るなどの行為は大変危険ですのでやめてください。
ケガ、本体の破損の原因になります。

●勢いよく腰かけるなど背もたれに強い衝撃をあたえないでください。
ギアが破損し、ケガをする原因となります。

●２人以上では使用しないでください。転倒や破損によりケガをするおそれがあります。

⚠ 注意

禁止

●製品の周辺、または上部に物を置かないでください。落下しケガの原因になるおそれがあります。

●屋外では使用しないでください。変形や著しい劣化が起こり、ケガをする原因となります。

●ギア付近のクッション材は薄くなっております。その付近には座ったり踏んだりしないでください。
思わぬケガや破損の原因となります。

●背もたれを倒す時に後方に人や物がないか確認してください。思わぬケガや破損の原因となります。

●移動の際は落としたり引きずったりしないでください。
床の破損、本体の破損によるケガの原因になります。

●端に片寄って座らないでください。
背もたれが破損しケガをする原因となります。

●座りながらの、片手でのギア操作は止めてください。
ギアが片掛かりにより背もたれが破損しケガの原因になります。

行う

●使い始めるときは、室内の換気を十分にしてください。接着剤などに含まれるホルムアルデヒドが残っている可能性があり、化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすおそれがあります。

●移動する際は、大人２人以上で移動させてください。１人で無理に移動させるとケガや商品の破損、あるいは床をキズつける原因となります。

●必ず木製脚を取り付けた状態でご使用ください。本体のみで使用すると床へのキズ、本体の破損によるケガの原因になります。

お願い（その他 注意）	
	●フェルトを貼った状態で凹凸や継ぎ目などの段差のある床面では使用しないでください。フェルトがはがれて、床面を汚したり、キズつけたりする原因となります。 ●ソファを畳やクッションフロアー（シートフローリング）などで使用されますと、床が凹む場合がありますので、カーペット等敷物の上にソファを設置してください。 ●シンナーなどの有機溶剤や漂白剤などの薬剤でお手入れしないでください。変色や変形の原因となります。 ●化学雑巾を長時間接触させたままにしないでください。変色したり、表面がはがれたりするおそれがあります。

パーツリスト

Ⓐ本体×１

ⓔ頭部インナークッション（小）
×１

ⓕ背部インナークッション（中）
×１

ⓖ座部インナークッション（大）
×１

各部の名称

（別売専用カバー装着時）

お願い（その他 注意）	●必ず別売の専用カバーを装着してご使用ください。 ●カバー装着方法は、別売のカバーに付属の説明書をご確認ください。

ご使用方法

■背もたれの角度操作方法

【背もたれを起こすには】

①の状態（ロックした状態）から背もたれを起こし、
『カチッ』と音がした所で止めると固定できます。

【背もたれを倒すには】

背もたれを９０度以上前方に押すとロックが解除し、①の状態に戻ります。

⚠ 注意	❗ リクライニング操作時は、本体の両側を持って行ってください。 片側のみを持って動かすと片方のギアだけがロックしやすくギアの破損によりケガの原因となります。

■ヘッドレストの角度操作方法

【ヘッドレストを起こすには】

①の状態（ロックした状態）から背を起こし、
『カチッ』と音がした所で止めると固定できます。

【ヘッドレストを倒すには】

ヘッドレストを前方に押すとロックが解除し、①の状態に戻ります。

移動について

⚠ 注意	⃠ １人では移動を行わないでください。ケガや破損、床面へのキズの原因になります。

●移動させる際は、必ず座部の下に両手をかけて運んでください。
必ず、大人２人以上で、床面をひきずらないように持ち上げて運んでください。

廃棄について

廃棄の際は、住居地域自治体のルールに従い、処分してください。

お手入れ方法

保守点検

●脚固定用ボルトにゆるみがないか定期的に点検し、ゆるみはじめたらしっかり締めなおしてください。ケガや破損、床面へのキズの防止となります。
●各部にゆるみやぐらつきがないか定期的に点検し、異常が見られたら使用を中止してください。商品の破損、ケガの原因となります。
●害虫を発見した場合は、直ちに殺虫や防虫処理をしてください。放置すると虫害が拡大するおそれがあります。

汚れについて

カバーのお手入れ

●毎日のお手入れはやわらかい布で乾拭きしてください。ほこりなどはブラシや掃除機（弱設定）などを使って取り除いてください。
●コーヒーなどの汚れがひどいときは、ぬるま湯を使って3-5％程度に薄めた中性洗剤にやわらかい布を浸し、よく絞って表面をたたくようにふき取ってください。その後、水を浸した布で洗剤をよく拭き取り、自然乾燥してください。
●カバーの洗濯方法については、カバーの洗濯表示に従い、正しく取り扱いください。

脚のお手入れ

●塗装面のホコリは、やわらかい布または、ハタキなどで軽く払ってください。硬い布やほこりなどが付着した状態でこすると細かなキズがつく原因となります。
●汚れがひどい時は、3-5％程度に薄めた中性洗剤を浸した布で汚れを落とし、その後、水で浸した布で洗剤をよくふき取ってください。次に乾いたやわらかい布で軽く拭いた後で自然乾燥させてください。
●化学雑巾を長時間、接触させないでください。表面がはがれたり変色したりするおそれがあります。

ご使用に際して

天然木について

●本商品は天然木を使用しているため、木目や色合い等、天然木材特有の個体差があります。そのため、商品として、木目や色調に差がありますが、あらかじめご了承ください。

●天然木は下記条件により割れや反りなどが発生することがありますのでご注意ください。

①直射日光のあたる場所でのご使用はできる限りお避けください。
どうしても直射日光が当たる場所は、カーテンなどでできる限りお避けください。

②冷暖房器具の近くでのご使用はできる限りお避けください。必ず冷暖房の風が直接当たらないようにしてください。

③特に冬の暖房による室内の極端な乾燥は、天然木の割れや反りを発生させる原因になります。

ホルムアルデヒドの対策について

●ホルムアルデヒドとは

ホルムアルデヒドは、シックハウス症候群の原因物質の一つといわれています。常温で気化する無色で刺激臭のある化学物質で、家具はもとより建築資材、壁紙を貼る接着剤などに含まれています。少しづつ放散されるため、ホルムアルデヒドに汚染された室内に長時間いると目がチカチカしたり、喉に不快な刺激を感じたりすることがあります。濃度が高いと呼吸困難を起こす場合もあります。

●お部屋の換気をしてください。

⚠ 注意	❗ 家具を設置の際は、室内の換気を十分にしてください。 化学物質に敏感な体質の方や乳幼児などアレルギー症状を起こすおそれがあります。

ホルムアルデヒドは空気中に放散されやすいので、普段からこまめに室内の換気を行うようにしてください。複数の家具を同時に設置した場合は特に窓をできるだけ広く開け、十分な換気を行ってください。室内の温度が高くなると、ホルムアルデヒドは多く放散される傾向がありますので、夏季に室内を長時間閉め切っている場合は特に換気をするようご注意ください。換気効率を上げるため、複数の窓を開けたり、換気扇、扇風機、サーキュレーターなどの利用をおすすめします。

●化学物質に敏感な体質のお客様へ

ホルムアルデヒドに限らず、シックハウス症候群に該当する化学物質は許容量に個人差があります。よって、室内濃度指針値（健康上望ましいとされるホルムアルデヒドの室内濃度値）以下の濃度であっても反応する体質の方もいらっしゃいます。現段階の無印良品の家具におきましても極力少ない材料を使用しておりますが、まったく放散されないわけではありませんので、ご注意ください。
アレルギー症状が起きた際は、医師にご相談される事をおすすめします。

●無印良品の家具は梱包内にホルムアルデヒド吸着・分解シートを入れて出荷しています。

狭い空間ではホルムアルデヒドは逃げ場がなく、材料に再吸着する可能性があります。そこで、お客様のお手元に届くまでに少しでもホルムアルデヒド濃度を低下させるために、ホルムアルデヒド吸着・分解シートを入れています。
※同梱の「ホルムアルデヒド吸着・分解シート」は、効力が落ちておりますので、燃えるゴミとして処分してください。

クッション材（ウレタンフォーム）について

●開梱時に特有のにおいがする場合がございます。このにおいはご使用過程で徐々になくなります。万一においが気になる場合は、直射日光のあたらない風通しの良い場所に陰干ししてからご使用ください。

●本製品は、製造工程により、一部クッション材に変色が見られる場合がありますが、本来の機能に支障はございません。

●ウレタンフォームの特性上、長時間放置しておくと、黄色に変色しますが、本来の機能に支障はございません。

●インナークッションの中身は、隅に片寄る性質があります。型崩れ防止のためにも、定期的にクッションをもみほぐし、中に空気を入れて形を整えるようにしてください。

●素材特性上、温度の変化により若干硬さに変化が生じます。温度が高いとやわらかく、低いと硬くなる場合があります。

側生地について

●本製品の側生地にはファスナーが付いておりますが、これは製造上のものです。修理などで開けないでください。破損やケガの原因となります。

●側生地は洗濯できないため、別売の専用カバーを必ず装着してご使用ください。

ご使用に際して（つづき）

操作について

リクライニング操作時、ギアから音が鳴ることがありますが本来の機能に支障はございません。

製品仕様

品　　名	ハイバックリクライニングソファ・本体・1シーター
J　A　N	4550002405236
製品寸法	幅 740 × 奥行 1140 ～ 1345 × 高さ 665 ～ 895 mm　座面の高さ 380 mm
製品重量	約 19 kg
用　　途	ソファ・1人用
材　　質	構造部材　本体フレーム：金属（鋼） 脚部：天然木（オーク材） 表面加工　脚部：ウレタン樹脂塗装 張り材　：ポリエステル 100% クッション材　：ウレタンフォーム、ポリエステルわた、鋼製ばね（Sばね）
原産国	中国

お問い合わせ先

商品のお問い合わせは、お買い上げの販売店もしくは下記お客様相談室までご連絡ください。

株式会社　良品計画

お客様相談室でんわ
0120-14-6404

MUJI 無印良品

Retain for future reference

HIGH BACK RECLINING SOFA / 1S

User Guide

Thank you for your purchase.
Read the User Guide before use to ensure correct use of this product.
Please store this User Guide in an easily accessible place for future reference.

Table of Contents | Pages

Important Information (Safety Advice)	10 - 12
Parts	13
Part Names	13
Directions for Use	14
Care Instructions	14
Usage	15 - 16
Specifications	16
Contact Information	16

24 August 2023

Important Information (Safety Advice)

These instructions must be followed.

This User Guide contains important information for the safe use of this product in order to prevent harm to the user and others or damage to the property.
Please note the following contents (indications and graphic symbols) before reading the main contents of this User Guide, and follow the instructions given.

● Explanations of Indications
If the product is used incorrectly, the degree of injury or damage that may arise is classified and explained with the following symbols.

⚠ **WARNING**	Indicates a hazard with a level of risk which, if not avoided, could result in death or serious injury*1 to the user.	⚠ **CAUTION**	Indicates a hazard with a level of risk which, if not avoided, could result in injury*2 to the user or property damage*3.

● Explanations of Graphic Symbols
Instructions are given in the form of the following graphic symbols. (Examples of graphic symbols are as follows.)

⃠	DON'Ts: Actions that are prohibited.	❗	DOs: Actions that must be taken.

*1 "Serious injury" indicates blindness, injuries, burns, bone fractures, poisoning, or electric shocks which have long term effects and require hospitalisation and / or long-term hospital visits for treatment.
*2 "Injury" indicates injuries or burns which do not require hospitalisation or long-term hospital visits for treatment.
*3 "Property damage" indicates extended damage that involves the house or household property.

⚠ Precautions for Unpacking

⚠ WARNING	
⃠ DON'Ts	● Do not leave the unnecessary packing materials within the reach of small children. Discard or store them out of reach of small children. Small children may accidentally pull packaging materials over the mouth or nose, causing suffocation.

⚠ Caution on Installation Environment

⚠ WARNING	
⃠ DON'Ts	● Do not place near a heat source such as a room heater. Doing so may cause a fire. ● Do not place a leg of the product on the power cord of an electrical appliance. Doing so may damage the cord, resulting in an electric shock or a fire.

⚠ CAUTION	
⃠ DON'Ts	● Do not expose to heat or hot air such as by the direct sun light, lighting, stove, and air conditioner. Doing so may cause warping, cracks or discolouration, resulting in injury. ● Do not store in a humid place (approx. humidity of 70% or higher and room temperature of 20°C or higher) for a long time. Doing so may cause an infestation of mould or mites, resulting in a health hazard.
❗ DOs	● Using the product installed in the same location for long periods of time may result in the location becoming dented or the floor becoming scratched. Be sure to install this product on top of a carpet or other protective underlay, and attach the felt stickers at the bottom of the legs. Additionally, using on a cushioned floor may cause discolouration of the floor due to a reaction between the wooden coating materials and a cushioned floor.

Note (Other Cautions)	
	● Install in a level and stable place. Using the product in an unstable place may distort or damage the product.

⚠ Precautions for Use

⚠ WARNING

DON'Ts

- Do not lay an infant on the product. Doing so may result in falling or suffocation.
- Do not allow children to use without supervision.
- Do not drop a lit cigarette on the product. Doing so may cause a fire.
- Do not use the sofa for other than sitting. Doing so may result in unexpected injury.
- Do not use in an unstable condition such as rocking back while sitting on it. This may result in unexpected injury from falling off or damaging the product.
- Do not stand or jump on the product or use it as a stepladder. Doing so may result in loss of balance and falling, or injury because of damage to the product.
- Do not use if it is damaged or deformed. Doing so may cause unexpected injury.
- Do not attempt to repair or modify. This weakens the product and may cause injury.
- Do not sit on the product when it is turned upside down. Doing so may result in unexpected injury from damage to the gears.
- Do not apply excessive load to the end of the backrest by sitting etc. Doing so may cause damage to the gears, resulting in injury.
- Do not attempt to do anything dangerous such as standing on the rear leg. Doing so may result in damage to the product or injury.
- Do not apply strong shock to backrest by suddenly sitting down etc. The gears may get damaged causing injury.
- Do not allow two or more people to use at the same time. Doing so may result in injury due to falling or damage to the product.

⚠ CAUTION

DON'Ts

- Do not place an object around or on the sofa. Doing so may cause falling resulting in injury.
- Do not use outdoors. Doing so may cause deformation or severe degradation of the product, resulting in injury.
- The cushioning material around the gears is thin. Do not sit or step on this area. Doing so may result in an unexpected injury or damage to the product.
- Check that there are no people or objects behind the product before reclining the backrest. Failure to do so may result in an unexpected injury or damage to the product.
- Do not drop or drag the product when moving it. This may cause damage to the floor or product, resulting in injury.
- Do not sit on just one side of the seat. Backrest may get damaged resulting in injury.
- Do not operate the gear with one hand while sitting. Backrest may get damaged due to gear becoming stuck on one side, resulting in injury.

DOs

- Ventilate the room well at the early stage of product use. Formaldehyde contained in adhesives may still remain, and those with chemical sensitivity or infants may experience allergic reactions.
- When moving the sofa, move with two or more adults. Attempting to move the product alone may result in injury, damage to the product, or scratch on the floor.
- Always use with wooden legs attached. Using the sofa without legs may scratch the floor or result in injury due to damage to the product.

Note (Other Cautions)	
	● Do not use on an uneven or jointed floor when the felt is attached to the product. Doing so may cause the felt to be removed, resulting in dirt or scratches on the floor. ● Using the sofa on tatami or cushioned flooring (sheet flooring) may cause dents on the floor. Please use sofa on floor coverings such as carpet. ● Do not use an organic solvent such as thinner or bleach to clean the product. Doing so may cause deformation or discolouration. ● Do not leave a chemical wipe on the product for a long time. Doing so may cause discolouration or peeling of the surface material.

Parts

Ⓐ Main Unit × 1

ⓔ Headrest Inner Cushion (small)
× 1

ⓕ Backrest Inner Cushion (medium)
× 1

ⓖ Seat Inner Cushion (large)
× 1

Part Names

(When separately sold cover is attached)

Note (Other Cautions)	● Always use with the cover designed for the sofa (sold separately) attached. ● Refer to the User Guide provided with the cover (sold separately) for details on how to attach the cover.

Directions for Use

■ Backrest Angle Adjustment

[Returning the Backrest to the Upright Position]

Raise the backseat from the locked position of ① and fix the angle where it clicks.

[Reclining the Backrest]

Raise the backrest beyond 90 degrees to release the lock, and push back to position ①.

⚠ CAUTION	❗ When operating reclining, hold the sofa with both hands. Holding only one side when adjusting may cause only one gear to lock and damage the gears, resulting in injury.

■ Headrest angle adjustment

[Returning the Headrest]

Raise the headrest from the locked position of ① and fix the angle where it clicks.

[Reclining the Headrest]

Push the headrest forward to release the lock, and return to position ①.

Moving the product

⚠ CAUTION	⃠ Always move the product with two or more persons. Failure to do so may cause injury, damage to the product or scratches to the floor.

- When moving the product, be sure to hold the underside of the seat with both hands. The product must be moved by at least two adults. Do not drag the product on the floor.

Disposal

Dispose of this product in accordance with the regulations of your local government.

Care Instructions

Maintenance and inspection

- Periodically check for any looseness in the leg bolts, and re-tighten if any looseness is found. Doing so will prevent injury, or damage or scratches to the floor.
- Periodically check for any looseness or wobbling in all parts, and stop use immediately if any abnormalities are found. Failure to do so may cause damage to the product or injury.
- Take insecticidal measures immediately if any type of pest is found. If left untreated, insect damage may worsen.

Dirt and stains

Maintenance for the cover

- For daily care, wipe the product with a soft, dry cloth. Remove the dust by using a brush or a vacuum cleaner (low setting).
- If the product is particularly soiled such as coffee stains, soak a soft cloth in a warm 3 to 5% solution of neutral detergent, wring out the cloth thoroughly and pat the cloth on the surface of the product to remove the stain. Then, wipe off the residual detergent with a clean, wet cloth and dry naturally.
- When washing the cover, follow the washing instructions on the cover and handle properly.

Maintenance for the legs

- Gently wipe off dust from coated surfaces using a soft cloth or duster. Rubbing the surface with a stiff cloth or with dust on the surface may result in small scratches.
- If the product is particularly soiled, wipe the dirt off with a cloth dampened in a 3 to 5% neutral detergent solution. Then wipe off any detergent residue with a damp cloth. Next, gently wipe off with soft and dry cloth and then dry naturally.
- Do not leave a chemical wipe in contact with the product for a long time. Doing so may cause peeling of the surface material or discolouration.

Usage

Natural wood

- This product is manufactured using natural wood. There are differences in the grain and colour as a result of using natural materials. Please note that the wooden grain and colours of all the products are not the same.
- Please note that cracks and warping may occur in natural wood in the following conditions.
  ① Avoid use in a place subject to direct sunlight wherever possible.
  If use in direct sunlight is unavoidable, reduce the amount of sunlight using curtains, etc.
  ② Avoid use near heaters or air conditioners. Be sure that the air from heaters or air conditioners does not come into direct contact with the product.
  ③ In particular, air from heaters in the winter season is very dry and can easily cause cracks and warping in natural wood.

Formaldehyde countermeasures

- What is Formaldehyde?
  Formaldehyde is said to be one of the causative substances of sick house syndrome. It is a colourless chemical substance with irritating odour that vaporizes at the ambient temperature. Formaldehyde is included in furniture, construction materials, adhesive for wallpaper, and so on. Since it is eventually diffused, staying in a room contaminated by formaldehyde may cause irritated eyes and throat. If the concentration of formaldehyde is high, it may even cause breathing difficulty.
- Ventilate the room.

⚠ CAUTION	❗ Ventilate the room well when installing the furniture. Infants and those who are sensitive to chemicals may have allergic reactions.

  Since formaldehyde is easily dispersed in the air, periodically ventilate the room. When several pieces of furniture are placed at the same time, pay closer attention and open the windows widely for sufficient ventilation. More formaldehyde is released when the room temperature increases. Therefore, be careful if the room is closed for a long time during the summer, and ventilate the room thoroughly. In order to increase ventilation efficiency, it is recommended that you open multiple windows, or use a ventilation fan or air circulator.
- For persons who have high sensitivity to chemicals
  There are individual differences in resistance to chemicals other than formaldehyde that are related to sick house syndrome. Therefore, even when the actual formaldehyde value in the room is lower than the indoor concentration guideline value (indoor concentration of formaldehyde that is desirable for health), some people react to formaldehyde. At present, MUJI furniture products are made with materials that emit as little formaldehyde as possible, but this does not guarantee that no formaldehyde is emitted at all. If you experience any allergic symptoms, it is recommended to see a physician.
- MUJI furniture is shipped with a formaldehyde absorption/decomposition sheet inside the packaging.
  If the product is used in a restricted space, formaldehyde may be re-absorbed by the material if there is nowhere for it to dissipate. Formaldehyde absorption / decomposition sheets are used to reduce the concentration of formaldehyde as much as possible before the product reaches the customer.
  * Effectiveness of the "formaldehyde absorption / decomposition sheet" in the packaging has been expended by the time the package reaches the customer, and it can be disposed of as combustible rubbish.

Cushioning material (urethane foam)

- There may be a unique odour to the product when it is unwrapped. This odour will gradually disappear through use. If you are concerned about the odour, dry in a well ventilated place without direct sunlight before use.
- Some of the cushioning material may become discoloured during the production process, but this does not affect the functionality of the product.
- Urethane foam may discolour and become yellow if left for a long periods of time due to the characteristics of the material, but this does not affect the functionality of the product.
- The stuffing inside the cushion tends to move to a corner. In order to prevent the cushion from losing its shape, periodically knead the cushion, and let air in to fix up the shape.
- Due to material qualities, firmness may change slightly with changes in temperature. Material may become softer in high temperatures, and harder in low temperatures.

Usage (Cont'd)

Outer shell

- The outer shell of the product has a fastener which is used when manufacturing the product. Do not open it in attempt to repair the product, etc. Doing so may result in damage or injury.
- Always keep the separately sold cover attached because the outer shell cannot be washed.

Operating the product

Sounds may be heard from the gears when reclining the backrest, but this does not affect the functionality of the product.

Specifications

Product Name	HIGH BACK RECLINING SOFA / 1S
JAN	4550002405236
Product Dimensions	W740 × D11400 - 1345 × H665 - 895 mm Seat Height: 380 mm
Product Weight	Approx.19 kg
Usage	Sofa for 1 person
Materials	Structural Element: Main unit frame: Metal (steel) Legs: Natural wood (oak) Surface Finish: Legs: Urethane resin coating Covering Material: 100% Polyester Cushioning Material: Urethane foam / Polyester filling/ Steel springs (S springs)
Country of Origin	China

Contact Information

For your inquiry about the product, please contact the store where you bought it.

MUJI 無印良品

保存用

高靠背斜倚沙发椅/主体/1人座

使用说明书

本次承蒙惠购本商品，在此深表感谢。
使用前请务必仔细阅读本文，并在充分理解的基础上再进行使用。
此外，请务必妥善保管本文，以备随时进行确认。

目录 页

重要通知 (安全注意事项)	18 ～ 20
配件清单	21
各部位名称	21
使用方法	22
保养方法	22
产品故障分析和排除	23
使用注意事项	23 ～ 24
有害物质限量的控制指标	24
产品规格	25
联系方式	25

2023 年 8 月 24 日

重要通知(安全注意事项)　请务必遵守。

为了防止使用者或他人遭受危害和经济损失，本文中记述了确保安全且正确使用的重要内容。
请在充分理解下述内容(标示/图形符号)的基础上仔细阅读本文，并严格遵守所述事项。

●标示说明
按错误使用所造成的危害或损失程度进行分类说明。

⚠ 警告	可能会导致使用者死亡或重伤(※1)的内容。	⚠ 注意	可能会导致使用者遭受伤害(※2)或物质损失(※3)的内容。

●图形符号说明
通过以下图形符号对应严守的内容进行说明。(以下为图形符号范例。)

⃠	不得执行的“禁止”内容。	❗	必须执行的“强制”内容。

※1 所谓重伤，是指因失明或受伤、烫烧伤、骨折、中毒、触电等原因而留下后遗症以及需住院治疗、长期就医的伤势。
※2 所谓伤害，是指无需治疗或住院、长期就医的受伤、烫烧伤。
※3 所谓物质损失，是指住房、家庭财产相关的连带损失。

⚠ 开箱时的注意事项

⚠ 警告	
⃠ 禁止	● 对于多余的包装材料应立即进行清理，请勿放置于儿童可以触及的场所。 否则可能有因包装材料套住头部等阻碍嘴或鼻的呼吸而导致窒息的危险。

⚠ 设置环境注意事项

⚠ 警告	
⃠ 禁止	● 请勿放置于火炉等火源附近。否则可能引起火灾。 ● 请注意勿使产品脚部等压住家电产品的电源线。否则可能会因电源线断裂而导致触电、火灾。

⚠ 注意	
⃠ 禁止	● 请勿使产品受到阳光直射以及直接接触照明、火炉和空调等热源及暖风直吹。否则可能导致弯曲、歪斜、开裂或变色等而受伤。 ● 请勿长期设置于潮湿场所(参考：湿度在70%以上且室温在20℃以上)。否则可能导致发霉或螨虫等繁殖而危害健康。
❗ 严守	● 如果将产品长期设置于同一场所使用，则可能导致地面与产品脚部的接触面产生凹陷而损伤地面。请务必将产品设置于地毯等铺垫物上，或在脚部底面粘贴毛毡等后再使用。此外，用于软木地板等时，可能会由于木部的涂料与软木地板发生反应而变色。

请求(其他 注意事项)	
	● 请放置于平坦、稳定的场所。如果在不平稳的场所使用，则可能导致产品变形、损坏。

⚠ 使用注意事项

⚠警告

禁止

- 请勿让婴幼儿睡在本产品上。否则可能摔落地面而导致窒息。
- 请勿让儿童在无家长监督的环境下单独使用。
- 请勿使烟灰等掉落于商品上。否则可能引起火灾。
- 请勿用于座椅以外的其他用途。否则可能导致意外受伤。
- 请勿在坐着时使商品倾斜等不稳定状态下使用。否则可能因翻倒或商品损坏而导致意外受伤。
- 请勿在商品上站立、跳跃或将其作为脚踏使用。否则可能因失衡翻倒、商品损坏而导致受伤。
- 请勿使用损坏、变形的商品。否则可能会导致意外受伤。
- 请勿擅自维修或改造。否则可能导致产品强度下降而受伤。
- 在倒置的状态下请勿从上方施压。否则可能会由于商品齿轮部位等损坏而导致受伤。
- 请勿坐在靠背上等对靠背上部过度施压。否则可能会因齿轮损坏而导致受伤。

- 请勿登上产品后脚部位，否则十分危险。
  可能导致受伤或损坏主体。

- 请避免坐下时用力过度等对靠背施加强烈冲击。
  否则齿轮可能会损坏而导致受伤。

- 请勿2人以上同时使用。否则可能会因翻倒或产品损坏而受伤。

⚠注意

禁止

- 请勿在产品周围或上方放置物品。否则可能会因物品掉落而导致受伤。
- 请勿在室外使用。否则可能发生变形或严重劣化而导致受伤。
- 齿轮附近的缓冲材较薄。请勿在该处附近倚坐或踩踏。否则可能会导致意外受伤或产品损坏。
- 放倒靠背时请确认后方是否无人或物品。否则可能会导致意外受伤或产品损坏。
- 移动沙发椅时请注意勿使其掉落或拖动。
  否则可能会损伤地面或因主体损坏而受伤。

- 请勿坐在边端部分。
  否则可能导致靠背损坏而受伤。

- 请勿坐着同时单手操作齿轮调整靠背角度。
  否则由于仅单侧齿轮运转，可能会导致靠背损坏而受伤。

严守

- 刚开始使用时，请务必对室内进行充分换气。粘合剂等可能含有甲醛残留物，易导致化学物质敏感体质者及婴幼儿等出现过敏症状。
- 移动时，请务必确保成人2人以上共同作业。如果1人强行搬动，则可能导致受伤、商品损坏或损伤地面。
- 请务必在安装木脚的状态下使用。若未安装，则可能导致在地面上留下伤痕、产品主体破损而受伤。

请求(其他 注意事项)	
	● 在粘贴毛毡的情况下，请勿设置于有凹凸或接缝等高低不平的地面上使用。否则可能因毛毡剥落而导致污损或损伤地面。 ● 如果在软木地板(粘贴式木地板)等上面使用，地面可能会出现凹陷，请将沙发椅设置于地毯等铺设物上。 ● 清洁时，请勿使用天那水等有机溶剂或漂白剂等药剂。否则可能导致变色或变形。 ● 请勿使产品长时间接触化学抹布。否则可能导致变色、表面剥落等现象。

配件清单

Ⓐ 主体×1

ⓔ 靠头内垫(小)
×1

ⓕ 靠背内垫(中)
×1

ⓖ 座部内垫(大)
×1

各部位名称

(安装另售的专用沙发套时)

请求 (其他 注意)	● 使用时请务必安装另售的专用沙发套。 ● 沙发套安装方法请确认另售沙发套附带的说明书。

使用方法

■ 靠背角度调节方法

【立起靠背时】

从①的状态(锁定状态)立起靠背，在听到“咔嚓”声的位置停止即可固定。

【放倒靠背时】

将靠背向前放倒90度以上即可解除锁定并恢复至①的状态。

⚠ 注意	❗ 调节靠背角度时，请握住靠背的两侧进行。 如果仅握住单侧操作，可能仅单侧的齿轮容易锁定，从而导致齿轮损坏而受伤。

■ 靠头垫角度调节方法

【立起靠头垫时】

从①的状态(锁定状态)立起靠头垫，在听到“咔嚓”声的位置停止即可固定。

【放倒靠头垫时】

将靠头垫向前放倒90度以上即可解除锁定并恢复至①的状态。

关于移动

⚠ 注意	⃠ 请勿1人搬运商品。否则可能会导致受伤、损坏或造成地面损伤。

● 移动时请务必用两手抬住座部底面搬运。
请避免在地面上拖动，至少由2名以上成人同时抬起搬运。

关于报废

报废时，请按各地区规定的方式进行处理。

保养方法

保养/检查

● 请定期检查固定脚部的螺栓是否无松动，一旦发现松动请重新紧固。以免造成受伤或商品损坏、划伤地面。

● 请定期检查各部分是否没有松动或摇晃，发现异常时请立即停止使用。否则可能导致商品损坏、受伤。

● 发现害虫时，请立即进行杀虫及防虫处理。若置之不理则可能导致虫害范围扩大。

关于污垢

沙发套保养方法

● 日常保养时请用软布干擦。对于灰尘等，请使用毛刷或吸尘器(弱风)等进行清除。

● 如果沾上咖啡等污渍严重时，请用温水将中性洗涤剂进行3-5%稀释，将软布浸湿、拧干后，轻敲式地擦拭表面。然后，请用清水浸润的湿布将洗涤剂擦拭干净并使其自然风干。

● 沙发套洗涤方法请按其附带的洗涤标示正确进行洗涤。

脚部的保养方法

● 涂装面的灰尘请用软布或掸子等轻轻掸去。若用硬布等直接擦拭灰尘则会留下细小划伤。

● 污垢严重时，请用经过3-5%稀释的中性洗涤剂将布浸透后擦除污垢，再用清水浸湿的布将洗涤剂擦拭干净。最后用柔软的干布轻轻擦拭后使其自然风干。

● 请勿使产品长时间接触化学抹布。否则可能会导致表面剥落或变色。

产品故障分析和排除

● 使用初期觉得有气味的话
由于是直接工厂放入箱子里，从箱子里拿出来后一段时间会有气味。如果在意的话，可以将其在无阳光直射无雨的地方放置一段时间。慢慢的气味会变淡。

● 家具不稳定的情况下
请确认家具和地面的接触面是否有夹杂物品。如有障碍物，可以将其移走将家具放在平坦的地面。带有调节器的家具，可以进行调整保证其不会前后左右晃动。

● 感觉有摇晃的话
点检各部件的螺丝钉或螺栓是否有松动的情况。如有松动的话请重新安置。部分零件如有裂痕或破损的话请停止使用。

● 其它
上述内容解决不了的问题或存在不清楚的地方请联络所购的店铺。

使用注意事项

关于天然木材

● 本商品采用天然木材制作，木纹及色调等均具有天然木材特有的个体差异。因此，商品会在木纹及色调上存在差异，敬请谅解。

● 天然木材由于以下条件，可能会出现开裂或弯曲等，敬请注意。
① 请尽量避免在阳光直射的场所使用。
难以避开阳光直射时，请尽量使用窗帘等遮挡。
② 请尽量避免在冷暖气设备附近使用。请切勿在冷暖气设备风口处使用。
③ 尤其是冬季的暖气会使室内极度干燥，因而可能导致天然木材发生开裂、弯曲。

关于甲醛对策

● 何谓甲醛
据说甲醛是导致病态建筑综合症的物质之一。是一种在常温下会气化的无色且具有刺激性气味的化学物质，除了家具以外，建筑材料、粘贴墙纸使用的粘合剂等中均含有这种物质。由于会逐渐扩散，所以如果长时间滞留于被甲醛污染的室内环境，将会刺激眼睛、导致咽喉产生不适的刺激感。如果浓度过高，还可能导致呼吸困难。

● 请对房间进行换气。

⚠ 注意	❗ 设置家具后，请务必对室内进行充分换气。 否则可能导致化学物质敏感体质者及婴幼儿等出现过敏症状。

甲醛易在空气中扩散，故请在日常随时对室内进行充分换气。同时设置多款家具时，请尽量开大窗户，对室内进行充分换气。室内温度一旦升高，甲醛可能出现加速扩散的倾向，所以在夏季长时间门窗紧闭时，请务必确保充分换气。为了提高换气效率，建议同时打开多扇窗户，开启换气扇、电风扇、空气循环风扇等。

● 致化学物质过敏体质的用户
除甲醛以外，其他导致病态建筑综合症的化学物质在容许量上也均因人而异。因此，即使浓度在室内浓度标准值(不会影响健康的甲醛室内浓度值)以下，也会存在过敏反应体质的用户。我们在目前的无印良品家具上已尽力使用甲醛释放量较少的材料，但依然无法完全阻止扩散，故请多加注意。
一旦出现过敏症状，建议立即向医生咨询。

● 无印良品的家具在封装出厂时均已放入甲醛吸附/分解纸
甲醛在狭窄的空间内无处可逃，可能再次被材料吸附。因此，为了尽量降低送达顾客手中的商品所附甲醛浓度，我们在封包中放入了甲醛吸附/分解纸。
封包中的“甲醛吸附/分解纸”在运输等过程中性能已下降，故请作为可燃垃圾处理。

使用注意事项

关于缓冲材料(聚氨酯泡沫)

- 开封时可能会闻到特有的气味。气味会在使用过程中慢慢消失。万一介意气味时，请放在不受阳光直射且通风良好的背阴场所晾置后再使用。
- 本产品根据生产工序，部分缓冲材料可能会发生变色，但对原本使用功能不会造成影响。
- 由于聚氨酯泡沫的特性，长时间放置会变为黄色，但不会妨碍原本使用功能。
- 内垫材料容易偏向一侧。为了防止走形，请定期揉搓坐垫，使空气充盈其中，保持良好的形状。
- 由于材料特性，根据温度变化会出现些许变硬的情况。温度高会变软，温度低会变硬。

关于表面面料

- 本产品的表面面料由于生产工序所需而带有拉链。请勿将其打开进行修整等。否则可能会导致损坏或受伤。
- 由于表面面料不可洗涤，请务必安装另售的专用沙发套再使用。

关于操作

操作斜倚靠背时齿轮会发出声响，但对原本使用功能不会造成影响。

有害物质限量的控制指标

木家具中有害物质限量　符合GB 18584
甲醛释放量：≤1.5mg/L
木家具中重金属限量
可溶性铅：≤90mg/kg
可溶性镉：≤75mg/kg
可溶性铬：≤60mg/kg
可溶性汞：≤60mg/kg
纺织面料甲醛含量　符合GB 18401 C类
甲醛含量：≤300mg/kg

产品规格

产品名称	高靠背斜倚沙发椅/主体/1人座
规格型号	4550002405236
产品尺寸	长740×宽1140～1345×高665～895 mm　座面高 380 mm
	该商品是根据与制造厂商的商定来决定商品的尺寸大小。
产品重量	约19 kg
用　　途	沙发椅/1人用
使用场所	室内
材　　质	结构材料　主体框架：金属(钢) 　　脚　　部：天然木材(白橡) 表面加工　脚　　部：聚氨酯树脂涂装 蒙面材料：聚酯纤维100% 缓冲材料：聚氨酯泡沫、聚酯纤维填充物、钢制弹簧(S弹簧)
执行标准	GB/T 3324-2017
等　　级	合格品
安全类别	GB 18401-2010 C类
原 产 国	中国

联系方式

有关商品的咨询，请联系购买的代理商。

销售商：**无印良品(上海)商业有限公司**
地　址：上海市静安区南京西路1601号35楼
　　3501-3508室（邮编200040）
电　话：021-63756677
www.muji.com